


*HONDA Robin - Horally  
Honda*

# ホンダ

## NSR250R・NSR250R SP

# サービスマニュアル



NSR250RG-J  
NSR250R SP



	MAINTENANCE INFORMATION	1
	INSPECTION, ADJUSTMENT	2
ENGINE	OIL LUBRICATION SYSTEM	3
	FUEL SYSTEM	4
	COOLING SYSTEM	5
	ENGINE REMOVAL	6
	CYLINDER HEAD, CYL, PISTON, PC VALVE	7
	CLUTCH, KICKSTARTER, GEAR SHIFT LINK	8
	TRANSMISSION	9
	<b>AC</b> GENERATOR	10
	CRANKCASE, CRANKSHAFT	11
	FRAME	FRONT WHEEL, SUSPENSION, STEERING
REAR WHEEL, SUSPENSION		13
BRAKES (DISC BRAKE)		14
FAIRING, EXH CHAMBER, RR FENDER, <sup>SUB</sup> FRAME		15
ELECTRICAL	BATTERY, CHARGING SYSTEM	16
	IGNITION SYSTEM	17
	LIGHTS, METERS, SWITCHES	18
	CONTROL UNIT, SERVO MOTOR, <sup>OIL PUMP</sup> SOLENOID	19
	<b>NSR250R(J)</b> SPECIAL FEATURES	20
	<b>NSR250R-SP</b> SPECIAL FEATURES	21

# MAINTENANCE INFORMATION


# 1.

IDENTIFICATION SYSTEM		SPECIAL TOOLS	
COLOUR LABELS	1 - 1	STANDARD TOOLS	1 - 19
SPECIFICATIONS	1 - 2	LUBRICATION POINTS	1 - 21
SPECIFIC INFORMATION	1 - 3	WIRING DIAGRAM	1 - 22
WARNINGS	1 - 9	WIRING MAP	1 - 23
TORQUE SETTINGS	1 - 17	TROUBLE SHOOTING	1 - 26


## IDENTIFICATION SYSTEM, COLOUR LABELS



FRAME NUMBER



ENGINE NUMBER




WHEN PAINTING ITEMS, USE THIS MODEL NAME AND COLOUR CODE

Make	Honda MC16	
Length	2.035m	
Width	0.705m	
Height	1.105m	
Wheel base	1.360m	
Engine Type	MC16E	
Engine capacity	249cm <sup>3</sup>	
Motive Power	Petrol	
Vehicle Weight	Frt	70kg
	Rr	71kg
	Ttl	141kg
Rider No.	2人	
Gross Weight	Frt	91kg
	Rr	160kg
	Ttl	251kg
Tires	Frt	100/80-17 52H
	Rr	130/70-18 63H
Ground clearance	0.135m	
Braking Distance (50K/h)	14.0m (50)	
Turning circle	2.9m	
Starting	Kickstart	
Fuel	Petrol 2 cycle	
Cyl. Configuration	V 2	
Com. Type	Half ball	
Bore X stroke	54.0×54.5mm	
Comp. ratio	6.2	
Cyl. Comp	12.0kg/cm <sup>2</sup> -400rpm	
Max Horsepower	45PS/9500rpm	
Torque	3.6kgm/8500rpm	
Port Timing	Open	Movement Automatic
	Close	Movement Automatic
Intake	Open	78°-94° (BBDC)
	Closed	78°-94° (ABDC)
Exhaust	Open	62° (BBDC)
	Closed	62° (ABDC)
Idle speed	1200rpm	
Lubrication	Forced pressure wet sump	
Oil pump	Plunge type, Tricoid type	
Oil capacity	*2.2ℓ	

Cooling system	Water cooled	
Air cleaner type	Foam	
Fuel tank cap.	16ℓ	
Type	TA10	
Gas intake	28mm	
Venturi bore	28mm	
Type	CDI式	
Ign Timing	15°BTDC, 1200rpm	
Spark Plug	NGK	B8ECS, B9ECS, B10ECS, B8ES, B9ES
	ND	W24ES-C, W27ES-C, W31ES-C, W24ES-U, W27ES-U
Plug Gap	0.7-0.8mm	
Battery	12V 3 AH	
Clutch - type	Wet coil spring	
operation	manual	
Primary Reduction	2.652	
Trans - type	Usual method	
1st gear	2.642	
2nd gear	1.800	
3rd gear	1.380	
4th gear	1.125	
5th gear	1.000	
6th gear	0.916	
Reduction - method	Chain	
Final	2.800	
Frt Wheel	Caster	26°00'
	Trail	103mm
Tire pressures	Frt	2.25kg/cm <sup>2</sup>
	Rear	2.50kg/cm <sup>2</sup>
Strg angle	Left	32°
	Right	32°
Brakes	Frt	Pressurised disc
	Rear	Pressurised disc
Suspension	Frt	Telescopic
	Rear	Swing arm
Frame type	Diamond	
Frame No. NO.	MC16-1000001~	
Engine No. NO.	MC16E-1000001~	
*: Transmission Oil	0.9ℓ	
Engine oil	1.3ℓ	

SPECIFIC INFORMATION






### VARIABLE EXHAUST PORT VALVE SYSTEM

Set Valves in cyl. exhaust port, and these valve will move in proportion to the engine revolutions. According to the change in height of the exhaust port the exhaust timing will be varied and power increase from low to high revolutions is shown here.


This system is totally controlled by the PGM control unit. Current will flow into the Servo Motor according to engine revolutions and Servo Motor resistance by calculating the engine revolutions from the front cylinder CDI

The Servo Motor will move by means of current from the control unit and by means of the control cable, move the RC valve




## CONTROL UNIT

The control unit calculates the pulse (eng. Revs) from the CDI unit, and allots the flow of current to the RC Valve Servo Motor and Oil Pump Solenoid. The pulse from the CDI unit is calculated according to the units internal revolutions calculation circuit, and is inputted into the micro computer. According to these engine revolutions, the micro computer will flow current through the solenoid driver and motor driver to the Servo Motor and Oil Pump Solenoid.




## CASSETTE TRANSMISSION

Depending on how the transmission bearing holder is held in the crankcase with the knock pin and bolt, the transmission can be adjusted while the engine is in the frame.




## CRANKCASE REED VALVE

Depending on the set-up of the reed valve in the crankcase, a large intake valve will increase, and will supply air mixture into the crankcase. Also if there is no reed valve in the cylinder, because there is no intake port hole, the influence of the cylinder disappears (warpage etc)









## INTAKE CHAMBER





When the reed valve pressure is to the maximum limit, the intake air capacity will increase and the output will increase. However, at partial throttle, depending on the throttle valve resistance, the insulator internal pressure will increase and the intake air pressure will completely decrease

























































下記のシンボルマークは、このマニュアルを通しての注意事項や、作業方法を示している。



:



: OP.



:



:



:



:



:



:

TORQUE SETTINGS:

ENGINE

Item	Nbr	Screw Dia (mm)	Torque (kg-m)	Note
Spark plug	2	14	1.5-2.0	
Cylinder head nut	12	7	1.2-1.6	
Cylinder nut	8	8	2.3-2.7	
Clutch lock nut	1	18	5.5-6.5	
Shift drum/stopper arm	1	6	0.8-1.2	
Shifter pin	1	8	2.1-2.5	Apply locking agent
AC Generator, flywheel bolt	1	10	8.0-9.0	UBS
AC Generator, stator bolt	3	6	1.0-1.4	
Crankcase 8mm bolt	6	8	2.1-2.5	
Primary drive gear bolt	1	10	9.0-10.0	Left thread
Neutral switch	1	10	1.4-1.8	
Clutch lifter arm stopper bolt	1	6	0.8-1.2	
Water pump impellor	1	14	1.0-1.4	
Oil drain bolt	1	12	3.0-4.0	
RC Valve shift nut	2	6	0.8-1.0	Left thread
Cylinder head bi-pass tube joint	1	6	0.25-0.45	

FRAME

Item	Nbr	Screw Dia (mm)	Torque (kg-m)	Note
Front axle pinch bolt	4	7	1.5-2.0	
Front axle bolt	1	14	5.5-6.5	
Rear axle nut	1	16	8.0-10.0	
Engine hanger plate bolt (8mm)	4	8	2.4-3.0	
Engine hanger bolt (10mm)	3	10	4.5-5.5	
Side stand bolt	1	10	1.0-2.0	
Side stand lock nut	1	10	3.0-4.0	
Side stand bracket bolt	2	8	2.4-3.0	
Sub frame bolt	4	10	3.5-4.5	
Step stay bolt	4	8	2.4-3.0	
Rear brake reservoir bolt	1	6	0.7-1.1	
Rear brake master cylinder bolt	2	6	1.0-1.4	
Exhaust chamber pinch bolt	2	8	2.4-3.0	
Silencer pinch bolt	2	8	2.4-3.0	
Chamber/silencer joint bolt	6	6	1.0-1.4	
Shift change pedal bolt	1	6	1.0-1.4	
Kick starter pedal bolt	1	8	3.5-4.5	
Fairing stay bolt	2	8	2.4-3.0	
Fairing sub stay bolt	4	6	1.0-1.4	

		mm	kg-m
Handle bar bolts	2	8	2.4-3.0
Main switch bolts	2	8	2.4-3.0
Seat bolts	1	8	2.0-2.4
Fule cock	1	22	2.0-2.5
Clutch lever bracket bolt	2	6	0.7-1.1
Rear fork pivot bolt	1	14	6.0-7.0
Rear fork pivot lock nut	1	26	6.0-7.0
Rear fork pivot adjust bolt	1	26	1.0-2.0
Steering stem nut	1	24	9.0-12.0
Steering adjustment nut	1	26	2.3-2.7
Top bridge bolt	2	7	0.9-1.3
Bottom bridge bolt	2	10	4.5-5.5
Front brake barcket caliper bolt	4	8	2.4-3.0
Front brake master cylinder bolt	2	6	1.0-1.4
Brake hose bolt	5	10	2.5-3.5
Front axle hose stay bolt	3	6	1.0-1.4
Front brake pipe	2	10	1.6-1.8
Bleeder valve bolt	3	7	0.4-0.7
Cushion conrod bolt (frame)	1	10	6.0-7.0
(cushion arm)	1	10	6.0-7.0
Cushion arm bolt	1	10	6.0-7.0
Rear cushion upper bolt	1	12	6.0-7.0
Rear cushion lower bolt	1	10	6.0-7.0
Front brake disc bolt	6	6	1.4-1.6
Front fork socket bolt	2	8	1.5-2.5
Front fork bolt	2	35	1.5-3.0
Driven sprocket nut	6	8	2.8-3.4
Rear cushion lwr joint lock nut	1	12	6.0-7.5
Rear cushion lower joint	1	12	3.8-6.0
Rear brake disc bolt	3	8	3.7-4.3
Front brake hangler pin	4	10	1.5-2.0
Rear brake hanger pin retainer bolt	1	6	0.8-1.3
Rear caliper pin bolt	1	10	2.4-3.0
Rear caliper bolt	1	8	2.0-2.5

STANDARD TORQUES

6 mmSH: : 8 mm

Size	Torque (kg-m)	Size	Torque (kg-m)
5mm bolt, nut	0.45-0.6	5 mm screw	0.35-0.5
6mm bolt, nut	0.8-1.2	6 mm screw 6 mm SH	0.7-1.1
8mm bolt, nut	1.8-2.5	6 mm flange bolt, nut	1.0-1.4
10mm bolt, nut	3.0-4.0	8 mm flange bolt, nut	2.4-3.0
12mm bolt, nut	5.0-6.0	10mm flange bolt, nut	3.5-4.5

SPECIAL TOOLS, STANDARD TOOLS

New special tools	Tool	Use	
Gear holder	07HMB-KV30100	Primary drive gear removal	8
Rotor puller attachment	07HMC-KV30100	Flywheel removal	10
Needle bearing driver attachment	07HMD-KV30100	Rear fork l. pivot brg instal	13

Special Tools

Pilot screw wrench	07908-4220201	Carburettor synchronization	4
Snap ring plier	07914-3230001	Brake M/cyl separation/assy	14
Steering stem socket	07916-3710100	Steering separation/assembly	12
Lock nut wrench	07GMA-KT70200	Rear fork removal	13
Steering stem wrench	07946-MB00000	Steering separation/assembly	12
Ball race remover set	07946-KM90000	} Ball race removal	12
- Driver attachment A	07946-KM90100		
- Driver attachment B	07946-KM90200		
- Driver shaft assembly	07946-KM90300		
- Bearing remover A	07946-KM90400		
- Bearing remover B	07946-KM90500		
- Assembly case	07946-KM90600		
Rear cushion compressor attach	07959-MB10000	Rear cushion separation/assy	13
Mechanical seal driver	07945-4150400	Water pump mechanical inserter	5
Needle bearing remover	07GMD-KT80100	Rear fork cushion arm bearing cushion conrod bearing, rear cushion bearing removal	13
Fork seal driver	07947-4630100	Front fork oil seal inserter	12
Driver handle	07949-3710001	L. main shaft, L. counter shaft, bearing inserter, rear fork L. pivot bearing removal	9, 13
Driver shaft (B)	07964-MB00200	Rear fork cushion arm brg removal	13
Bearing Remover set (10mm)	07936-GE00000	Water pump brg removal	5
Bearing remover (15mm)	07936-KC10000	} rear fork R. Pivot brg removal	13
- Removerassy (15mm)	07936-KC10500		
- Remover shaft (15mm)	07936-KC10100		
- Remover head (15mm)	07936-KC10200		
- Remover steering weight	07741-0010201		
Bearing remover	07936-3710300	} Cushion conrod brg removal;	13
Remover handle	07936-3710100		
Remover steering weight	07741-0010201		
Outer driver (28x30mm)	07946-1870100	Rear fork L. Pivot brg removal	13

Standard Tools

Float level gauge	07401-0010000	Carburettor float measurement	4
Lock nut wrench (30x32mm)	07716-0020400	Steering stem nut removal	12
Extension Bar	07716-0020500	Lock nut wrench bar	12

Item	Number	Usage	Ref
Clutch centre holder	07725-0050001	Clutch lock nut removal	8
Universal holder	07725-0030000	Flywheel holder	10
Flywheel puller	07733-0010000	Flywheel removal	10
Outer driver (32x35mm)	07746-0010100	Rear fork R.brg insertion	13
Outer driver (42x47mm)	07746-0010300	Driven flange, rear wheel, frt wheel, R.countershaft bearing insertion	9, 12. 13
Outer driver (37x40mm)	07746-0010200	L.Mainshaft brg insertion	9
Outer driver (62x68mm)	07746-0010500	L.countershaft brg insertion	9
Outer driver (24x26mm)	07746-0010700	Rear fork cushion arm brg cushion conrod, rear cushion water pump brg insertion	5, 13
Pilot (10mm)	07746-0040100	Water pump brg inserti	5
Pilot (15mm)	07746-0040300	Swing arm R.pivot brg insert	13
Pilot (17mm)	07746-0040400	Rear fork cushion arm brg rear cushion conrod brg insertion	13
Pilot (20mm)	07746-0040500	Wheel driver flange, R/countershaft brg insert.	9, 12. 13
Pilot (25mm)	07746-0040600	Shift drum bearing insertion	9
Bearing remover shaft	07746-0050100	Wheel brg, collar removal	12, 13
Bearing remover head (17mm)	07746-0050500	R.wheel collar removal	13
Bearing remover head (20mm)	07746-0050600	Wheel bearing removal	12, 13
Driver handle A	07749-0010000	Brg, brg race insertion	5, 9.
Driver handle C	07746-0030100	R.mainshaft brg insertion	12, 13
Inner driver (25mm)	07746-0030200	" " "	9
Rear cushion compressor	07GME-0010000	Rear cushion sep/assy	13
- Compressor screw assy	07GME-1010100	" " "	13
Torque driver	07703-0010500	Carburettor separation/assy	4

#### METERS

Digital circuit tester	07411-0020000	Alternatively Showa Circuit Tester (TH-SH) or Showa Circuit Tester (07308-0020000)	16, 17, 18, 19
		* Always do MF battery charging performance test with digital circuit tester!	
Compression Gauge	07305-0010000	Cylinder compression test	2


LUBRICATION MAP


Engine

Cylinder, piston, crankshaft	Honda Ultra 2 super, or Honda Ultra GP2	Tank Capacity : 1.3ℓ
Crankcase	Honda Ultra U (4 cycle m/cycle, SAE10W-30) or API SE 10W-30 engine oil	Total Capacity : 0.9ℓ

FRAME

Do as shown below  
Apply multipurpose grease to those points shown










0030 Z - KW3 - 0000




WIRING MAP










TROUBLE SHOOTING






POOR ADJUSTMENT TO ENGINE - NO POWER





AT LOW REVS, LOTS OF EXHAUST NOISE



# NSR250R(K)


## NO SPARK FROM SPARK PLUG

If there is no spark, conduct spark test on ignition coil. Measure the ignition coils primary voltage. If there is difficulty with the coil but still normal spark, the ignition coil has been faulty from beginning


PERFORMANCE PROBLEM	CHECK THE FOLLOWING POSSIBLE CAUSES FROM 1.
PEAK VOLTAGE IS LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. TESTING SAMPLING TIME CONSEQUENCES</li> <li>3. IGNITION WIRING CUT, POOR CONTACT</li> <li>4. IGNITION COIL FAULTY</li> <li>5. ENGINE CONTROL UNIT FAULTY</li> </ol> <p>(1-4 If no abnormal conditions, no spark from plugs)</p>
NO PEAK VOLTAGE  PEAK VOLTAGE USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. ADAPTOR MISCONNECTED</li> <li>2. FUSE, MAIN SWITCH, KILL SWITCH FAULTY</li> <li>3. ENGINE CONTROL UNIT COUPLER CONNECTION POOR</li> <li>4. NO VOLTAGE IN ENGINE CONTROL UNIT 16P COUPLER BLACK/WHITE WIRES ( 22.42)</li> <li>5. ENGINE CONTROL UNIT 4P COUPLER WIRE BROKEN, POORLY CONNECTED</li> <li>6. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>7. PULSE GENERATOR POOR QUALITY (MEASURE PEAK VOLTAGE)</li> <li>8. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>9. ENGINE CONTROL UNIT FAULTY</li> </ol> <p>(1-8 If no abnormal condition, no spark from plugs)</p>
PEAK VOLTAGE NORMAL BUT NO SPARK FROM PLUGS	<ol style="list-style-type: none"> <li>1. SPARK PLUGS POOR QUALITY, OR IGNITION COIL SECONDARY CURRENT LEAK</li> <li>2. IGNITION COIL FAULTY</li> </ol>
PEAK VOLTAGE LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>3. TESTING SAMPLING TIME CONSEQUENCES (MEASURE REVOLUTIONS - NORMAL IF VALVE ABOVE STANDARD)</li> <li>4. PULSE GENERATOR FAULTY</li> </ol> <p>(1-3 No abnormal conditions)</p>
NO PEAK VOLTAGE OR USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>2. PULSE GENERATOR FAULTY</li> </ol>



POOR CHARGING




IGNITION TIMING POOR




# NSR250R(K)

## CARBURETTOR AIR JET CONTROL SYSTEM



RC VALVE MOVEMENT POOR



# INSPECTION, ADJUSTMENT 2.

Maintenance Schedule.....	2 - 1	Transmission .....	2 - 7
Steering Brakes .....	2 - 5	Electrical System .....	2 - 11
Brake Fluid Reservoir .....	2 - 5	Maintenance Items .....	2 - 12
Brakes - Disc and Pads .....	2 - 6	Cooling System .....	2 - 16
Suspension .....	2 - 7	Maintenance Items.....	2 - 17

## MAINTENANCE SCHEDULE

		Cont Intervals	1 MLhs	16 MLhs	112 MLhs	
STEERING	I/Boards	- Play			●	
		Damage			●	
		Left, Right turning			●	
	F Forks	Damage		●	●	
		Fork spindle installation		●	●	Tighten steering stem
		Fork spindle movement		●	●	Tighten steering stem
	Brake Pedal	Play and performance when pushed		●	●	Play 10-20mm Pedal 20-30mm Lever
		Noise	●			
		Brake noise		●	●	
		Leakage, damage, installation		●	●	
Brake hose replacement					Every 4 years	
Res Tank	Fluid capacity	●	●	●	Fluid level Front between top & bottom mark Rear between top & bottom amrk	
	Damage, wear			●		
M/cyl, wheel cyl, Disc, caliper	Master cylinder, cylinder cap, dust seal, disc caliper replacement				☆ Every two years	
	Disc to pad clearance			●		
Brake Disc/Pads	Pad wear		○	●	Indicator	
	Disc wear and damage			●	Standard : F - 4.0mm R - 3.0mm Ser. limit : F - 3.5mm R - 4.0mm	
	Brake fluid replacement				Every year	

		6	12		
WHEEL	Tire Pressures	●	● ●	Frt	Rear
				1 rider	2.25      2.25
				2 riders	2.25      2.50
				Tire type	.10/70R17 54H   150.60R18 67H
	Tire wear and damage	●	● ●		
	Tire tread depth	●	● ●	Min - Frt 0.8mm	Rear 0.8mm
	Foreign articles struck in tires	●	● ●		
	Wheel nut, wheel bolt loosening			Tighten axle nut, axle holder front axle holder torque	1.8-2.5 Kg.m
				Fro axle bolt torque	5.5-6.5 Kg.m
				Rr axle nut torque	8.5-10.5 Kg.m
Rim, side rim, wheel disc damage	○	●	Wheel rim runout, warpage		
			Front	2.0mm axial 2.0mm radial	
			Rear	2.0mm axial 2.0mm radial	
Front wheel bearings		●			
Rear wheel bearing		●			
Rush Spring Arm	Damage		●	Tighten cushion, spring	
	Arm damage		●		
Shock Abs	Fluid leakage, damage		●		
	Bushings		●		
Clutch	Lever play		● ●	Play - lever	10-20mm
	Use	○	● ●		
Trans	Fluid leakage, oil capacity		● ●	Oil capacity - between upper and lower marks	
	Gear movement		●		
Oil	Transmission oil replacement			Every two years	

	12 mths	6 Mths	1 Month	Contin.	
CHAIN AND STROKER	Chain slack	●	●	○	Use side stand and measure play in middle 15-25mm
	Sprocket installation & damage	●			
IGN	Ignition plug performance	●	●		Plug gap 0.7-0.8mm
	Ignition plug replacement				5,000km (every)
BAT	Terminal connections		●		
	Connections & wire damage		●		
WIRE	Twisting, foreign sounds	●	●		
	Low/High speed performance	○	●	●	Idle speed 1200=100rpm
BODY	Exhaust gas	●	●		
	Air cleaner element	●	●		
	Oil leakage and capacity	●	●		Oil capacity Check that pilot lamp does not shine
	Oil leakage	●	●		
	Oil capacity	●			
	Oil cleaner clogging		●		
	Oil pump performance	○	○		
FUEL SYS	Fuel leakage	●	●		
	Carburettor link		●		
	Throttle cable & choke cable		●		
	Fuel filter clogging		●		
	Fuel capacity	●			
	Fuel hose replacement				Every 4 years
COOLING SYS	Water capacity	●	●	●	Between upper and lower levels in reserve tank
	Water leakage	●	●		
	Radiator cap		●		Pressure 1.1-1.4 K/cm <sup>2</sup>
	Cooling agent replacement				Every two years
		●	●		
		●			

	12 mths	6 mths	1 month	Cont'd.
Horn	●			
Labels			●	
			●	
Gauges	●			
Exhaust pipe, muffler	●			
Muffler performance	●			
	●			
			●	
	●	●		
				0

## STEERING SYSTEM


### Steering fork:

Look at front wheel, move frt forks up/down & Left/right & inspect for smooth movement

If there is movement up/down, inspect steering head bearings & replace if abnormal( 12-17)

If there is movement left/right inspect front fork installation

Recheck wiring & cable routings.



## BRAKE SYSTEM

### Brake Pedal


#### Play

Operate front brake lever & rear brake pedal & inspect for brake noise & whether air has entered system or not.

If air has entered then bleed ( 14-3)

#### Pedal Height Adjustment

Loosen rear master cylinder push rod lock nut, turn push rod and the pedal height can be adjusted. After adjusting check rear stop light switch operation timing & adjust if necessary ( 2-17)




## RESERVOIR TANK


### Fluid Capacity

Inspect brake fluid capacity

If below lower mark, remove reservoir cover, set plate & diaphragm & refill front with DOT 4 & rear with DOT3 fluid to upper level  
Inspect for brake pressure & leakage



\* Ensure rubbish does not enter brake fluid when filling  
\* Do not fill reservoir with any item that could contaminate brake fluid  
\* Rear brake fluid inspection can be done without removing side cover






**BRAKE DISC, PADS**

**Pad Wear**

Inspect pad wear using the marks and direction arrows.




Replace if worn to the usage mark ( 14-4)

\* Replace brake pads as a set

Inspect brake disc face for damage & wear ( 14-7)

**Brake Fluid Replacement**

Replace brake fluid once a year ( 14-3)




**MOVEMENT SYSTEM**

**Wheels**

**Tire pressures**

Stu pressures : kg. cm<sup>2</sup>

	FRT	REAR
1 rider	2.25	2.25
2 riders	2.25	2.50
Tire size	100/80-17 52H	130 70-18 63H



Inspect tire pressures with wheels on the ground

**Wheel nut & wheel bolt loosening**

Inspect frt axle bolt & axle pinch bolt for loosening

Inspect rear axle nut for loosening


If loose tighten to torques below:

Frt axle bolt 5.5-6.5Kg-m

Axle pinch bolt 1.5-2.0Kg-m

Rear axle nut 8.0-10.0Kg-m

Inspect frt/rear wheels for warpage and damage ( 12-6; 13-3)



## SUSPENSION

Shock Absorber  
Oil leakage, damage

Apply front brake and inspect front suspension by moving it up & down  
Inspect for front fork oil leakage, damage and loosening




Inspect rear cushion by moving it up & down  
Inspect for rear cushion oil leakage, damage and loosening

Hold rear wheel and push rear fork from left to right, and inspect rear fork pivot bearing condition. If there is movement then replace bearing ( 7-13-14)

### Front Fork Air Pressure

Do not move front wheel  
Remove valve cap  
Measure air pressure using standard air pressure gauge (std pressure 0-0.4Kg-cm<sup>2</sup>)  
When adjusting air pressures, insert air using a hand pump and adjust so that left and right pressures are even

\* When adjusting air pressure do not insert air all at one time  
\* The air mixes with the oil so pressure will drop




## GEARBOX SYSTEM

Clutch

Lever Play

Inspect clutch lever play



Play: 10-20mm



For the main adjustment, remove lower fairing ( 15-3), loosen lock nut and turn adjuster nut.

For final adjustment, loosen handle lock nut and turn adjuster

\* Do not increase adjuster thread more than 8mm




#### TRANSMISSION

##### Oil Leakage & Oil Capacity

\* Inspect level, with motorcycle on level ground  
If below upper level mark, fill with recommended oil to upper level mark

##### Recommended Transmission Oil

Honda standard oil Ultra U (4 cycle motorcycle SAE10W-30) or AP SE 10W-30 engine oil)



## TRANSMISSION OIL REPLACEMENT

\* Run engine & drain while still warm

Remove R lower fairing ( 15-3)  
Remove oil level gauge  
Remove oil drain bolt & drain all oil  
Clean drain bolt & reinstall

Torque: 3.0-4.0Kg-m

\* Replace sealing washer if damaged

Insert recommended oil

Transmission capacity	
Oil Replacement	0.55 L
Total Replacment	0.9 L

Oil replacement time is every 2 years

After confirming no leakages, inspect oil level and reinstall R. lower fairing ( 15-5)

## CHAIN & SPROCKETS

\* Always inspect/adjust drive chain with engine stopped

If there is O-ring damage, chain damage, chain roller wear, or pin loosening, then replace chain





Drive Chain Slack

Stop engine  
Place gears in neutral, pull bike up on side stand and check drive chain movement or sprockets

Maximum Play 15-25mm (on side stand)

Adjust by hand as below

Loosen rear axle nut  
Turn adjuster bolt to adjust



After adjusting, check adjuster plate index mark is in the same position with the index mark on the rear fork on both sides

- \* If the rear fork final groove meets the red portion of the indicator label then replace the drive chain
- \* When replacing drive chain, inspect chain slider also and if necessary replace



Tighten axle nut

Torque: 8.0-10.0 Kg-m

Tighten adjuster bolt

Apply SAE #80-90 gear oil to drive chain


- \* Do not use steam cleaner, high pressure cleaner, or oil cleaner on chain as it will cause damage
- \* Do not use penetration oils that will cause damage to O-ring



### Sprocket Installation & Damage

Inspect drive and driven sprocket for damage and wear, if necessary then replace


- \* Always replace drive chain and sprockets as a set.



### Chain Slider Damager

Inspect chain slider and replace if worn

- \* If the chain and rear fork hit, this will cause wear and damage to rear fork and chain, therefore requiring replacment



## ELECTRICAL SYSTEM

### Ignition System

Remove lower fairing ( 15-3)

Remove plug cap

\* The front cylinder spark plug can be removed with removing the R. lower fairing

### Ignition Plug Performance

Remove spark plug

Inspect plug for wear and build ups

If there are any build-ups, clean with plug cleaner or a wire brush

### Recommended Plugs:

NGK =B8ECS, B9ECS, B10ECS, B8ES, B9ES

ND = W24ES-C, W27ES-C, W31ES-C, W24ES-U  
W27ES-U

\* When installing plug, after inserting it tighten with a plug wrench

Torque : 1.5-2.0 Kg-m

### Ignition Timing

\* This machine uses CDI ignition system so adjustment of ignition timing is not necessary

If ignition timing is wrong inspect CDI unit and pulse generator, if poor then replace

Remove lower fairing ( 15-3)


Warm engine

Remove L. crankcase cover ( 10-2)




Connect timing light cord to rear cylinder high tension cord. Start engine, idle at  $1200 \pm 100$  rpm, and if F mark meets index mark, then rear cylinder timing is okay.

In the same way, connect timing light cord to front cylinder high tension cord  
Idle at  $1200 \pm 100$  rpm and if F mark meets the index mark then front cylinder timing is okay

Increase revolutions and if the F mark exceeds the timing directions the it is okay



PLUG CAP & PLUG



## ENGINE

### Low Speed/high Speed Performance

- \* Adjust idling once the engine is warm
- \* Synchronize carbs after overhauling them

### Start engine

Place gears in neutral. Turn throttle stop screw to adjust idling speed.

Idle Speed:  $1200 \pm 100$  rpm

If idling speed is imbalanced or there is a snapping then synchronize carbs ( 4-16)


### Air Cleaner Element

- Remove seat and fuel tank
- Remove screws and air cleaner case
- Remove element from air cleaner case


Inspect element for dirt and wear  
If dirty then clean it. If worn then replace it  
Wash element with oil cleaner in a safe way.

- \* Do not clean element with petrol, solvents or alkalis
- \* If element is installed squashed then it will become easily worn thus needing replacement



After completing this, then apply Ultra U (4 cycle motorcycle SAE 10W-30 or AP SE 10W-30 engine oil spread over element evenly and reinstall



TERMINAL




SLIDE ADJUST SCREW



Install element into air cleaner case

\* Check that there is no clearance between cleaner case and element  
\* Install element on case side, making sure it fits totally inside case

Install the 6 screws in the air cleaner case  
Reinstall fuel tank and seat



Cylinder Compression

\* Measure while engine is warm

Remove R. lower fairing ( 15-3)  
Pull of spark plug cap  
Remove spark plug  
Insert compression gauge attachment into plug hole and connect compression gauge  
Turn main switch and kill switch off  
Open throttle valve fully and kick kickstarter 5 times & measure each cylinders compression



Compression:  $12 \pm 2 \text{Kg/cm}^2$   
Cylinder difference:  $4 \text{Kg cm}^2$  (under)


METER COMPRESSION GAUGE 07305-0010000

If compression is low, inspect the following:

- Cylinder head gasket damage
- Piston ring damage ( 7-7)
- Piston, cylinder damage ( 7-6.7)

If compression is high inspect the following:

- Carbon build-up in piston head, cylinder head ( 7)



LUBRICATION SYSTEM

Oil Strainer Screen (oil cleaner, clogging)

Remove R. lower fairing ( 15-3)  
Remove oil tube from oil pump side, and drain engine oil into a clean container





Loosen oil tube clips until the oil tank is a set.  
 Pull the oil strainer joint from the tank.  
 Remove the oil strainer screen from the tank.



\* After removing each item, ensure no foreign particles enter the system before installation

Clean strainer screen with pressurised air.  
 Reinstall in reverse to removal procedure.  
 Refill the engine oil into the tank and you must bleed air from air tube and oil pump ( 3-4)

Engine Oil Tank Capacity: 1.3 L

Reinstall in reverse order of removal

\* After completing this process, check each part for oil leakages  
 \* After installing tube you must install tube clip



### Oil Pump Control Cable Adjustment

Remove r. lower fairing ( 15-3)  
 Adjust throttle grip play ( 2-15)  
 Turn throttle grip, in order to turn throttle drum.

At this time, inspect if the oil control lever moves into the oil pump body and that there are no restrictions with the oil pump control cable.


Also inspect that when the throttle drum starts to move, at the same time the oil control cable moves. If it does not move as above, loosen the oil control cable lock nut and turn adjuster nut

After adjusting, open the throttle fully, and confirm that the oil pump body index mark and the oil pump control lever index mark meet

If synchronization is poor the cause may be;

- Oil pump lever, open position is too big
- Oil pump lever open position is too small
- even with adjustment of piston adjuster nut there is no regular movement or no smooth movement

If so replace the oil pump control cable



FUEL SYSTEM

Throttle Valve and Choke Lever

Inspect throttle cable condition, damage and thread

Inspect the throttle grip slides around handle properly.

Inspect the play between the throttle grip and throttle grip flange

Play : 2-6mm

Main adjustment can be done at the carburettor.

Remove fuel tank ( 4-2)





Loosen the pull through throttle cable lock nut, and turn adjuster.

Final adjustment can be done at the handle bars.

Loosen the lock nut and turn the adjuster Even with adjustment using adjuster, if the play is not taken up or operation is not smooth the replace the cable.

Inspect the choke cable condition, damage and thread


inspect for smooth operation from a fully closed to fully open position.



Check that the choke lever will fully open/fully close.

Check that the carburettor bi-starter valve will fully close/open

Adjustment can be done at the carburettor  
Remove the fuel tank ( 4-2)  
Remove the air cleaner ( 4-3)  
Loosen choke cable clamp and hold cable in position with a clamp



#### Fuel Filter Clogging

Remove seat ( 15-1)  
Remove tank ( 4-2)  
Remove fuel cock and fuel filter  
If necessary replace with new parts  
tighten lock nut

Torque : 2.0-2.5Kg-m

#### COOLING SYSTEM

##### Water

\* Place motorcycle on level ground when checking radiator fluid level.  
\* Do radiator fluid level inspection at the reservoir tank

Check that reservoir tank fluid level is between "UPPER" & "LOWER" marks



##### Recommended Radiator Fluid:

Honda Standard Ultra Radiator Fluid or equivalent (ratio = 30%)

#### LIGHTING SYSTEM

##### Headlight

With motorcycle on level ground, adjust headlight by turning screw with a driver




## Stop Light

\* Do after adjusting brake pedal light

So that the stop light will shine when the brake pedal is pushed down 10mm, turn the adjuster while pushing the switch. After adjusting, check the brake pedal movement and light timing.

\* Front stop light switch cannot be adjusted



## Side Stand

Because of the weight of the frame and raising the bike using the side stand, the side stand may bend.

With 2.0-3.0Kg pressure, the stand will raise when pushing the rubber. If not, apply grease to the joint.

If worn or damaged, replace the rubber.




### Torque :

Side stand bolt : 1.0-2.0 Kg-m  
Side stand lock nut: 3.0-4.0 kg-m  
Side stand bracket : 2.4-3.0 kg-m

## RC VALVE CONTROL CABLE ADJUSTMENT

\* If the control cable connection is removed or the control cable is loose, then replace the control cable.

Remove R. lower fairing ( 15-3)  
Remove fuel tank ( 4-2)  
Remove control cable connection from cylinder pulley.  
Connect fuel tube to fuel cock and start engine.  
Slowly raise engine revolutions and check that at roughly 2000rpm the servo motor pulley protuberance stops at the "HI" mark position and stop the engine with the OFF switch.




Fully open the pulley on the cylinder side and fix there with the knock pin or something suitable

- \* Check that the pulley is okay when it is in the fixed position
- \* It is easier to perform if the knock pin (94303-06100) is used.

Connect control cable to the cylinder pulley  
Adjust the adjuster nut so that the pulley which pulls up cable has freeplay of under 0.5mm


- \* Always tighten the adjuster nut by hand

Start engine, and slowly increase revolution to around 2000rpm and check that the pulley moves clockwise to a stop, and increase the revolutions to around 3000rpm where it should move anti-clockwise to a stop




OIL LUBRICATION SYSTEM

---



# 3.

---



Lubrication Map .....	3 - 1	Oil Pump .....	3 - 3
Maintenance Points .....	3 - 2	Oil Pump Air Bleeding .....	3 - 4
Trouble Shooting .....	3 - 2	Oil Tank Removal .....	3 - 5

MAINTENANCE POINTS

Warnings:

- Conduct all maintenance with vehicle upright
- Take care that foreign particles do not enter engine or oil path tube when removing oil pump.
- Do not separate oil pump assembly
- Bleed air if air has entered oil tube (oil tank - oil pump) or when oil tube has been removed from oil pump
- Bleed path tube if oil path tube (oil pump - carburettor) has been removed

MAINTENANCE INFORMATION

Oil Tank Capacity	1.3ℓ
Recommended Engine Oil - Honda Ultra 2 super, or Honda Ultra GP2 or equivalent	

TROUBLE SHOOTING:

Lots of Exhaust Smoke, Carbon on Spark Plugs

- Oil pump not balanced
- Engine oil poor quality
- Oil pump solenoid faulty

Overheating

- Oil pump not balanced
- Engine oil quality poor
- Oil pump faulty

Engine Oil Does Not Come From Oil Tank

- Oil tank cap breather faulty
- Oil strainer screen clogged

Piston Seizure

- Engine oil cut, or oil strainer screen tube, clogged
- Oil pump not balanced
- Air leaking into oil tube
- Oil pump faulty
- Ignition plug failure



## OIL PUMP

### Removal

Remove R. Lower fairing ( 15-3)  
Remove fuel tank ( 4-2)  
Remove oil pump solenoid coupler (2P amp white) connection

\* Use tube clamp and stop oil flowing out from oil tube or oil tank

Pull oil tube from oil pump  
Remove oil pump control cable from oil pump control lever  
Remove the 2 oil path tubes from oil pump  
Remove bolt and oil pump assembly

\* Ensure foreign particles do not enter oil pump or tubes  
\* Insert plug into each oil path tube so that oil does not flow out  
\* Do not damage tube clip  
\* Check that each tubes oil pump assembly is installed




### Inspection

After removing the oil pump assembly inspect the following:


- O rings
- Oil pump drive shaft wear
- Oil pump body wear
- Oil pump control lever operation

\* Do not disassemble oil pump assembly

OIL PUMP SOLENOID COUPLER



OIL TUBE OIL PUMP CONTROL CABLE



O-RING DRIVE SHAFT

## INSTALLATION

Apply transmission oil to O ring and install oil pump

\* Ensure foreign particles do not enter oil pump or tubes

Fill oil path tube with engine oil  
Install oil path tube to oil pump

\* Do not forget to install the tube clip

Install oil pump control cable  
Connect oil tube

Connect oil pump solenoid coupler  
(2P mini white)

\* After installing, inspect the following and adjust if necessary:

- Control cable adjustment ( 2-14)
- Oil pump air bleeding
- Oil path tube air bleeding
- Oil leakages

Install fuel tank ( 4-2)  
Install R. Lower fairing ( 15-5)

### OIL PUMP AIR BLEEDING

If air enters the oil system trouble will be caused to the oil lubrication  
Perform air bleeding to the oil pump and oil tube - oil path tube


### OIL TUBE, OIL PUMP AIR BLEEDING

Remove R. Lower fairing ( 15-3)  
Loosen oil pump indicator bleeder bolt and drain oil and air from oil tube and oil pump



If all air is out, then reinstall bleeder bolt

\* When the oil tube is removed and oil cut and air enters the oil tube always bleed air from oil tube and oil pump

\* When bleeding air from oil tube and oil pump, always bleed air from oil path tube also



### OIL PUMP SOLENOID COUPLER



### OIL PATH TUBE AIR BLEEDING

\* When oil tube is removed and oil cut and air enters the oil tube always bleed air from the oil tube and oil pump

With a fuel ratio of 25-50:1, start engine With control lever in a fully open position allow engine to idle up to 10 seconds and push out oil from oil pump depending on if air is in oil path tube.

\* Do not perform when muffler is hot. Do where ventilation is good and where there are no hot items

\* Use recommended engine oil  
\* Do not rev engine quickly

### OIL TANK REMOVAL


Remove R. Lower fairing ( 15-3)  
Remove fuel tank ( 4-2)  
Drain engine oil from oil tank ( 2-13)  
Remove oil unit coupler (3P mini)

Remove oil tank 2 bolts. and oil tank  
Install in the reverse order to removal


\* Ensure no foreign particles enter tank or tubes

After installing bleed air from oil pump


CONTROL LEVER




UNIT COUPLER



BOLT



FUEL SYSTEM



# 4. FUEL SYSTEM

MAINTENANCE INFORMATION.....	4 - 1	CARBURETTOR .....	4 - 4
TROUBLE SHOOTING.....	4 - 1	REED VALVE .....	4 - 15
FUEL TANK .....	4 - 2	AIR SCREW ADJUSTMENT .....	4 - 16
AIR CLEANER CASE .....	4 - 3	CARBURETTOR SYNCHRONIZATION.....	4 - 16

## MAINTENANCE INFORMATION

### Warnings:

- When draining gasoline beware of naked flames
- Take care when installing o-rings and always use new ones
- Before separating loosen float chamber drain plug and drain fuel from carburettor

Venturi Bore	28mm
Setting Mark	TA10A
Float Level	13mm
Main Jet	≠ 110
Slow Jet	≠ 38
Jet Needle Mark	No. 1 2QY                      No. 2 2QZ
Idle Speed	1,200 ± 100rpm
Throttle Grip Play	2 - 6 mm
Air Screw Rotations	1-1/2回転

### TOOLS

Special Tools:	
Pilot screw wrench	07908-4220201
Standard Tools:	
Float level gauge	07401-0010000
Torque driver	07703-0010500

### No Power:

Fuel system clogged  
Float valve faulty

### Mixture Too Lean:

Fuel jets clogged  
Float valve faulty  
Float level too low  
Fuel tank breather tube clogged  
Fuel tube bent, split clogged  
Air vent tube clogged  
Air screw adjustment faulty

### Mixture Too Rich:

Choke lever still on  
Float valve movement faulty  
Float level too high  
Air jet clogged  
Air cleaner element dirty  
Air screw adjustment faulty

## TROUBLE SHOOTING

### Does Not Go:

No fuel in tank  
No fuel entering carburettor  
Too much fuel in engine  
Air cleaner clogged  
Choke movement faulty

### Movement Inhibited (Goes & Soon Stops)

Idle Not Balanced:  
Choke movement faulty  
Ignition/idle faulty  
Poor synchronization  
Carburettor faulty  
Dirty fuel  
Idle balance faulty

### Misfire/Backfire:

Ignition problems (section 17)  
Carburettor faulty

## FUEL TANK

### Removal




\* Be careful with heat & remove gasoline to avoid spillage

Remove seat ( 15-1)  
Remove breather tube from fuel tank, turn fuel cock off  
Remove side cover protuberance from fuel tank grommet & lift up tank  
Remove fuel tube from fuel cock  
Remove fuel tank mount cover from fuel tank and remove fuel tank

### Installation

Install in reverse order to removal



\* Check that fuel tank mount rubbers are pushed forward so that tank can be installed on frame  
\* Take care not to split or bend breather tube and fuel tube.



## AIR CLEANER CASE

### Removal


- Remove side cover ( 15-1)
- Remove fuel tank ( 4-2)
- Remove battery ( 16-3)
- Remove air cleaner case bolt
- Remove drain tube
- Loosen connecting tube band
- Remove air cleaner case



### Installation

Install in reverse order of removal

- \* Align connecting tube band protuberance with tube groove
- \* After checking that tube is not bent internally, install carburettor. If bent when installed engine performance will be affected
- \* Check that nothing has fallen into air cleaner case when installing air element




## CARBURETTOR

### Removal


Remove fuel tank ( 4-2)  
Remove air cleaner case ( 4-3)  
Remove lower fairing ( 15-3)  
Loosen drain plug and drain gasoline from carburettor

Remove intake chamber




Remove oil path tube from carburettor & insert a screw in path tube so that oil does not drain out

Remove choke cable




Loosen insulator band and raise carburettor up.  
Remove throttle cable and oil pump control cable from carburettor

\* After removing carburettor, place a cover or screw in reed valve so that rubbish cannot enter. Also take care that rubbish does not enter crankcase



CHOKE CABLE





Analysis

\* Float chamber, jets, throttle valve can be analysed without separating the carburettor. Only separate if necessary





Remove tube from carburettor

Turn the synchronizing bolt and align the No.2 carburettor throttle valve height with the No.1 carburettor throttle valve height

Loosen the bi-starter arms screw and remove the shaft and spring


Remove the rear bracket

AIR VENT TUBE




Remove front bracket

Remove throttle stop screw together with stay




While taking care that the spring does not fly out, separate the carburettor


\* Separate horizontally so as not to damage the fuel joint pipe



Remove screw and front chamber




Remove float arm, float, and float valve



Inspect valve seat area for damage. Inspect float valve seat for damage

Remove air screw

\* Before removing air screw, check position of it for safe revolutions  
\* Do not insert with force, as the seat facing is easily damaged




Remove main jet, needle jet holder, needle jet and slow jet

Clean each jet with cleaning solvent

Loosen bi-starter valve nut & remove spring and bi-starter valve.

Inspect bi-starter for wear and damage




Remove the 3 screws fastening the throttle valve cover (or 4 screws if the throttle stop screw has not been removed)


Remove the throttle tube together with the cover

Use the following special tool


Torque Driver 07703-0010500




\* Take care not to damage jet needles when removing it  
\* Do not do analysis of throttle valve if not totally necessary




Remove throttle valve from throttle link arm




Remove set plate, the pin, link and jet needle



Inspect jet needle and throttle valve for damage and wear



Remove nut, and spring washer and remove synchronizing arm and spacer  
Remove link arm set screw and spring washer, and remove throttle drum and return spring together.




NUT, SYNCHRON. ARM, SPACER, SPRING WASHES

Clean carburettor body with air gun



ASSEMBLY



Install throttle shaft return spring, throttle drum together with link arm as a set

Install link arm set screw and spring washer as a set  
Install spacer and synchronizing arm & install nut and spring washer as a set

Insert jet needle to the throttle valve  
Install link with the pin  
Align set plate with the plate and insert  
Align the jet needle head with the set plate hole and install

Install throttle valve into link arm

Install O ring into groove of throttle cover

While inserting jet needle into needle jet install into cover body





**\* Take good care not to damage jet needle**

Install the 3 screw (if No.1 carburettor stop screw has not been removed, 4 screws)


Insert special screw with tool

Torque Driver 07703-0010500

\* Install throttle valve cover while pushing body bottom




Install bi-starter valve together with spring and tighten nut



Install needle jet, needle jet holder, and main jet

Install slow jet


Install air screw



Air screw standard rotations :  $1\frac{1}{4}$  times

Install float valve, float and float arm pin

Inspect float valve movement




Measure float level height at main jet

Std float level = 13mm


Adjust float arm by bending

Float level gauge : 07401-0010000




If float chamber O ring is damaged, replace it.

Install float chamber and install three screws




If fuel joint O ring is damaged, replace it

Set fuel joint and thrust spring in carburettor and assemble carburettor




Install bi-starter arm, spring and shaft in carburettor

Set synchronizing spring




Install front bracket  
install throttle stop screw together with stay

insert screws.






Install rear barcket, aNS INSERT SCREWS




REAR BRACKET

Move throttle drum by hand, and inspect movement of throttle valve




Turning synchronizing adjuster bolt and align No.2 carburettor throttle valve height with No. 1 carburettor throttle valve



HEIGHT ADJUSTMENT LINE

Install tube

AIR VENT TUBE



DRAIN TUBE

FUEL TUBE

## INSTALLATION

Install the oil pump control cable and throttle cable into the carburettor





Install carburettor into insulator and tighten band

Connect oil path tube to carburettor  
Connect choke cable to carburettor

Check for foreign particles and abnormal conditions and install chamber to insulator

\* When installing intake chamber, ensure that it is position against the stopper and tighten band

Inspect throttle grip play ( 2-15)  
Adjust oil pump control cable ( 2-14)  
Install air cleaner case ( 4-3)  
Install fuel tank ( 4-2)  
Bleed oil pump ( 3-4)  
Adjust air screw ( 4-16)  
Adjust idling ( 2-12)  
Synchronize ( 4-16)  
Install lower fairing ( 15-5)



## REED VALVE

### Removal

Remove carburettor ( 14-4)  
Remove 8 reed valve bolts, and remove insulator, reed valve and gasket

\* after removing all parts, place cover over crankcase so that foreign particles do not enter

Inspect insulator valve guide for wear


Replace reed if worn

If reed valve seat is worn, cut or if there is clearance or gaps with the reed, then replace as an assembly


\* The reed stopper must not be bent at all, if bent engine will be affected  
\* Replace all items in a poor condition  
\* Do not separate reed valve

Install new gaskets and install reed valve

Install insulator and tighten 8 bolts




REED VALVE GUIDE



REED

STOPPER



## AIR SCREW ADJUSTMENT

\* Adjust once the engine is warm

Fully close air screw and then turn out standard number of turns

Standard number of turns :  $1-\frac{1}{2}$  revolutions

\* Take care not to turn into seat too tight as it will be easily damaged

Start engine, turn throttle stop screw to make engine idle

Idle speed :  $1200 \pm 100$  rpm

Lightly snap the throttle from idle and check if revolutions are smooth and increase is normal

Turn air screw  $\frac{1}{2}$  turn from standard position and if abnormal conduct another test ( 1-23)

## CARBURETTOR SYNCHRONIZATION

\* Synchronize carburettors once engine is warm

Remove lower fairing ( 15-3)  
Remove each plug from carburettor

Use vacuum gauge to adjust




Start engine and idle

Idle speed :  $1200 \pm 100$ rpm

Inspect each cylinder vacuum

Standard vacuum : UNDER 30mmHg

If vacuum is above standard valve then adjust



---


Balance each carburettor by turning  
synchronizing bolt

Special Tool:


Pilot Screw Wrench : 07908-4220201

\* No.1 carburettor becomes normal

After adjusting, snap throttle 2-3 times  
inspect and adjust idling ( 2-12)



COOLING SYSTEM



MAINTENANCE INFORMATION.....	5 - 1	THERMO SENSOR .....	5 - 6
TROUBLE SHOOTING.....	5 - 1	RADIATOR .....	5 - 6
INSPECTIONS .....	5 - 3	WATERPUMP .....	5 - 7
RADIATOR FLUID REPLACEMENT.....	5 - 4	RESERVOIR TANK .....	5 - 9
THERMOSTAT .....	5 - 5		

MAINTENANCE INFORMATION:

Warning: If you think the radiator fluid temperature may be over 100°C do not open radiator cap as this will cause rapid outflow of pressure

- Adjust cooling system when it is cold
- All maintenance to cooling system can be performed with the vehicle upright
- Refill radiator at reserve tank
- After inspecting and adjusting use a radiator cap tester and inspect each connection and seal for leakage

Torques:

Water Pump Impellar : 1.0-1.4 kg-m

Maintenance Standards

Item	Std	Service Limit
Radiator cap pressure	1.1-1.4kg/cm <sup>2</sup>	
Thermostat	Opening	63-67°C
	Ttl Open	80°C
	Ttl Open Lift	8mm以上
Coolant Capacity	Total roughly 1.310cc	Radiator 1,060cc Reserve tank 250cc

TOOLS:

Special:

Bearing remover set (10mm) 07936-GE00000  
 Mechanical seal driver attachment 07945-4150400

Standard:

Outer driver (24x26mm) 07746-0010700  
 Pilot (10mm) 07746-0040100  
 Driver handle A 07749-0010000

Water Leakage:

Mechanical seal faulty  
 Water hose worn, split  
 O-rings, gaskets seals faulty

TROUBLE SHOOTING

Temperature Does Not Rise, or Rises Poorly:

Water Temperature Too High:

Temperature gauge or thermostat faulty

- Temperature gauge or thermo sensor fault
- Radiator cap faulty
- Radiator fluid faulty
- Water hose or jacket clogged
- Fins bent
- Radiator clogged
- Water pump faulty

RADIATOR FLUID DENSITY

Temp °C	0	5	10	15	20	25	30	35	40	45	50
5	1.009	1.009	1.008	1.008	1.007	1.006	1.005	1.003	1.001	0.999	0.997
10	1.018	1.017	1.017	1.016	1.015	1.014	1.013	1.011	1.009	1.007	1.005
15	1.028	1.027	1.026	1.025	1.024	1.022	1.020	1.018	1.016	1.014	1.012
20	1.036	1.035	1.034	1.033	1.031	1.029	1.027	1.025	1.023	1.021	1.019
25	1.045	1.044	1.043	1.042	1.040	1.038	1.036	1.034	1.031	1.028	1.025
<b>30</b>	<b>1.053</b>	<b>1.052</b>	<b>1.051</b>	<b>1.049</b>	<b>1.047</b>	<b>1.045</b>	<b>1.043</b>	<b>1.041</b>	<b>1.038</b>	<b>1.035</b>	<b>1.032</b>
35	1.063	1.062	1.060	1.058	1.056	1.054	1.052	1.049	1.046	1.043	1.040
40	1.072	1.070	1.068	1.066	1.064	1.062	1.059	1.056	1.053	1.050	1.047
45	1.080	1.078	1.076	1.074	1.072	1.069	1.066	1.063	1.060	1.057	1.054
50	1.086	1.084	1.082	1.080	1.077	1.074	1.071	1.068	1.065	1.062	1.059
55	1.095	1.093	1.091	1.088	1.085	1.082	1.079	1.076	1.073	1.070	1.067
60	1.100	1.098	1.095	1.092	1.089	1.086	1.083	1.080	1.077	1.074	1.071

RADIATOR MIXTURE

Lowest Temp	Ratio	Honda Ultra Rad Fluid	Water
-9°C	20%	262cc	1.048cc
-16°C	30%	393cc	917cc
-25°C	40%	524cc	786cc
-37°C	50%	655cc	655cc
-44.5°C	55%	720.5cc	589.5cc




LEVEL INDICATOR

INSPECTION

Radiator Fluid Level

Use a level gauge and measure radiator fluid level  
Inspect for leakage



Radiator Cap Inspection

Remove R. lower fairing ( 15-3)  
Remove fairing stay  
Remove oil tank bolts and put in a position where the radiator cap can be removed and fix to frame

Remove radiator cap




\* Check that radiator fluid has cooled sufficiently before removing radiator cap

Use radiator cap tester and check cap quality

If radiator cap relief pressure holds for around 6 seconds it is okay

Radiator Cap relief Pressure: 1.1-1.4kg/cm<sup>2</sup>

\* So that the tester can be installed to the cap apply water to the cap seal



## RADIATOR PRESSURE INCREASE TESTS


Remove radiator cap

\* Check that the radiator has cooled before removing cap

Apply specified pressure to radiator cap & check that it holds pressure for 6 seconds


Standard pressure : 1.1-1.4 Kg/cm<sup>2</sup>

\* Do not increase pressure above specified pressure. If too much pressure is applied damage can be caused to the radiator and connections



TESTER

If there is pressure leakage, check for leaks in hoses, each connection and water pump lower section



DRAIN BOLT

DRAIN PLUG

## RADIATOR FLUID REPLACEMENT

Remove radiator cap ( 5-3)


Remove lower fairing ( 15-3)

Remove water pump drain bolt, No.1 cyl head drain bolt and drain fluid for radiator

Remove each cylinders drain bolt and drain remaining radiator fluid

Finally move bike left & right to drain total radiator fluid. After draining install sealing washer into drain plug and drain bolt and tighten plug and bolt sufficiently

\* Do not forget to install sealing washers



DRAIN BOLT

Fill radiator fluid into filler hole

Place transmission in neutral & start engine  
Once engine is warm snap throttle 3-4 times between 4000-5000rpm

Finally fill radiator fluid to level mark

Install radiator cap

Inspect reservoir tank fluid level and if insufficient fill to "UPPER" level

Install oil tank

Install lower fairing ( 15-3)



FILLER MARK

## THERMOSTAT

### Removal

- Remove fuel tank ( 4-2)
- Remove coupler holder from under fuel tank ( 17-3)
- Drain radiator fluid ( 3-4)
- Remove two bolts

Raise thermostat cover upward and remove thermostat

### Inspection

Put thermostat inot tester container, raise water temperature and test opening relief temperature




### Thermostat:

- |                       |           |
|-----------------------|-----------|
| Opening temperature   | 63-67°C   |
| Full open temperature | 80°C      |
| Full open lift        | above 8mm |

- \* Do not let thermostat touch container
- \* Do not place thermostat & thermometer near edge of container
- \* Replace thermostat if it opens even just a little above the standard temperature
- \* Measure opening lift for roughly 5 minutes after it has held 80°C

Insert thermostat into thermostat case and reassemble

- Assemble seal rubber into thermostat case
- Install thermostat cover and tighten bolts
- Install radiator fluid ( 15-4)
- Install coupler holder ( 17-3)
- Install fule tank ( 4-2)



## THERMOSENSOR

### Removal

Drain radiator fluid ( 5-4)  
Remove thermostat wire connector from  
thermosensor  
Remove thermosensor from thermostat case

### Inspection

Insert thermostat unit into test container,  
raise water temperature gradually, and  
measure thermosensor resistance change

### Thermosensor Unit:

Temperature (°C)	60	118	122
Resistance (ohms)	90-120	16-19	14-18

### Installation

Install thermosensor

Torque : 1.2-1.8Kg-m

\* Apply sealing agent to thermostat when  
installing it.





Connect thermosensor wire connector  
Insert radiator fluid ( 5-4)

## RADIATOR

### Radiator, Hose Inspection

Inspect radiator core and fins for clogging  
If fins are bent use a screwdriver and adjust

Inspect hose pipe and plug for damage and  
splitting



## Removal

\* Perform when engine is cold

Remove lower fairing  
Drain radiator ( 5-4)  
Remove radiator hose from radiator

Remove radiator lower mount stay from cylinder head  
Remove radiator upper bolt, and remove radiator from frame

## Installation

Install in reverse order of removal  
Insert radiator fluid ( 5-4), after this conduct increasing pressure test on radiator to check for leakages from each ( 5-4)




## WATER PUMP

### Mechanical Seal Inspection

Remove R Lower fairing ( 15-3)  
Inspect radiator for leakages from the inspection hole in the lower part of the water pump. If any leakages, replace mechanical seal as it will be worn.


### Water Pump Removal

Drain radiator fluid ( 5-4)  
Remove radiator hose from water pump cover  
Remove bolt, and remove water pump cover and gasket.



Remove impellor and washer

Inspect impellor for wear



IMPELLAR WASHER


### Mechanical Seal Replacement

Remove R crankcase cover ( 8-3)

Remove water pump shaft bearing

Special Tool:

Bearing removal set (10mm) 07936-GE00000



BEARING

BEARING REMOVER SET

Remove mechanical seal

Insert new mechanical seal

Special Tool:

Mechanical seal driver attachment

07945-4150400

Standard Tool:

Driver handle A 07749-0010000

Insert new bearing

Standard tools:

Outer driver (24x26mm)


07746-0010700

Pilot (12mm)


07746-0040100

Driver handle A

07749-0010000



MECHANICAL SEAL



DRIVER HANDLE A

MECHANICAL SEAL

DRIVER ATTACHMENT

OUTER DRIVER PIPE

---

## WATER PUMP INSTALLATION

Inspect water pump shaft, gears for damage



Install R. crankcase cover ( 8-15)

Install washer into shaft and install impellor into shaft

Torque: 1.0-1.4 Kg-m

Install new gasket into water pump cover and install R crankcase cover


Tighten bolt  
Insert radiator fluid ( 5-4)



## RESERVOIR TANK


Removal

Remove lower fairing ( 15-3)  
Remove overflow tube and drain tube from reservoir tank.  
Remove 2 bolts and remove reservoir tank




installation

Install in reverse order to removal



# ENGINE REMOVAL





# 6. ENGINE REMOVAL

MAINTENANCE INFORMATION .....	6 - 1	ENGINE INSTALLATION .....	6 - 3
ENGINE REMOVAL .....	6 - 2		

## MAINTENANCE INFORMATION:

### Warnings:

- When removing engine ensure motorcycle is upright and take care not to damage frame engine, cables and harnesses. Raise engine using a jack
- When removing engine put tape on frame where the engine may mark it.
- Perform the following maintenance:
  - Clutch, gearshift linkage, kickstarter ( section 8)
  - Cylinder head, cylinder, piston (Section 7)
  - Oil pump (section 3)
  - Crankshaft, conrod (section 11)
  - AC Generator (section 10)
  - Water pump (section 5)
  - Carburettor (section 4)
  - Transmission (shift drum, shift fork, fork shaft (section 9)

**6**

### Remove the following

- Crankcase (section 11)

Engine weight		30.5kg
Transmission oil capacity (disassembled)		0.9ℓ
Coolant Capacity	Radiator engine	1,060cc
	Reserve Tank	250cc
Recommended engine oil		see section 3 - 2
Recommended transmission oil		see section 2 - 8
Recommended radiator fluid		see sections - 2 ( recommended ratio 30%)

### TORQUES:

Engine hanger bolt 8 mm	2.4-3.0kg-m
Exhaust chamber pinch bolt 10mm	4.5-5.5kg-m
Shift change pedal	2.4-3.0kg-m
Silencer pinch bolt	1.0-1.4kg-m
	2.4-3.0kg-m

## ENGINE REMOVAL

Place vehicle on flat ground and raise frame

Remove the following parts:



- seat, side covers, lower fairing (section 15)
- Fuel tank ( 4-2)
- battery ( 16-3)

Drain transmission oil ( 2-9)

Drain radiator fluid ( 5-4)

Remove the following parts:-

- air cleaner case
- carburettor ( 4-4)
- radiator
- cylinder head water hose ( 7-3)
- RC valve control cable ( 19-3)
- oil tube
- exhaust chamber/silencer
- spark plug cap
- radiator fluid reservoir tank
- AC generator wire coupler
- Pulse generator wire coupler
- L.crankcase cover
- drive sprocket
- change pedal
- clutch cable



Raise engine with a jack

Remove engine hanger bolt, hanger plate and remove engine from frame

#### ENGINE INSTALLATION

- \* Take care not to damage harness and cables
- \* Take care not to damage each part on frame bolts and threads.
- \* Do not forget to install collars
- \* Place harness and cable in the correct positions.

While raising engine with a jack set it in the frame

Install upper hanger bolts and plate bolts

Torques:

Hanger bolt (10mm)	4.5-5.5 kg-m
Plate bolt (8mm)	2.4-3.0 kg-m




Install lower hanger bolts and plate bolts

Torques:

Hanger bolt (10mm)	4.5-5.5 kg-m
Plate bolt (8mm)	2.4-3.0 kg-m

Check that collars have been installed and tighten front hanger bolt

Torque: 4.5-5.5 kg-m




Install drive sprocket

Install fixing plate and lock plate and tighten bolts  
Line up lock plate hole and turn bolt till it stops


Align change pedal pinch mark and shift spindle pinch mark and install change pedal

Torque: 1.0-1.4 kg-m

Connect clutch cable lifter arm




Connect AC generator wire coupler and pulse generator wire coupler




Connect RC valve control cable as in the diagram

Connect RC valve control cable, cylinder head water hose and spark plug cap to the front cylinder



\* Align hoses white mark and cylinder head alignment mark and install hose.



Connect RC valve control cable, cylinder head water hose, radiator bypass tube and spark plug cap to rear cylinder

Install the following parts:

- L. crankcase cover
- radiator reserve tank
- exhaust chamber
- radiator
- oil tube
- carburettor ( 4-14)

\* Install wiring and harness correctly  
( 1-23)

Insert radiator fluid ( 5-4)  
Insert transmission oil ( 2-9)




Perform the following inspections/  
maintenance

- throttle grip play ( 2-15)
- clutch lever play ( 2-7)
- drive chain ( 2-9)
- oil pump control cable ( 2-14)

Install the following parts:

- air cleaner case
- battery ( 16-3)
- fuel tank ( 4-2)

Bleed transmission system ( 3-4)  
Adjust RC valve control cable ( 2-17)  
Install lower fairing, side covers, seat  
(section 15)



# 7. CYLINDER HEAD, CYLINDER PISTON, R.C. VALVE

MAINTENANCE INFORMATION.....	7 - 1	CYLINDER, PISTON SELECTION	7 - 8
TROUBLE SHOOTING .....	7 - 2	RC VALVE .....	7 - 9
CYLINDER HEAD REMOVAL .....	7 - 3	CYLINDER, PISTON INSTALLATION .....	7 - 10
CYLINDER, PISTON REMOVAL .....	7 - 4	CYLINDER HEAD INSTALLATION.....	7 - 13

## MAINTENANCE INFORMATION

### Warnings:


- It is not necessary to remove engine when maintaining frame. Perform all maintenance with the vehicle in an upright position
- Before maintenance, clean engine so that foreign materials cannot enter
- When removing cylinder and cylinder head do not use screwdrivers or other object which will damage the index mark
- Do not damage cylinder wall or piston facing
- Before inspecting parts which have been removed wash them and when reinstalling apply engine oil to moving parts
- Always replace cylinder head gasket with a new one once removed. If reused leakage and poor performance will result
- Cylinder and piston selection is related. When replacing cylinder or piston always install the part with the corresponding mark

Item	Standard	Service Limit	
Cylinder I.D	Mark : A	54.010-54.015	54.085
	Mark : B	54.005-54.010	54.080
	Mark : C	54.000-54.005	54.075
		-----	0.05
		-----	0.05
Piston O.D (15mm from skirt)	Mark : B	53.971-53.975	53.940
	Mark : C	53.966-53.970	53.935
	Mark : D	53.961-53.965	53.930
Cylinder-to-piston clearance	0.035-0.044	0.08	
Piston pin hole I.D	15.002-15.008	15.03	
Piston pin O.D	14.994-15.000	14.98	
Piston-to-pin clearance	0.002-0.014	0.04	
Piston ring clearance	Top	0.23-0.38	0.43
	Second	0.23-0.38	0.43
Cylinder head warpage	-----	0.10	
Upper cylinder warpage	-----	0.02	
Ring groove to ring clearance	Second	0.065-0.095	0.12
Cylinder compression		12 ± 2 kg/cm <sup>2</sup>	-----

### TORQUES:

Cylinder head nut	1.2-1.6kg-m
Cylinder nut	2.3-2.7kg-m
RC Valve shaft	0.8-1.0kg-m
Cylinder head bypass tube joint	0.25-0.45kg-m

# CYLINDER HEAD, CYLINDER, PISTON, RC VALVE



---

TROUBLE SHOOTING:

Low Compression, Poor Response  
At Low Revs:

- Cylinder head gasket faulty
- Spark plug installation faulty
- = Piston rings damaged, sticking or worn
- Cylinder piston damaged or worn

High compression, Overheating,  
Knocking:

- Carbon deposits on cylinder head  
or pistons

Piston Noise:

- Cylinder, piston damaged
- Piston pin bore or piston pin damaged
- Conrod small end bearing damaged



## CYLINDER HEAD REMOVAL

Remove seat, side covers, lower fairing (section 15)

Drain radiator ( 5-4)

### Rear Cylinder Head Removal


Remove fuel tank & air cleaner case (sect. 4)

Remove coupler holder & CDI unit ( 17-3)

Remove spark plug cap, bipass tube, water hose from cylinder head and spark plug

Remove spark plug

Remove cylinder head nut & remove cylinder head and gasket



### Front Cylinder Head removal


Remove radiator ( 5-7)

remove cylinder head water hose and spark plug cap from cylinder head and spark plug.

Remove spark plug




Remove cylinder head nut and remove cylinder head and gasket



## CYLINDER HEAD INSTALLATION

Clean fuel system of carbon and other deposits

\* Do not damage fuel system and cylinder index mark




Inspect spark plug bore and around stud bolt hole.  
Inspect cylinder head warpage using a straight edge and thickness gauge

Service Limit: 0.05mm


## CYLINDER, PISTON REMOVAL

Remove cylinder head ( 7-3)  
Remove exhaust chamber ( 15-7)



## Rear Cylinder Removal

Remove thermostat case



Remove cylinder water hose & RC valve control cable


Remove control cable pulley

\* Take care as nut is left hand thread

Remove cylinder nut, cylinder, gasket and knock pin

\* Take care not to damage cylinder index mark

\* Take care not to drop knock pin



### Front Cylinder Removal

Remove cylinder water hose & RC valve control cable

Remove control cable pulley

\* Take care as nut is left hand thread

Remove cylinder nut, cylinder, gasket and knock pin

\* Take care not to damage cylinder index mark

\* Take care not to frop knock pin

### Piston Removal

Remove piston pin clip, pull out piston pin and remove piston





Remove conrod small end bore needle bearing from conrod

\* Take care not to damage piston  
\* When pulling out piston pin do not change composition in conrod  
\* take care that clip does not fall into crankcase

### Piston Ring Removal

Open piston ring gap and remove from opposite side of gap


Remove expander



## CYLINDER INSPECTION

Clean exhaust port of carbon deposits

\* When removing carbon deposits from cylinder and exhaust port entrance, be careful not to cause damage




Inspect cylinder upper face warpage with a straight edge and thickness gauge

Service Limit: 0.05mm

inspect cylinder and piston for damage & wear

Measure the internal diameter at right angles to the piston pin direction (X-Y) at top, middle and lower 6 points  
Each measurements largest value is the cylinder I.D. valve




Service limit: Mark A 54.085mm] Replace  
Mark B 54.080mm] - if  
Mark C 54.075mm] above

Check the cylinder-to -piston clearance  
Identify the largest clearance

Service limit: 0.08mm (replace if above)

Measure the piston O.D. ( 7.7)




After measuring each valve calculate the circular and cylindrical diameters, and obtain the largest degree of difference at each point (X,Y) at top, middle and bottom

Circular: 0.05mm (replace if above)  
Cylindrical: 0.05mm (replace if above)

\* When replacing cylinder, always select the matching piston and assemble

Cylinder replace warning: Relating to marks ( 7-8)



## PISTON INSPECTION

Remove all foreign deposits off piston  
Inspect for piston damage, cracks, ring  
groove damage, carbon deposits

Measure piston O.D.

\* Measure 15mm from bottom of skirt at the  
piston pin hole

Service limit:	Mark B	53.940mm	Replace
	No Mark	53.935mm	if
	Mark O	53.930mm	below

\* For the purpose of assembling the piston  
with the same cylinder mark (the piston with  
no mark is assembled with the cylinder mark  
C) decide using the cylinder mark

Measure the piston pin bore I.D.

Service limit: 15.03mm (replace if above)

\* When replacing pistons always select using  
the matching cylinder and assemble

Piston Replacment Warning: Relating to marks  
( 7.8)



## PISTON RING INSPECTION

Inspect the piston ring to ring groove  
clearance


Service limit: 0.12mm (replace if above)  
(second ring)

Measure the piston ring gap clearance

Service limit: 0.43mm (replace if above)  
(top, second ring)



Install top, second rings and expander to piston.  
 Push piston rings into place and check that the piston circumference and piston rings are inserted at the same height. If it does not insert correctly the rings may be damaged or carbon may be deposited on piston rings



**PISTON PIN INSPECTION**

Measure piston pin O.D

Service limit: 14.98mm (replace if under)

Check piston-to-piston pin clearance


Service limit: 0.04mm (replace if above)

If above service limit value replace with new piston pin  
 If within service limit replace piston and piston pin



**CONROD SMALL END INSPECTION**

Install conrod small end needle bearing end piston pin in conrod small end, and inspect condition. Replace if movement in



**CYLINDER PISTON SELECTION**

If cylinder or piston exceed service limit then replace pistons that correspond to cylinder must be installed  
 Select as per the following method:

**Piston Selection**

Write down piston mark

- \* The mark is on top of piston
- \* In order that the piston selected corresponds with same cylinder mark, decide using the mark on the cylinder

When replacing piston, select piston with the same mark




**CYLINDER SELECTION**

Write down cylinder mark

\* The mark is under cylinder (carburettor side) and on exhaust top side

When replacing cylinder select cylinder with the same mark




**CYLINDER AND PISTON SELECTION**

When replacing cylinder and piston at same time, always choose cylinder and piston with corresponding marks

X = do not select      O = Select


		CYLINDER		
		Mark A	Mark B	Mark C
P	Mark B	O	X	X
I	No MARK	X	O	X
S				
T	Mark D	X	X	O
O				
N				



**RC VALVE**

removal


Remove bolt and remove cable guide base  
Remove RC valve shaft, dust seal and take out RC valve



Inspection

Clean carbon from RC valve and shaft  
Inspect RC valve and shaft for wear  
Install RC valve together with collar into shaft, and replace if it moves greater/less than 1mm at valve pointed end

Replace with new dust seal



## Installation

Set RC valve into cylinder

\* Beware of installation direction

Align shaft wide shoulder with valve wide gap, and install with collar

Install new dust seal

\* Take care with "F" and "R" marks "F" mark is for front cylinder. "R" marks is for rear cylinder

\* The pinch bolts are specially for the guide base, so use special bolts

## CYLINDER, PISTON INSTALLATION

### Piston Ring Installation

Install piston rings into piston

\* Always install piston ring "N" and "R" mark facing upwards

\* The respective top, second rings are special to the piston.

\* When replacing piston rings, replace with the same makers parts as a set.

### Piston Installation

Apply recommended engine oil to conrod small end bearing and piston, then install





put piston pin in piston and install

\* Always face "IN" mark to the intake side

Install new piston pin clip

\* When installing rear cylinder piston, ensure clip does not fall inside crank

\* Do not align clip gap with piston should






Install cylinder gasket, knock pin

\* Use new cylinder gasket


Align piston ring gap with piston ring stopper arm



### FRONT CYLINDER INSTALLATION

Apply recommended engine oil to piston and piston rings and while pushing piston rings inward push into cylinder


\* Take care not to get piston rings stuck in cylinder  
\* Do not install in cylinder if piston rings are riding on piston ring stopper



Install cylinder nut

Torque: 2.3-2.7 Kg-m

\* Turn nut 2-3 times, and tighten in the opposite angle




Install cable pulley spacer into RC valve shaft and tighten nut together with washer


Torque: 0.8-1.0 Kg-m

\* Align cable pulley with RC valve shafts flat surface and install

\* Beware nut is left hand thread



Connect control cable  
Connect cylinder water hose




#### Rear Cylinder Installation

install rear cylinder in same way as front cylinder ( 7.11)


Tighten cylinder nut  
Torque: 2.3-2.7 Kg-m

Install cable pulley and spacer into RC valve shaft and tighten nut and washer together

Torque: 0.8-1.0 Kg-m




\* Align cable PULLEY AND RC valve shaft flat surface and install



\* Take care nut is left hand thread

Connect control cable  
Connect water hose  
install exhaust chamber ( 15.7)  
Install thermostat case



## CYLINDER HEAD INSTALLATION

### Front Cylinder head Installation

Install new gasket in cylinder

\* Face "EX UP" mark upwards and install with protuberance on intake side

Install cylinder head and tighten nut

Torque: 1.2-1.6 Kg-m

\* Tighten nuts opposite to each other 2-3 times each time

Install cylinder head water hose into cylinder head and install clamp

\* Align hose white mark with cylinder head index mark and tighten bolt.

Install spark plug

Torque: 1.5-2.0 Kg-m

Connect plug cap to plug





Install radiator ( 5.7)

Insert radiator fluid which was drained when radiator was removed ( 5.4)

### Rear Cylinder Head Installation

Install new gasket in cylinder

\* Face "EX UP" mark upwards and install with protuberance on intake side



Install cylinder head and tighten nut

Torque: 1.2-1.6 Kg-m

\* Tighten nuts opposite to each other  
2-3 turns each time

Install cylinder head water hose into  
cylinder head and tighten clamp

Install spark plug

Torque: 1.5-2.0 Kg-m

Install spark plug cap

Connect bipass tube


Install coupler holder and CDI unit  
( 17-3)

Install air cleaner case and fuel  
tank (section 4)


Insert radiator fluid which was drained  
when radiator was removed ( 5.4)

ADjust RC valve control cable ( 2.17)

Install lowerfairing, side covers and  
seat ( section 15)



# CLUTCH, KICKSTARTER, GEAR SHIFT LINKAGE



# 8. CLUTCH, KICKSTARTER, GEAR SHIFT LINKAGE

MAINTENANCE INFORMATION.....	8 - 1	GEAR SHIFT LINKAGE .....	8 - 8
TROUBLE SHOOTING .....	8 - 2	KICKSTARTER INSTALLATION .....	8 - 11
R. CRANKCASE COVER REMOVAL .....	8 - 3	PRIMARY DRIVE GEAR INSTALLATION .....	8 - 13
CLUTCH REMOVAL .....	8 - 3	CLUTCH INSTALLATION .....	8 - 13
PRIMARY DRIVE GEAR REMOVAL .....	8 - 6	R. CRANKCASE COVER .....	8 - 15
KICKSTARTER REMOVAL .....	8 - 7		

## MAINTENANCE INFORMATION:

### Warnings:

- Perform all adjustments with vehicle on level ground
- When removing primary drive gear, always use special/standard tools
- Clean cases when installing gaskets
- Ensure foreign particles do not enter engine
- When separating case take care not to damage index mark

: mm

Item	Standard	Service Limit	
Clutch spring freeplay	38.9	38.0	
Clutch disc thickness	2.92-3.08	2.5	
Clutch plate warpage	—	0.2	
Clutch outer guide I.D	22.011-22.031	22.03	
Main shaft O.D (clutch outer guide)	21.980-21.999	21.94	
Kickstarter	Kickstarter spindle O.D	19.959-19.980	19.92
	Kickstarter pinion gear I.D	20.020-20.041	20.10
	Kickstarter idle gear I.D	20.020-20.041	20.10
	Countershaft O.D	19.980-19.993	19.97

### TORQUES:

Clutch centre locknut	5.5-6.5kg-m	Kickstarter pedal	3.5-4.5kg-m
Primary drive gear bolt	9.0-10.0kg-m		
Shifter pin	2.1-2.5kg-m	Clutch lifter arm	0.8-1.2kg-m
(apply locking agent)		stopper bolt	1.0-1.4kg-m
		Shift change pedal	

### TOOLS:

Special tools		Standard tools	
Gear holder	07HMB-KV30100	Clutch centre holder	07724-0050000

---

TROUBLE SHOOTING:

Clutch Slip When Accelerating

- Not enough play
- Damage to clutch discs
- Clutch springs bent

Clutch Movement Not Balanced

- Clutch outer groove damaged
- Transmission oil leakage
- Recommended transmission oil not used

Clutch Will Not Engage, Clutch Engaged But Still Moves

- Too much play
- Clutch plate warped, bent

Lever Movement Too Heavy

- Clutch cable damaged or clogged
- Lifter damaged
- Cable not routed correctly
- Clutch lubrication faulty

Gears Difficult To Engage

- Clutch cable adjusted poorly
- Shift fork bent, damaged
- Shift drum cam groove damaged
- Shift spindle slot clogged

Gears Jump Out


- Gear docks damaged
- Shift shaft bent
- Stopper arm damaged
- Shift fork bent, damaged

## REAR CRANKCASE COVER

### Removal

Remove R. lower fairing (section 15)  
Drain transmission oil ( 2.9)  
Drain radiator ( 5.4)  
Remove bolt and remove kick pedal  
Remove water joint bolt

Remove 12 bolts and remove R. crankcase cover  
Remove gasket and knock pin



## CLUTCH REMOVAL

Remove R crankcase cover  
Remove 5 bolts and remove pressure plate and clutch springs

\* Loosen opposite bolts on pressure plate little by little

Remove clutch lifter guide, lifter guide inner steel ball and clutch lifter rod.

\* Hold clutch lever and move lifter rod a little to remove




Remove: clutch discs, clutch plates

Steady clutch with clutch centre holder and remove clutch centre lock nut

Standard tool:


Clutch centre holder 07724-0050000

Remove washer





Remove clutch centre, thrust washer, clutch outer, needle bearing and outer guide from main shaft



### Clutch Spring Inspection

Measure spring freeplay

Service limit: 38.0mm

(replace if below)




### Clutch Disc Inspection

Replace clutch discs if damaged or different colour

Measure clutch disc thickness


Service limit: 2.5mm (replace if below)



### Clutch Plate Inspection


Measure plate thickness using a thickness gauge.

Service limit: 0.2mm (replace if above)



### Spring Seat, Judder Spring Inspection


Inspect spring seat and judder spring for change in shape, warpage, damage and wear



### Clutch Lifter Guide, Steel Ball, Clutch Lifter Inspection

Inspect clutch lifter guide, steel ball damage


Inspect clutch lifter rod for bends



### Clutch Outer Inspection

Inspect clutch outer bearing condition  
Replace if in poor condition  
Inspect clutch outer groove for damage and wear due to discs  
Measure clutch outer guide I.D


Service limit: 22.03mm



### Main shaft Inspection

Measure main shaft O.D

Service limit: 21.94mm  
(replace if below)





## CLUTCH LIFTER ARM

### Removal

Remove L. crankcase cover ( 10.2)  
Remove exhaust chamber ( 15.7)  
Remove clutch cable from lifter arm  
Remove clutch lifter arm stopper bolt,  
pull lifter arm down and remove

\* When removing lifter arm it is necessary to remove clutch lifter rod ( 8.3)



### Clutch Lifter Arm Inspection

Inspect the following:

- lifter arm bent, damaged
- Spindle bent, damaged
- Return spring bent
- Spindle lifter rod connection damaged

## PRIMARY DRIVE GEAR

### Removal

Remove R crankcase cover ( 8.3)  
Remove clutch ( 8.3)  
Install 2 6mm bolts of gear holder as in the picture.


### Special Tools:

Gear Holder O7HMB-KV30100


Remove primary drive gear bolt, washers

Remove primary drive gear

\* Take care as bolts are left hand thread



### PRIMARY DRIVE GEAR




### PRIMARY DRIVE GEAR INSPECTION

Inspect primary drive gear for damage and wear

KICKSTARTER REMOVAL

Kickstarter Idle Gear Removal



Remove R.crankcase cover ( 8.3)  
 Remove clutch ( 8.3)  
 Remove snap ring and thrust washer and  
 take out counter shaft idle gear and thrust  
 washer



KICKSTARTER SPINDLE REMOVAL

\* When adjusting kickstarter spindle, it is not necessary to remove clutch and kickstarter idle gear

Remove kick return spring from R crankcase  
 Remove kickstarter spindle from R.crankcase  
 as a set.  
 Separate kickstarter spindle




### KICKSTARTER INPSECTION

Measure kickstarter spindle O.D.

Service limit: 19.92mm (replace if below)

Measure kickstarter pinion gear I.D

Service limit: 20.10mm (replace if above)




### KICKSTARTER IDLE GEAR INSPECTION

Measure kickstarter idle gear I.D

Service limit: 20.10mm (replace if above)

Measure countershaft O.D


Service limit: 19.97mm (replace if below)



### GEAR SHIFT LINKAGE


Removal

Remove 2 bolts and remove gear shift linkage cover



Remove shift change pedal from shift spindle  
Pull shift spindle assy out of crankcase.

\* Take care not to drop thrust washer



Remove 2 guide plate mount bolts and remove the assembled guide plate and drum shifter. Push the 2 ratchet pawls in the drum shifter so that they do not fall out and separate the guide plate and drum shifter.

\* Take care not to drop ratchet pawls and springs

Remove shifter pin shift drum

Remove shift drum centre and roller pin from shift drum

\* Only remove shifter pin if adjusting shift drum centre





Remove bolts and remove drum stopper arm, thrust washer and stopper arm spring

Remove the thrust washer from the assemblies shift spindle. Remove circlip from spindle and remove shift retain spring.

#### GEARSHIFT LINKAGE INSPECTION

Inspect the following


- Shift drum centre and pin wear/damage
- Stopper arm spring warpage
- Drum shifter wear/damage
- Ratchet pawl wear/damage
- Ratchet spring warpage
- Pawl plunger wear/damage
- Shift spindle and drum shifter pin wear/damage
- Shift retain spring warpage
- Shift spindle warpage, damage



### Installation

Use drum stopper arm bolt and install stopper arm spring, thrust washer and drum stopper arm


\* Do not forget to install thrust washer



Fix drum stopper arm with a driver as in the picture to the right


Push roller pin into shift drum

Align shift drum centre groove with shift drum roller pin and install




Apply locking agent to new shifter pin and install

Torque: 2.1-2.5 Kg-m



Assemble ratchet spring, pawl flange and ratchet pawl into drum shifter

\* Check that the transmission gear is in neutral according to the position of the shift drum centre




Push drum shifter ratchet pawl and assemble guide plate

\* Take care not to drop ratchet pawl, ratchet spring and pawl flange

Once drum shifter and guide plate are assembled, assemble in drum centre

Install 2 bolts into guide plate



Install shifter collar

Install gear shift spindle and thrust washer


\* After assembling turn gear shift spindle and check linkage operation

Align shift change pedal and spindle punch mark and install pedal

Tighten bolts

Torque: 1.0-1.4 kg-m



Install 2 bolts into gear shift linkage cover



#### KICKSTARTER INSTALLATION

Apply molybdenum grease to pinion gear  
Install each part into kickstarter spindle by hand


\* Check that circlip is situated fully in groove  
\* Do not forget to install thrust washer  
\* Align collar shoulder with return spring and install






Place spindle punch mark and ratchet punch mark horizontally up, push ratchet into spindle and assemble

Install spring




Install kickstarter pin such that the return spring and the R. crankcase groove meet




#### KICKSTARTER IDLE GEAR INSTALLATION

Install thrust washer into countershaft



Apply molybdenum grease to idle gear  
Install idle gear, thrust washer and snap ring into countershaft



## PRIMARY DRIVE GEAR INSTALLATION

Install gear holder and install drive gear bolt and washer together


Torque: 5.0-6.0 Kg-m

Special Tool:

Gear Holder : 07HMB-KV30100

Install clutch

Install R. crankcase cover ( 8.15)



## CLUTCH INSTALLATION


Clutch Lifter Arm Installation

Apply molybdenum grease to spindle lifter rod connection  
Insert clutch lifter arm and install clutch lifter arm stopper bolt.

Torque: 0.8-1.2Kg-m


Install clutch cable into lifter arm

Install L. crankcase cover ( 10.3)  
Install exhaust chamber ( 15.7)




## CLUTCH INSTALLATION

Install clutch outer guide and needle bearing into main shaft




Apply molybdenum grease to clutch outer  
Install clutch outer, thrust washer into main shaft

\* If it is difficult to install clutch outer, turn the kickstarter idle gear in order to make it easier to enter




Align main shaft spline and install clutch centre and washer



Install lock nut  
Install clutch centre holder into clutch centre

\* Install clutch centre groove and holder so that they connect correctly




Install new clutch centre lock nut

Torque: 5.0-6.0 Kg-m

Standard Tool:


Clutch centre holder : 07724-0050000

Align main shaft groove with locknut flange



Install clutch discs, clutch plates, judder springs and seat as in the picture

\* Before installing apply recommended engine oil to disc plates  
\* Check that judder springs are assembled in correct direction





Insert clutch lifter rod into main shaft  
Check clutch lifter arm

\* Move clutch lever and arm and check rod movement

Apply grease to steel balls  
Insert steel balls into clutch lifter guide  
Push clutch lifter guide and steel balls into clutch lifter rod and install


Install 5 clutch springs and install 5 bolts into pressure plate

\* Turn opposing bolts 2-3 times to install




#### R. CRANKCASE COVER INSTALLATION

Apply grease to oil seal lip



Install knock pin and new gaskets



Install R.crankcase cover

\* Install bolts opposing each other



Install water joint


Install kickstarter pedal

Torque: 3.5-4.5 Kg-m

\* Align kickstarter and spindle punch mark and install kick pedal

Inspect clutch lever play ( 2.7)  
Insert transmission oil ( 2.9)  
Insert radiator fluid ( 5.4)  
Install R. lower fairing ( 15.5)





# 9. TRANSMISSION

MAINTENANCE INFORMATION.....	9 - 1	TRANSMISSION INSPECTION .....	9 - 4
TROUBLE SHOOTING.....	9 - 2	TRANSMISSION REPLACEMENT .....	9 - 5
TRANSMISSION REMOVAL .....	9 - 3	TRANSMISSION INSTALLATION .....	9 - 8

## MAINTENANCE INFORMATION:

### Warnings:

- \* Perform all maintenance with vehicle in an upright position
- \* Before removing transmission, remove the following parts:
  - clutch (section 8)
  - kickstarter (section 8)
  - gearshift linkage (section 8)

: mm

ITEM		STANDARD	SERVICE LIMIT	
Mainshaft	Backlash	0.044-0.133	0.30	
Countershaft	Gear I.D	M 5	28.000-28.021	
		M 6	28.000-28.021	
		C 1	23.000-23.021	
		C 2	28.000-28.021	
		C 3	28.000-28.021	
		C 4	28.000-28.021	
	Gear Collar	M 5 I.D	25.000-25.021	
		M 5 O.D	27.959-27.980	
		M 6 O.D	27.959-27.980	
		C 1 O.D	22.959-22.980	
		C 1 I.D	20.020-20.041	
		C 2 O.D	27.959-27.980	
		C 2 I.D	25.000-25.021	
		C 3 O.D	27.959-27.980	
	Mainshaft O.D	M 5	24.980-24.993	
		Countershaft O.D	C 1	19.980-19.993
			C 2	24.959-24.980
	Shift fork	Hook width	5.93-6.00	5.6
I.D		11.000-11.021	11.04	
Fork shaft O.D		11.966-11.984	11.94	
Shift drum O.D		11.966-11.984	11.94	

## TOOLS

### Special Tools

Bearing remover	07936-3710300
Remover handle	07936-3710100
Remover sliding weight	07741-0010201
Driver handle	07949-3710001

### Standard Tools

Outer driver (37x40mm)	07746-0010200
Outer driver (42x47mm)	07746-0010300
Outer driver (62x68mm)	07746-0010500
Pilot (20mm)	07746-0040500
Pilot (25mm)	07746-0040600
Driver handle A	07749-0010000
Driver handle C	07746-0030100
Inner driver (25mm)	07746-0030200

---

TROUBLE SHOOTING:

Engine Noise

- transmission bearing worn
- transmission gears shaft collar damaged

Gears Sticking

- gear dogs damaged
- shift fork bent
- shift fork shaft bent

Gear Difficult To Engage

- clutch cable adjustment faulty
- shift fork bent, damaged
- shift fork shaft bent
- Transmission oil level incorrect  
or faulty



## TRANSMISSION REMOVAL

Remove lower fairing ( 15.3)


Remove the following

- clutch ( 8.3)

- kickstarter ( 8.7)

Gearshift linkage ( 8.8)


Raise plate tabs, remove drive sprocket bolts, lock plate and drive sprocket



Remove 6 bolts


While lightly knocking counter shaft from drive sprocket side, remove transmission and bearing holder as as assembly

Remove knock pin




Inspect each gears backlash


Service Limit: 0.30mm (replace if above)



Pull shift fork shaft and remove shift fork and shaft drum



Remove main shaft bearing set plate and remove mainshaft and countershaft as an assembly from bearing shaft



TRANSMISSION INSPECTION

Mainshaft, Countershaft, Gears, Collars

Separate each gear from shaft and inspect gears faces and dogs for damage

\* Do not open circlip more than necessary. Hold shaft and heavy items and slide to remove

Inspect each gear dog and hole for wear and damage. Also inspect each gear facing for wear and damage.



Measure each gears I.D

- M5, M6, C2, C3, C4 : 28.05mm (replace if over)
- C1 : 23.05mm (replace if over)

Measure each gear collars internal O.D

Service limit:

- M5 I.D : 25.085mm (replace if above)
- C2 I.D : 25.05mm (replace if above)
- C1 I.D : 20.07mm (replace if above)
- C1 O.D : 22.92mm (replace if below)
- M5, M6, C2, C3, C4 O.D : 27.92mm (replace if below)




Measure mainshaft counter shaft O.D

Service limit:

- M5 : 24.95mm (replace if below)
- C1 : 19.95mm (replace if below)
- C2 : 24.93mm (replace if below)

While turning mainshaft bearing outer race, inspect for smooth movement and condition Also inspect that mainshaft is tightened so there is no slack if abnormal, then replace ( 9.7)



### SHIFT FORK


Inspect shift fork for warpage and change in shape

Measure shift fork I.D and hook width

Service limit:

I.D : 11.04mm (replace if above)

Hook width : 5.6mm (replace if below)




### SHIFT FORK SHAFT

Inspect shift fork shaft for warpage and damage

Measure shaft O.D

Service limit: 11.94mm (replace if below)




GUIDE GROOVE

### SHIFT DRUM

Inspect shift drum guide groove for damage

Measure shift drum O.D

Service limit: 11.94mm (replace if below)




### TRANSMISSION BEARING REPLACEMENT

Bearing holder

Turn R. countershaft bearing and shift drum bearing and inspect for smooth movement  
Also inspect bearing holder for movement  
If replacement is necessary, remove shift drum bearing set plate and remove shift drum bearing

Remove R. countershaft bearing




Insert new R. countershaft bearing and shift bearing

- \* Insert with bearing mark facing outwards
- \* Insert using weight


Standard tools:

Outer driver (42x47mm) 07746-0010300  
Pilot (20mm)(R.countershaft)07746-0040500  
Pilot (25mm)(shift drum brg)07746-0040600  
Driver handle A 00749-0010000



Install shift drum bearing set plate and tighten bolt

- \* Apply locking agent to bolt and install
- \* Do not apply too much locking agent




### CRANKCASE

Inspect shift drum and shift fork shaft for wear and damage  
Turn L. countershaft bearing and L. mainshaft bearing inner race and check for smooth movement

Also inspect for movement in crankcase

#### L. Countershaft Bearing Replacement

Remove countershaft oil seal and remove L. countershaft bearing



Insert new L. countershaft bearing

- \* Insert with bearing facing outwards
- \* Insert into crankcase using weight

Special Tools:  
Driver handle 07949-3710001  
Standard Tools:  
Outer driver (62x68mm) 07746-0010500



L. Mainshaft Bearing


Remove L. mainshaft bearing

- Bearing remover 07936-3710300
- Remover handle 07936-3710100
- Remover sliding weight 07741-0010201



Insert new L. mainshaft bearing

- \* Insert with bearing mark facing outwards
- \* Insert into crankcase using weight




Special Tool: Driver handle 07949-3710001

Standard Tool: Outer driver (37x40mm) 07746-0010200

Inspect shift spindle oil seal and replace if necessary

Apply grease to lip



MAINSHAFT

Use bearing puller and remove R. mainshaft bearing .




Insert new R.mainshaft bearing into mainshaft

Standard Tools

Driver handle C  
 Inner driver (25mm)


07746-0030100  
 07746-0030200



- \* Insert with bearing mark facing outwards
- \* Insert into mainshaft using weight

TRANSMISSION INSTALLATION

Apply transmission oil to each moving part




Install mainshaft and countershaft as an assembly into bearing holder  
Install mainshaft bearing set plate

Install bolts

\* Use new bolts


Take care when installing shift forks that the respective "R", "C" and "L" marks are in the correct places



Install shift drum and shift fork


\* Face shift fork marks upwards as in the photo

Install shift fork shaft  
Inspect for smooth movement in each part




Install knock pin

\* Do not forget to install knock pin




Install transmission as an assembly with bearing holder into crankcase

Install 6 bolts in opposing positions, 2-3 turns each time



Install new countershaft oil seal into crankcase

- \* Install at same height as crankcase edge
- \* Install taking care not to damage oil seal lip and spring
- \* Apply tape to countershaft drive sprocket and apply grease to oil seal lip




Install drive sprocket, fixing plate and lock plate and tighten bolts

Align lock plate hook so that the bolts can not rotate


Install the following:

- gearshift linkage ( 8.10)
- kickstarter ( 8.11)
- clutch ( 8.13)





AC GENERATOR



# 10. AC GENERATOR

MAINTENANCE INFORMATION.....	10- 1	AC GENERATOR INSTALLATION .....	10- 3
PULSE GENERATOR REMOVAL .....	10- 2	PULSE GENERATOR INSTALLATION .....	10- 3
AC GENERATOR REMOVAL .....	10- 2		

## MAINTENANCE INFORMATION

### Warning

- This section explains how to remove the AC Generator and Pulse Generator
- Refer to section 16 for AC Generator troubleshooting and inspection
- Refer section 17 for pulse generator troubleshooting and inspection

### Torques:

Flywheel	8.0-9.0kg-m
Stator	1.0-1.4kg-m

### TOOLS:

#### Special Tools:

Rotor Puller Attachment      07HMC-KV30100

#### Standard Tools

Universal holder                      07725-0030000


Flywheel puller                      07733-0010000

**PULSE GENERATOR REMOVAL**


Remove seat, side covers and lower fairing ( section 15)

Remove pulse generator coupler connection

If removing AC Generator, disconnect AC Generator coupler




Remove 4 bolts and remove L. crankcase cover



Remove connector from neutral switch

Remove pulse generator



\* Take care not to lose wire grasper


**AC GENERATOR REMOVAL**

Remove AC Generator coupler connection

Use a universal holder and fix flywheel

Standard Tool - Universal Holder 07725-0030000

Remove flywheel bolt




Use flywheel puller and remove flywheel

Special tool - Rotor Puller Attachment


07HMC-KV30100

Standard Tool - Flywheel Puller 07733-0010000

\* Install the special tool puller as in the picture so that the puller thread does not enter the crankshaft thread



ROTOR PULLER ATTACHMENT




### AC GENERATOR INSTALLATION

Install stator into crankshaft and tighten bolts

Torque: 1.0-1.4 Kg-m

Route AC Generator wires correctly and install grommet into case groove

Connect AC generator coupler ( 10.4)



Install flywheel into crankshaft


\* Remove all damaged and abnormalities from flywheel and stator and install

\* Remove tape from crankshaft

Use the universal holder and fix flywheel  
Install washer and flywheel bolt and tighten

Special Tool - Universal Holder 07725-0030000

Torque: 8.0-9.0 Kg-m




### PULSE GENERATOR INSTALLATION

Install pulse generator

\* Clamp AC generator wires, pulse generator wires correctly using clamber


Route pulse generator wire correctly and install grommet into case groove

Connect neutral switch




---

Install L. crankcase and tighten bolts




Connect pulse generator coupler and AC generator coupler

Install lower fairing, side covers and seat (section 15)



CRANKCASE, CRANKSHAFT



# 11. CRANKCASE, CRANKSHAFT

MAINTENANCE INFORMATION.....	11-1	CRANKSHAFT .....	11-2
TROUBLE SHOOTING .....	11-1	CRANKCASE ASSEMBLY .....	11-4
CRANKCASE SEPARATION .....	11-2		

## MAINTENANCE INFORMATION

### Warnings:

When adjusting crankshaft it is not necessary to remove engine. If the following parts are removed, maintenance can be performed.

- Cylinder head, cylinder, piston (section 7)      - Primary drive gear (section 8)
- AC Generator, Pulse generator (section 10)      - Front engine hanger bolt (section 6)
- Upper crankcase
- Crankshaft adjustment is explained as if the engine has been removed from the frame
- Remove the following parts before adjusting crankcase
  - Cylinder head, cylinder, piston (section 7)      - Clutch kickstarter, gearshift linkage (section 8)
  - Transmission (section 9)
  - AC generator, pulse generator (section 10)
- Remove engine as in section 6
- Before proceeding clean engine of all foreign particles
- When separating crankshaft take sufficient care not to damage oil seal. This could cause a decrease in engine performance
- When installing crankshaft the main journal bearing set pin must be set in the case groove

: mm

Item		Standard	Service Limit
Conrod	Big end axial clearance	0.55-0.75	0.85
	Big end axial perpendicular gap		0.05
Crankshaft Journal runour	A	0.05	0.10
	B	0.03	0.08

### Torque:

Crankcase bolt                      2.1-2.5kg-m                      Neutral Switch                      1.4-1.8kg-m

## TROUBLE SHOOTING

### Engine Noise

- Main journal bearing faulty
- Crank pin bearing faulty

## CRANKCASE SEPARATION

Remove the necessary parts for adjustment

( 11.1)

Remove upper crankcase bolt



\* So that the cases do not warp remove the small bolts first, moving to the bigger bolts, removing opposite bolts 2-3 turns at a time

Lower upper crankcase and remove lower crankcase bolt

Face upper crankcase upwards

Pull upper crankcase upwards and separate crankcase

\* Take care not to mark align marks with driver etc  
\* Lightly tap cases with plastic hammer to separate




## CRANKSHAFT

Crankshaft Removal

Hold both ends of crankshaft and pull crankshaft assy upwards from lower crankcase.

Remove oil seals from both ends of crankshaft


\* Take care not to damage oil seal lip



## OIL SEAL INSPECTION

Inspect oil seal for damage. Particularly if you can see damage to oil seal lip, engine performance will be affected unless seal is replaced.

\* If damage can be seen to middle oil seal in crankshaft, replace as a crankshaft assembly.





## CRANKSHAFT INSPECTION


Measure conrod big end axial clearance

Service limit : 0.85mm (replace if above)



Measure conrod big end axial values X,Y

Service limit: 0.05mm (replace if above)



Turn crankshaft journal bearing outer race and inspect for smooth movement


If abnormal, replace crankshaft assembly

If crankshaft middle oil seal is damaged, replace crankshaft assembly

Measure crankshaft journal runout:


Service limit : 0.10mm (replace if above)(A,C)  
: 0.08mm (replace if above) (B)

If abover service limits are exceeded replace crankshaft assembly



## CRANKSHAFT INSTALLATION

Install bearing set ring into right hand lower crankcase bearing holder




Apply recommended engine oil to journal bearing and conrod big end.

Install oil seal to crankshaft end

\*Take care not to damage oil seal lip

Apply sealing agent to R-L oil seal outside  
Align crankshaft journal bearing set pin with lower crankcase groove and install bearing into crankshaft assembly

\* Set crankshaft into crankcase and lightly tap journal bearing into crankcase with plastic hammer  
\* Check that the respective oil seals are set into the case grooves  
\* Check that the respective bearing set pins are entered into the crankcase groove



#### CRANKCASE ASSEMBLY

Check that the crankshaft journal bearings set pin is set into the case groove.


\* Clean crankcase aligning face of all packing

Apply packing to crankcase aligning face

\* Do not apply to knock pin hole

Install upper crankcase to lower crankcase


\* Inspect aligning mark clearance & assemble so there is no clearance



Tighten lower crankcase bolt

Torque: 2.1-2.5 Kg-m

\* Tighten bolts 2-3 turns at a time from the inside to the outside




Tighten upper crankcase bolts


Torque : 8 mm bolt 2.1-2.5kg-m  
6 mm bolt 1.0-1.4kg-m

\* Tighten bolts 2-3 turns at a time,  
opposing each other

Install removed parts in reverse order to  
removed



FRONT WHEEL, SUSPENSION, STEERING



# 12. FRONT WHEEL, SUSPENSION, STEERING

MAINTENANCE INFORMATION	12-1	FRONT WHEEL	12-6
TROUBLE SHOOTING- HANDLEBARS	12-2	FRONT FORKS	12-10
	12-3	STEERING STEMS	12-17

## MAINTENANCE INFORMATION

### Warnings:

- Raise front wheel and make sure that wheel can turn with minimal force. Also make sure there is nothing that can damage wheel
- Because tubeless tires have been fitted, take special care that there is no damage to tires and rims.
- When removing wheels from rims use special "tire levers" and "rim protectors"
- Regarding tubeless tire removal refer to Honda Motorcycle Tubeless Tire Service Manual No.6041551
- When replacing tires remove disc housing from wheel hub. When replacing tire balance wheel by adding disc plate.

Item		Standard	Service Limit
Front axle warp		_____	0.2mm
Front Wheel Rim Out	Radial	_____	2.0mm
	Axial	_____	2.0mm
Front cushion spring freeplay		291.5mm	285.7mm
Front fork pipe warp		_____	0.2mm
Front fork oil capacity	Total	383cc	_____
	Ttl Replacement	108mm	_____
Front fork air pressure		0-0.4kg/cm <sup>2</sup>	_____

## TORQUES

Handlebar bolts	2.4-3.0kg-m	Front fork socket bolt	1.5-2.5kg-m
Brake disc nut	1.4-1.6kg-m	Bottom bridge bolt	4.5-5.5kg-m
Front axle bolt	5.5-6.5kg-m	Top bridge bolt	0.9-1.3kg-m
Axle pinch bolt	1.5-2.0kg-m	Fork bolt	1.5-3.0kg-m
Caliper bracket bolt	2.4-3.0kg-m	Steering adjust. nut	2.3-2.7kg-m
Master cylinder holder bolt	1.0-1.4kg-m	Clutch lever holder	9.0-12.0kg-m 0.7-1.1kg-m

## TOOLS:

### Special Tools

Steering stem socket	07916-3710100	(1) Driver shaft body	07946-KM90300
Steering stem driver	07946-MB00000	(2) Assembly base	07946-KM90600
Fork seal driver	07947-4630100	(3) Driver attachment A	07946-KM90100
Ball race remover set [(1)-(6)]	07946-KM90000	(4) Driver attachment B	07946-KM90200
		(5) Bearing remover A	07946-KM90400
		(6) Bearing remover B	07946-KM90500

---

### Standard Tools

Extension bar	07716-0020500	Driver handle A	07749-0010000
Lock nut wrench (30x32)	07716-0020400	Pilot (20mm)	07746-0040500
Bearing remover shaft	07746-0050100	Outer driver (42x47)	07746-0010300
Bearing remover head (20mm)	07746-0050600		

### TROUBLE SHOOTING

#### Handlebars Heavy

- steering adjustment nut too tight
- Steering bearings damaged
- Wires, cables stuck on steering
- Tire pressures too low

#### Handlebars Pullable

- Front forks bent
- Front axle bent, tires warped
- Rear fork bent

#### Front End Runout

- rim shape changed
- front wheel bearings damaged
- tires faulty
- axle tightening faulty
- wheel balance faulty

#### Front Cushion Noise

- fork pipe and bottom case give
- oil capacity incorrect
- cushion bolts to lose

#### Front cushion Sag

- springs bent
- oil capacity too low
- fork air pressure incorrect
- recommended oil not used

#### Front Cushion Too Hard


- fork oil incorrect
- fork air pressures incorrect
- fork pipes bent
- oil clogged
- recommended oil not used

## HANDLEBARS

### Removal


Remove the following from R. Handle

- master cylinder
- handle switches
- handle weight
- throttle grip




Remove following from L. handle

- clutch lever bracket
- handle switch case
- handle weight
- handle grip
- choke lever




Remove steering top bridge ( 12.18)

Loosen handle bolts and remove handlebars



### Installation

Check that left and right front fork grooves have stopper rings fitted




Install handlebars to front forks  
Install top bridge and align top bridge  
shoulder and protrusion

Tighten steering stem nut ( 12.22)

Torque : 9.0-12.0 Kg-m

\* Inspect that top bridge and handlebars  
are fitted correctly and that the  
stopper ring is not pushing out. If any  
abnormality, loosen bottom bridge bolt  
and adjust front fork position



Tighten top bridge bolt

Torque : 0.9-1.3 Kg-m

Tighten handlebar bolts


Torque : 2.4-3.0 Kg-m

Apply multipurpose grease to throttle  
grip and install. Install handle weight



Connect throttle cable to throttle grip  
Align R. handle switch case protrusion  
and handle hole, then tighten

Tighten switch case 2 screws




\* Tighten front screws first then rear  
screws

Face holder "UP" mark upwards and install  
master cylinder to handlebars  
Align master cylinder and holder with  
handlebars pinch mark  
Tighten top bolt first then bottom bolt

Torque : 1.0-1.4 Kg-m

Connect wire to front stop light switch

After tightening adjust throttle grip  
play ( 2.15)





Install choke lever to handlebars

Clean L. handle grip completely

Apply recommended "Honda Bonda A" or "Semedine #540" to grip internally and install making sure grip cannot turn

\* After installing grip make sure it cannot turn

Install handle weight

Install choke cable to choke lever

Align L. switch case protrusion with handle hole and install




Tighten 2 screws

\* Tighten front screws first then rear screws

Install clutch lever bracket and holder and tighten bolts

Torque : 0.7-1.1 Kg-m

\* Align holder mark with handle punch mark  
\* Face holder "UP" mark upwards  
\* Tighten top bolt first then bottom bolt




## FRONT WHEEL

### Removal


Remove screws and remove speedometer cable from gear box

Remove caliper bracket bolt and remove one caliper ( 14.4)



- \* Do not hang brake caliper on brake disc
- \* Hold caliper upwards with tape
- \* Do not twist brake hose
- \* After removing brake caliper do not move from brake lever

Place vehicle in upright position and steady front wheel  
Loosen L-R axle pinch bolt and remove axle  
Pull out axle and remove front wheel



- \* Take care not to damage disc pads

### Inspection


Inspect front axle for warpage

Place Vee block upwards and measure front axle with dial gauge. A reading on the dial gauge indicates warpage


Service limit : 0.2mm (replace if above)

Turn wheel slowly and inspect rim runout with dial gauge

Service limit : radial - 2.0mm  
axial - 2.0mm  
(replace if above these)



- \* Cast wheel can not be dismantled



Turn bearing inner race by hand and replace if any noise or poor movement  
 inspect that bearing outer race is completely pressurised against hub, if abnormal then replace bearing

8 Always replace left and right bearings as as set.

WHEEL BALANCE

- \* Check wheel balance with vehicle raised, handlebars stationery and vehicle completely balanced. If tire is removed from wheel inspect rim balance
- \* Check that tire balance mark ( on side of wheel) is aligned with valve




Remove collar and speedometer gearbox  
 Inspect wheel, tire and brake disc with vehicle on a stand. Stop wheel from rotating release and wait for heavy portion to reach bottom. Do this 2-3 times to assess heavy point. If wheel is imbalanced apply weight to top of rim (opposite to heavy point). If necessary change weights until one is selected which will stop the wheel rotating to a heavy point. Fix weights securely

- \* Do not place weights greater than 60g on front wheel and 60g on rear wheel


Separation

Remove collar and dust seal from right hub  
 Remove the 6 nuts and remove R. brake disc housing

- \* Do not remove more that brake disc and housing



R. DISC HOUSING - NUT - COLLAR




Remove speedometer gearbox, dust seal and gear box retainer from left side

Remove 6 bolts and remove L. brake disc housing

\* Do not remove more than brake disc and housing

L. DISC HOUSING BOLT GEARBOX




Standard tools:

Bearing remover shaft

07746-0050100

Bearing remover head (20MM)

07746-0050600




REMOVER SHAFT

REMOVER HEAD

ASSEMBLY

\* Brake disc performance will be affected if oil or other foreign materials are apply to disc. Clean totally before use.

AXLE BOLT R. BRAKE DISC



Insert R. bearing and distance collar

Standard tools

Driver Handle A  
07749-0010000

Pilot (20mm)  
0.16-0040500

Outer driver (42×47mm)  
07746-0010300

\* Before installing bearing check that distance collar is installed

Insert L-R bearing with same standard tool  
Install gearbox retainer and dust seal  
Apply grease to dust seal lip  
Apply grease to gear box align gearbox shoulder and retainer groove and install

Install left/right disc housing

Tighten disc housing nut

Torque: 1.4-1.6 Kg-m

install dust seal and apply grease to lip

install wheel

#### INSTALLATION

While aligning brake pad gap with brake disc, set front wheel

\* Take care not to damage brake pads, disc





Move axle from left  
Align speedometer gear box stopper with L. fork bottom case stopper

Install L. axle pinch bolt

Torque : 1.5-2.0 Kg-m

\* Align axle line with bottom case

: 1.5-2.0kg-m



install axle bolt and tighten

Torque : 5.5-6.5 Kg-m

Tighten R axle pinch bolt

Torque : 1.5-2.0 Kg-m

Connect speedometer cable to gearbox and tighten screw

Install caliper ( 14.6)

\* Take care not to damage brake pads

Loosen L. axle pinch bolt

Measure that the L. Brake disc and caliper bracket clearance is 0.7mm using a thickness gauge. If thickness gauge does not enter pull L. fork out until it will. Check that both sides of the left disc have a clearance of greater than 0.07mm.

Tighten L. axle pinch bolt

Torque : 1.5-2.0 Kg-m

Pull in brake lever a few times and check caliper bracket to disc clearance

\* If the caliper bracket to brake disc clearance is not sufficient then a damaged disc will be the cause.

#### FRONT FORKS

##### Removal

Remove front wheel ( 12.6)





Remove caliper bracket bolt and caliper ( 14.4)

\* Do not pull caliper on brake hose  
\* Tie brake caliper into a fixed position  
\* Do not twist brake hose  
\* After removing brake caliper do not operate front brake lever

Remove front fender bolt and remove front fender

Remove brake pipe from front forks

\* Do not bend or twist brake pipe



Remove air valve cap push air valve and drain air from forks

Loosen fork bolt  
loosen top bridge bolt  
Remove handlebars ( 12.3)

\* Do not hang brake hose on front brake master cylinder  
\* Oil pressure can be affected by air entering master cylinder, fix it at the position the same as the installed position

Pull out stopper ring





Loosen bottom bridge bolt and remove front forks

#### SEPARATION

Remove fork bolt


Remove spacer, spring seat, spring

Pump fork pipe and drain oil from front fork




Fix bottom case in vice

Remove socket bolt from bottom case




Remove dust seal

Remove snap ring




Pull out fork pipe from bottom case

\* Push in fork pipe (not too hard) and pull strongly and repeat



Remove oil lock piece from bottom case  
Remove oil seal, back up ring and guide bush from fork pipe


\* Only remove fork pipe bush if replacing with a new one





Remove stopper ring from seat pipe

Remove seat pipe from fork pipe



Inspection


Measure for spring free play

ServiceLimit: 285.7mm (replace if below)




Inspect fork pipe, seat pipe, oil lock piece, rebound spring, bottom case and piston ring for wear and damage

Replace if any abnormalities




Inspect spacer, spring seat for damage.  
If any then replace




Face Vee block upwards and measure warpage of fork pipe with dial gauge. The value will give the degree of warpage


Service Limit: 0.2mm (replace if above)




Inspect guide bush and fork pipe bush rubbing face. When rubbing portion is more than 3/4 and metal can be seen (teflon is peeling off), or if damaged, then replace  
Inspect back up ring inspection portion  
If there is a change in shape, then replace




ASSEMBLY



Install seat pipe to fork pipe  
 Install stopper ring into seat pipe groove




Install oil lock piece into seat pipe  
 Install guide bush and back up ring into fork pipe.  
 Apply ATF to oil seal lip and install fork pipe




\* Before aligning oil seal, stick tape to fork pipe upper end and take care not to damage oil seal lip  
 \* Face oil seal markers mark upwards

Install fork pipe into bottom case  
 Hold bottom case, fix in vice and install socket bolt, into seat pipe  
 Torque : 1.5-2.5kg-m



Insert guide and oil seal at the same time into the bottom case, using a driver




Special Tool 07947-4630100  
 Fork seal driver

Install snap ring

Install dust seal


\* Ensure that snap ring is installed in bottom case groove



Fully extend fork pipe and fill with ATF fluid to recommended level

Recommended level : 108mm

Total Capacity : 383cc




Face the small pitch end of the fork spring into the bottom and install in the front fork



Install spring seat and spacer

Replace fork bolt O ring if damaged and apply a little ATF fluid to it.

Install fork bolt into fork pipe



## INSTALLATION

Place front fork in bottom bridge  
Install stopper ring into fork pipe groove  
Install handlebars ( 12.3)  
Tighten top bridge

Torque : 0.9-1.3Kg-m

Tighten bottom bridge bolt

Torque : 4.5-5.5 kg-m

Install fork bolt

Torque : 1.5-3.0 kg-m

Install front fender  
Install brake pipe

\* Place bolts in both sides of brake pipe and after deciding on correct position, tighten bolts

Install brake caliper ( 14.6)  
Install front wheel ( 12.9)  
Adjust front fork air pressure ( 2.7)

## STEERING STEM




### Removal

Remove steering stem nut, washer  
Loosen top bridge bolt and remove top bridge


Standard tools  
Extension bar

Lock nut wrench (30×32mm) 07716-0020500

Remove front wheel ( 12.6)  
Remove front forks ( 12.10)  
Remove centre lower fairing ( 15.3)




Remove brake hose crammer from bottom bridge



Straighten lock washer hook  
Remove lock nut, lock washer

\* Do not re-use lock washer



Remove steering adjuster nut  
Special tool

07916-3710100 - Steering stem socket




Remove steering stem, dust seal, upper bearing inner race and upper bearings  
Remove lower bearings from steering stem.

#### INSPECTION

Inspect upper, lower bearings for wear and damage. Inspect steering stem lower bearing inner race and dust seal for wear and damage

Inspect steering head pipe bearing outer race for wear and damage



**BEARING REPLACEMENT**

\* When replacing bearings, replace bearings inner and outer races as a set

Remove lower bearing inner race

\* Install stem nut inot stem and fix so that thread cannot be damaged  
 \* Take care not to damage stem



Remove dust seal

Inertill

Install dust seal into steering stem and pressure in inner race

Special tools:

07946-MB00000 - Steering stem driver



**BALL RACE REPLACEMENT**

Ball race remover set (1)-(6)

07946-KM90000

① Driver shaft assy (nut A,B)  
 07946-KM90300

② Assembly Base  
 07946-KM90600

③ Driver attachment A  
 07946-KM90100



④ Driver attachment B  
 07946-KM90200

⑤ Bearing remover A  
 07946-KM90400

⑥ Bearing remover B  
 07946-KM90500

Set ball race remover into head pipe as in the picture

\* Align head pipe shoulder with bearing remover A and install  
 \* Lightly tighten nut B with spanner  
 \* Take care with assembly base direction



Stop driver shaft moving using spanner,  
turn Nut A and remove outer race

At the same time, remove lower outer  
race




\* Align bearing remover B with head pipe  
shoulder and install

Set upper outer race and ball race  
remover with head pipe as in the  
picture



Stop driver shaft moving using spanner  
turn Nut A and install outer race

Set lower outer race and ball race  
remover in the head pipe as in the  
picture

Stop driver shaft moving using spanner  
and turn Nut A and install lower outer  
race




### INSTALLATION





Apply sufficient grease to bearing  
Install lower bearings to steering stem  
Install steering stem into steering head  
Install upper bearings, inner race and dust seal



Tighten steering adjuster nut


Torque : 2.3-2.7 kg-m

Special tool

Steering stem socket - 07916-3710100


Move steering stem left and right 5-6 times to seat bearings

Tighten steering adjuster nut to the recommended torque.




Align new lock nut washer hook with steering adjuster nut groove and install  
Tighten lock washer and lock nut by hand until they meet  
Hold steering adjuster hook and lock nut groove meet exactly

Bend lock washer hook until it nears lock nut groove



Install brake hose into bottom bridge using crammer




Temporarily install front forks  
Temporarily install handlebars to front  
forks  
Install fork top bridge  
Install washer stem nut and tighten

Torque : 9.0-12.0 Kg-m

Special Tools:

Lock nut wrench (30x32) 07716-0020400


Extension bar 07716-0020500



Install front forks properly ( 12.17)  
Tighten top bridge bolt

Torque : 0.9-1.3 kg-m

Install handlebars ( 12.3)  
Install front wheel ( 12.9)



#### STEERING STARTING WEIGHT


Raise frame and lift front wheel off  
ground

Hang scales from front fork pipe and  
measure the weight required to move  
steering

\* Do not hook up cables and wire harness  
on ste,  
\* Turn steering top bridge and pull 90°

If it takes 1.0-1.5kg to move forks from  
left to right it is okay.

# REAR WHEEL, SUSPENSION



# 13. REAR WHEEL, SUSPENSION

MAINTENANCE INFORMATION.....	13-1	REAR CUSHION .....	13-7
TROUBLE SHOOTING.....	13-2	SUSPENSION LINKAGE .....	13-12
REAR WHEEL .....	13-3	REAR FORK .....	13-14

## MAINTENANCE INFORMATION

### Warnings

- \* When raising wheel, ensure wheel does not require large force to turn. Also, do not damage wheel.
- \* Standard tubeless tires are being used. Take care not to damage tire, rim.
- \* When removing tire from rim, so that tires do not get damaged, use special tools [tire levers] and [Rim protectors]
- \* Refer to HONDA MOTORCYCLE TUBELESS TIRE SERVICE MANUAL No.6041551 for tubeless tire removal method
- \* Always use correct nuts and bolts in rear suspension linkage and rear cushion. Also do not change bolt direction
- \* Refer to section 12.7 for rear wheel balancing

Item	Standard	Service limit
Rear axle warpage	-----	0.2mm
Rear wheel rim runout	Radial	2.0mm
	Axial	2.0mm
Rear cushion damper pressure	24-29kg	19.2kg
Rear cushion spring length	124.0mm	-----
Rear cushion spring freeplay	131.3mm	128.7mm

### TORQUES:

Driven sprocket nut	2.8-3.4kg-m	Rear fork pivot adjuster bolt	1.0-2.0kg-m
Rear axle nut	8.0-10.0kg-m	Rear fork pivot lock nut	6.0-7.0kg-m
Rear cushion lower joint 1/nut	6.0-7.5kg-m	Rear fork pivot nut	6.0-7.0kg-m
Rear cushion lower bolt	6.0-7.0kg-m	Rear brake disc bolt	3.7-4.3kg-m
Rear cushion upper bolt	6.0-7.0kg-m	Cushion arm bolt (rear fork)	6.0-7.0kg-m
Conrod bolt (cushion arm)	6.0-7.0kg-m	Rear cushion lower joint	3.8-6.0kg-m
Conrod bolt (frame)	6.0-7.0kg-m	(apply locking agent)	

---

TOOLS:

Special Tools

Lock nut wrench	07GMA-KT70200	Bearing remover (15mm)	07936-KC10000
Rr cushion Comp. Attach	07959-MB10000	- Remover assy (15mm)	07936-KC10500
Needle bearing remover	07GMD-KT80100	- Remover shaft (15mm)	07936-KC10100
Driver shaft B	07964-MB00200	- Remover head (15mm)	07936-KC10200
Needle brg driver attac	07HMD-KV30100	- Remover steering weight	07741-0010201

Standard tools

Outer driver (32x35mm)	07746-0010100	Bearing remover shaft	07746-0050100
Outer driver (42x47mm)	07746-0010300	Bearing remover head (17mm)	07746-0050500
Outer driver (24x26mm)	07746-0010700	Bearing remover head (20mm)	07746-0050600
Pilot (15mm)	07746-0040300	Driver handle A	07749-0010000
Pilot (17mm)	07746-0040400	Rear cushion compressor	07GME-0010000
Pilot (20mm)	07746-0040500	- Compressor screws assy	07GME-0010100

TROUBLE SHOOTING

Rear Wheel Runout

- wheel rim shaped changed
- rear wheel bearings collapsed
- tires faulty
- axle incorrectly tightened
- tire pressures faulty
- rear fork pivot bearings faulty
- tires worn
- wheel balance incorrect

. Rear Cushion Noisy

- cushion case out of shape
- bolts loose

Rear Cushion Too Soft

- cushion spring warped
- rear cushion adjuster incorrectly adjusted
- rear damper warped, oil leakage

Rear Cushion Hard

- damper rod bent
- rear fork pivot bearing worn
- rear cushion adjuster incorrectly adjusted



## REAR WHEEL

### Removal

Raise frame and rear wheel off the ground  
Remove rear axle nut  
Loosen drive chain adjuster, pull out rear axle, push rear wheel forward, and remove chain from driven sprocket  
Remove rear wheel

Place rear axle on Vee block and inspect using dial gauge  
The reading on the dial gauge indicates the degree of warpage


Service limit: 0.2 (replace if above)



Turn wheel slowly and inspect runout using dial gauge

Service limit: Radial: 2.0mm (replace if above)  
Axial: 2.0mm ( " " " )


- \* Do not assemble cast wheel
- \* If exceeds service limit then replace



Turn bearing inner race, and replace if any abnormalities


Inspect that the outer race is in hub properly - If abnormal replace

- \* Always replace bearings as a set of three (2 wheel bearings and 1 flange bearing)




Inspect final driven sprocket for wear and damage

\* Do inspection of drive chain and drive sprocket at the same time. If replacing, always replace as a set.




Separation

Remove rear brake disc three bolts and remove brake disc



Remove driven flange and damper rubber

Remove O ring



Use bearing remover to remove left and right side collars


Bearing remover shaft 07746-0050100

Bearing remover head (17mm) 07746-0050500


Remove dust seal, wheel bearings & distance collar

Bearing remover shaft 07746-0050100


Bearing remover head (20mm) 07746-0050600



Remove bearings, collar, dust seals from driven flange



ASSEMBLY



Inset new bearings into driven flange

\* Insert bearings so that there is more sticking out in driven flange

Standard tools

Driver handle A


Outer driver (42x47mm)

Pilot (20mm)

07740-0010000

07746-0010300

07746-0040500






Apply grease to dust seal lip and install into driven flange

install collar into bearing

\* When installing collar, ensure bearing inner race will not cause damage to bearings



Insert R. bearing first  
insert distance collar into wheel hub  
and insert L. bearing


\* Insert bearing so that it seals correctly, end cannot move

Standard tools:

Driver handle A 07749-0010000


Outer driver (42x47mm) 07746-0010300

Pilot (20mm) 07746-0040500



Apply grease to dust seal lip and install into right side of wheel hub  
Install right side collar into bearing  
install left side collar into bearing


\* When installing side collars take care not to chip opposite side of bearing inner race or to damage bearing



Apply grease to new O ring and install in wheel hub  
Inspect damper rubbers for wear or warpage  
If the driven sprocket has been removed apply oil to nut and tighten to standard torque


Torque: 2.8-3.4 kg-m

install driven flange into wheel hub



Install rear brake disc and tighten bolts

Torque: 3.7-4.3 kg-m




#### INSTALLATION

\* Align brake disc between pads and take care not to damage them when installing wheel

Set drive chain into sprocket  
install rear axle from the Left side and  
adjust chain ( 2.9)  
Tighten axle nut

Torque 8.0-10.0 kg-m




#### REAR CUSHION

Removal

Raise frame and remove rear wheel


remove side covers ( 15.3)  
Remove R.lower fairing ( 15.3)  
Remove conrod bolt (cushion arm side)  
Remove rear cushion lower bolt



Remove rear cushion upper bolt




Raise rear wheel and fix in place  
 Remove rear cushion downwards from  
 between exhaust chamber



REAR CUSHION

LOWER JOINT BEARING REPLACEMENT

Remove collar  
 Replace needle bearing if damaged  
 Remove dust seals from both sides  
 Remove breather tube



BREATHER TUBE


NEEDLE BEARING COLLAR DUST SEAL (BOTH SIDES)

Remove needle bearing

\* Remove taking care not to scratch  
 lower joint bearing face.

Special tool:

Needle bearing remover 07GMD-KT80100




NEEDLE BRG REMOVER

Use hydraulic press to insert new  
 bearings

\* Push into bearing mark

Standard tools

Driver Handle A	07749-0010000
Outer driver (24x26mm)	07746-0010700
Pilot (17mm)	07746-0040400



DRIVER HANDLE

PILOT

OUTER DRIVER

## SEPARATION

Install rear cushion compressor


Standard tool:

Rear cushion compressor 07GME-0010000

Special tool:

Rear cushion compressor attachment  
07959-MB10000


Pressure spring to a position where the locknut can be removed. Hold lock nut using a spanner and remove lower joint. Remove standard tool and remove seat stopper, dust sea, spring guide, lower spring seat, spring, upper spring seat and adjuster




## INSPECTION

Inspect rear cushion spring freeplay

Service limit : 128.7mm (replace if below)




Inspect rear damper shape, oil leakages, rod warpage and damper rubber damage  
Inspect rear damper for smooth movement



Push down rear damper and place a mark 10mm from damper base. Apply pressure, push down to mark using hydraulic press and measure force required

Damper pressure 24-26kg

If under 19.2kg then replace




### DAMPER UNIT GAS DRAINAGE

Because high pressure gas is inside damper unit, take care with the following point


\* Never try to increase oil or separate unit as fire or high oil, output may occur

Drill using a punch as in the picture  
Stand damper unit up and fix in position in a vice  
Drill a 3mm hole where the punch mark is to drain the gas.



Inspect upper seat, dust seal, lower seat, adjuster and spring guide for damage, wear and change in shape

### ASSEMBLY



Assemble adjuster, upper seat, spring, lower seat, dust seal, spring guide and seat stopper in damper

Push in lower joint using a rear cushion compressor and install spring

Standard tool:

Rear cushion compressor 07GME-0010000  
Rear Cushion comp. attach 07959-MB10000

Tighten locknut into damper rod

Torque: 6.0-7.5 kg-m

Tighten until lower joint meets locknut

Spring length (installed)

Standard : 124.0mm (adjuster=3rd position)





Hold lock nut and tighten lower joint

Torque: 3.8-6.0 kg-m

\* Apply locking agent to damper rod thread and assemble.

Align lower joint shoulder and seat stopper protrusion and remove rear cushion compressor from rear cushion


Apply grease to needle bearing roller  
Apply grease to new dust seal lip and install lower joint  
Install collar  
Install breather tube



## INSTALLATION


Pass the rear cushion from the bottom, between the exhaust chamber and set in the installed position

\* Set the breather tube to the rear



Install upper bolt and nut

Torque: 6.0-7.0 Kg-m




Remove rear wheel from held position  
Install rear cushion lower bolt, nut

Torque: 6.0-7.0 kg-m

Install conrod bolt and nut (cushion arm side)

Torque: 6.0-7.0 kg-m


Install R. Lower fairing ( 15.5)  
Install side covers ( 15.2)



## SUSPENSION LINKAGE

Removal

Raise frame and remove rear wheel  
Remove conrod bolt (frame & cushion arm sides) and remove cushion conrod  
Remove rear cushion lower bolt and cushion arm bolt and remove cushion arm plate.



### CUSHION CONROD BEARING REPLACEMENT

Inspect cushion conrod for damage  
Remove collar  
If needle bearing is damaged, replace with a new one  
Remove dust seal

Remove needle bearing

\* Take care not to damage; cushion conrod bearing face

Special tool:

Needle bearing remover - 07GMD-KT80100

Insert new bearing using hydraulic press




\* Insert up to the bearing mark

Standard tools:


Driver Handle A	07749-0010000
Outer driver (24x26mm)	07746-0010700
Pilot (17mm)	07746-0040400

Apply grease to needle bearing roller  
Apply grease to new dust seal lip and install cushion conrod

Install collar



GREASE DUST SEAL, NEEDLE BRG






### CUSHION ARM PLATE INSPECTION

Inspect cushion arm plate for damage and warpage

If any abnormalities then replace




Set cushion arm plate, cushion conrod into installed position

\* Face cushion arm plate (F) mark forward and install

Install bolt

Torque: 6.0-7.0 kg-m




### REAR FORK

Removal


Raise frame and unweight rear wheel  
Remove rear wheel ( 13.3)  
Remove rear fender B ( 15.8)  
Remove rear caliper from rear fork

\* Hold caliper using tape or something  
\* Do not allow caliper to hang from brake hose



Remove cushion arm bolt and rear cushion lower bolt


Remove rear fork pivot nut



Remove locknut


Special tool; Lock nut wrench 07GMA-KT70200

\* To remove lock nut, do not turn adjuster bolt, and screw in pivot bolt



Remove rear fork pivot adjuster bolt and pivot bolt together

Remove rear fork




#### PIVOT BEARING REPLACEMENT

Remove R. pivot collar

Remove dust seal

Inspect pivot collar and dust seal for damage

Inspect ball bearings for damage, noise and smooth movement



Remove chain slider from rear fork


Inspect chain slider for wear and damage

Remove dust seal

Remove L. pivot collar

Inspect dust seal and L. pivot collar for damage

Inspect needle bearings for damage



Remove circlip  
 Remove R. Pivot bearing (ball bearing)


Special tools:

Bearing remover (15mm)	07936-KC10000
- Remover assy (15mm)	07936-KC10500
- Remover shaft (15mm)	07936-KC10100
- Remover head (15mm)	07936-KC10200

-Remover sliding height 07741-0010201

BEARING REMOVER

R. PIVOT BEARING



Remove distance collar from rear fork pivot

Inspect distance collar for damage


DISTANCE COLLAR



Remove L. pivot bearing (needle bearing)

Special tool:

Driver handle	07949-3710001
Outer driver (28-30mm)	07946-1870100




Use hydraulic press and insert L. pivot bearing (needle bearing)

Special Tool

Needle bearing driver att. 07HMD-KV30100

Standard tool

Driver handle A 07749-0010000



Install distance collar

Use hydraulic press and insert R. pivot bearing (ball bearing)

Standard tool:




Outer driver (32x35mm)	07746-0010100
Pilot (15mm)	07746-0040300
Driver handle A	07749-0010000

Install circlip into groove

Apply grease to L. pivot bearing roller  
Apply grease to L. pivot dust seal lip and install  
Install L. pivot collar  
Install chain slider

Apply grease to R. pivot dust seal lip and install

Install R. pivot collar




## CUSHION ARM BEARING REPLACEMENT

Remove collar

If needle bearing is damaged then  
replace with new one

Replace ring

Remove dust seal




Remove needle bearing

\* Take care not to damage rear fork  
bearing face

Special Tool

Needle bearing remover	07GMD-KT80100
Driver shaft (B)	07964-MB00200




Use a hydraulic press to install new  
bearing

\* Insert up to bearing mark

Special tool:


Driver shaft (B)	07964-MB00200
Standard tool:	
Outer driver (24x26mm)	07746-0010700
Pilot (17mm)	07746-0040400
Driver handle A	07749-0010000



Apply grease to bearing roller


Apply grease to new dust seal lip and  
install

Install collar



## INSTALLATION


Do not insert rear fork pivot adjuster bolt as far as the pointed end will meet the frame internal face.



Install rear fork and insert pivot bolt from adjuster bolt side

Turn pivot bolt and tighten adjuster bolt

Torque: 1.0-2.0 kg-m





Install lock nut and tighten

Special Tool:  
Lock nut wrench


07GMA-KT70200

\* To tighten lock nut do not turn adjuster bolt at the same time and push in pivot bolt



Install cushion arm bolt and rear  
cushion lower bolt and tighten

Torque: Cushion arm bolt: 6.0-7.0 kg-m  
R.cushion lwr bolt: 6.0-7.0kg-m




Align rear caliper bracket protrusion  
with rear fork index mark and install

Install rear fender B ( 15.8)  
Install rear wheel ( 13.7)



# BRAKES (DISC BRAKE)





# 14. BRAKES (DISC BRAKE)

MAINTENANCE INFORMATION	14-1	FRONT MASTER CYLINDER	14-8
TROUBLE SHOOTING	14-2	REAR MASTER CYLINDER	14-11
BRAKE FLUID REPLACEMENT/ AIR BLEEDING	14-3	FRONT BRAKE CALIPER	14-14
BRAKE PADS/DISC	14-4	REAR BRAKE CALIPER	14-16
		BRAKE PEDAL	14-18

## MAINTENANCE INFORMATION

### Warnings

- When using brake fluid, ensure no water or foreign particles enter it
- Use only recommended brake fluid
- Use DOT 4 for front brake fluid and DOT 3 for rear
- Clean all dismantled parts of fluid and check each part
- Ensure foreign particles do not enter each removed part
- Brake pads may be replaced without removing hose
- If brake hose is removed, then bleed air
- Do not bend brake pipe

Item	Standard	Service limit
Brake disc width rear	3.8(4.8) - 4.2(5.2)	3.5(4.0)
Brake disc runout - front	-----	0.4
rear	-----	0.3
Front master cylinder I.D	14.000 - 14.043	14.055
Rear master cylinder I.D	12.700 - 12.743	12.755
Front master piston O.D	13.957 - 13.984	13.945
Rear master piston O.D	12.657 - 12.684	12.645
Caliper cylinder I.D	27.000 - 27.050	27.06
Caliper piston O.D	26.918 - 26.968	26.91

### TORQUES

Bleeder valve	0.4 - 0.7kg-m	Master cylinder holder bolt	1.0 - 1.4kg-m
Front caliper bracket bolt	2.4 - 3.0kg-m	Brake hose bolt	2.5 - 3.5kg-m
Hanger pin	1.5 - 2.0kg-m	R. Step stay bolt	2.4 - 3.0kg-m
Rear hanger pin retainer bolt	0.8 - 1.3kg-m	R. Brake reservoir bolt	0.7 - 1.1kg-m
Rear caliper pin bolt 10mm	2.4 - 3.0kg-m	Rear master cylinder	1.0 - 1.4kg-m
Rear caliper pinch bolt	2.0 - 2.5kg-m	Front brake pipe (apply locking agent)	1.6 - 1.8kg-m

---

TOOLS:

Special tools:

Snap ring pliers 07914-3230001

TROUBLE SHOOTING

Brake Movement Heavy

- air in brake system
- not enough brake fluid
- brake fluid leaking
- brake pads worn
- pad-to-disc face dirty

Brake Lever Heavy (Brake Pedal) or Brakes Stay On

- caliper piston fixed in
- brake system clogged
- master piston fixed on

Noise From Brakes

- pads dirty, damaged
- disc runout damaged
- caliper installation faulty
- disc or wheel alignment faulty
- pad and hanger pin lubrication incorrect

Brakes Poor On One Side


- pads dirty
- disc or wheel alignment faulty
- caliper slide fixed on

Check master cylinder brake fluid level

- \* When adjusting fluid level ensure no foreign particles enter fluid
- \* When removing rear reservoir cap remove R. side cover
- \* Use DOT 4 brake fluid for front master cylinder and DOT 3 for rear

FRONT

REAR



### BRAKE FLUID EXTRACTION/FILLING


Front

Turn handlebars to left and remove reservoir cover with vehicle in upright position


Rear

Remove side cover and remove reservoir cover  
Install bleeder valve vinyl tube

loosen caliper bleeder valve and move brake lever/pedal  
Move until brake fluid does not come out of bleeder valve




- \* Brake performance will be affected by dirt on brake disc pads
- \* If dirty then replace with new pads and clean brake disc



### AIR BLEEDING

- 3 Take care when assessin brake fluid level
- \* If fluid is nearing the lower level, then advance to the following

Tighten bleeder valve and fill brake fluid to upper level and install diaphragm



## Front

Move brake lever and drain air from separator. Move until air does not come from reservoir (until brake lever movement is heavy)



## Rear

Move brake lever until air does not come from reservoir. Install vinyl tube to caliper bleeder valve and drain into container

1] Move brake lever (brake pedal) several times and in a hold position (with push ins), turn bleeder valve roughly  $\frac{1}{2}$  turn and retighten.

\* Do not move brake lever (brake pedal) until tightening bleeder valve



2] Slowly move brake lever (brake pedal) and once moving safely then pump into position

1 & 2 should be carried out until all air is removed from bleeder valve

Tighten bleeder valve

Torque : 0.4-0.7 kg-m

After bleeding air, fill reservoir with brake fluid to upper mark




## BRAKE PADS/DISC


### Front brake Pad Replacement

\* When replacing pads do not remove brake hose.

Remove hanger pin plug and loosen hanger pin.  
Remove speedometer cable guide.  
Remove caliper bracket bolt and remove caliper bracket from front forks




In order to install new brake pads push to return piston position




Remove hanger pin from caliper and remove brake pads

\* Pull caliper bracket open to replace pads



Check that pad springs are installed correctly  
Apply silicon grease to caliper bracket pin



Install new pads to caliper

\* Always replace brake pads as a set

Push pads, align with caliper hole and install hanger pin



Install caliper to front forks

\* Take care not to damage brake pads

Tighten caliper bracket bolt:

Torque: 2.4-3.0kg-m


Tighten hanger pin:

Torque: 1.5-2.0 kg-m

Install hanger pin plug

install speedometer cable guide into  
L. front brake caliper bracket

\* After replacing pads move brake  
lever to push piston in and out



#### REAR BRAKE PAD REPLACEMENT

8 Do not remove brake hose when  
replacing pads

Remove hanger pin retainer


Remove caliper pinch bolt and remove  
caliper from rear caliper bracket

In order to install new pads push out  
caliper piston

Take hanger pin from caliper and  
remove pads



Check that pad springs are installed  
correctly




Install new pads into caliper

\* Always replace brake pads as a set

Push in pads, align pad pin and assemble with hanger pin

Apply silicon grease to caliper pinch bolt and caliper bracket pin




Install caliper to caliper bracket and tighten caliper pinch bolt

Torque: 2.0-2.5 kg-m

Assemble hanger pin retainer into hanger pin pad and tighten bolt

Torque: 0.8-1.3 kg-m


\* After replacing pads move brake pedal and push out piston



### BRAKE DISC INSPECTION

Measure brake disc width


Service Limit: Front 3.5mm (replace if below)  
Rear 4.0mm (replace if below)



Inspect front disc for movement

Use dial gauge and measure brake disc runout

Service limit: Front 0.4 mm (replace if above)  
Rear 0.3mm (replace if above)



FRONT MASTER CYLINDER

Removal

\* When working on brake fluid ensure no foreign particles enter each part  
\* In order to drain fluid, cover the hose joint

Drain brake fluid ( 14.3)  
Remove brake hose bolt and remove brake hose  
Remove wire connection from front stop light switch.  
Remove holder bolt and remove master cylinder





Remove reservoir hose  
Remove bolt and take off reservoir from master cylinder

Remove front stop light switch

Remove brake lever

Remove boot

Remove rubber cap and snap ring and take off reservoir hose joint






### Separation

Remove snap ring


Special tool : snap ring pliers

07914-3230001



Remove piston secondary cap primary cap and spring  
Clean master cylinder reservoir and master piston with brake fluid

\* Clean all removed parts with brake fluid and check each part has been cleared so air can pass through  
\* Ensure all foreign particles have been removed from parts



### Inspection

Inspect master cylinder moving parts for damage

Measure master cylinder I.D

Service limit: 14.055 (replace if above)



Inspect piston surface for damage and warpage

Inspect primary cap and secondary cap for damage

Measure master cylinder O.D

Service limit: 13.945mm (eplace if below)



## ASSEMBLY

\* Check that each part is clean before installing  
\* Replace master cylinder piston, spring cap and snap ring as a set

Apply brake fluid to piston cap and master cylinder inside





Install spring, piston cap and piston into master cylinder and hold using snap ring

Special tool: 07914-3230001  
Snap ring pliers

\* When installing primary cap, face O.D small end to the piston and install  
\* Ensure snap ring fits into groove correctly

Apply brake fluid to new O ring and install reservoir hose joint  
Install reservoir hose joint into master cylinder and hold using snap ring.  
Install rubber cap into master cylinder

Install front stop light switch  
Install boot  
Install brake lever



Install reservoir hose into reservoir hose joint and hold using clip

Install reservoir into master cylinder and tighten bolts

#### INSTALLATION

Install master cylinder onto handlebars

\* Face holder "UP" mark upwards and align holder index mark with handlebar punch mark  
\* Tighten bolt into holder top side first

Torque: 1.0-1.4kg-m

Install 2 new sealing washers and hose bolts into brake hose

Torque: 2.5-3.5 kg-m

Connect stop light switch wire into switch

Fill with brake fluid and bleed air ( 14.3)

#### REAR MASTER CYLINDER

Removal

Remove sidecover ( 15.1)

Drain brake fluid ( 14.3)

Remove brake hose bolt





Loosen master cylinder bolts first

Remove reservoir

Remove R. step stay


Remove master cylinder from Rstep stay, loosen locknut and remove pushrod/master cylinder from push rod joint.

\* Ensure no foreign particles enter brake fluid  
\* In order to protect brake fluid outflow, cover hose joint



### Separation


Remove screw and remove brake hose joint and reservoir from master cylinder



Remove boot and snap ring

Special tool: 07914-3230001


Snap ring pliers



Remove piston, piston cap and spring from master cylinder and clean master cylinder and reservoir of all brake fluid

\* Clean removed parts with brake fluid and check that air can pass through each port  
\* Remove all foreign particles from separated parts

Inspect push rod for warpage damage




### INSPECTION


Inspect master cylinder master piston movement and damage

Measure mater cylinder I.D

Service limit: 12.755mm (replace if above)



Inspect master piston for damage  
 Inspect piston cap for damage  
 Measure master piston O.D  
 Service limit: 12.645mm (replace if below)



**ASSEMBLY**

- \* Remove all foreign particles from each part
- \* Do not reuse drained brake fluid
- \* Replace master cylinder, piston, spring cap and snap ring as a set.

Apply brake fluid to piston cap and assemble piston  
 Apply brake fluid to master cylinder inside  
 Assemble spring, piston cap and piston into master cylinder  
 Apply grease to push rod piston and face

- \* To install cap do not change lip shape
- \* The spring small end faces the piston side.

Assemble push rod into master cylinder and hold using snap ring




Special tool: 07914-3230001  
 Snap ring pliers

- \* Ensure snapping is installed in groove correctly

Install boot

install new O ring into hose joint and apply brake fluid

Install joint into master cylinder



## INSTALLATION

Install lock nut to push rod and install into joint

Install master cylinder into R. step stay

Torque: 1.0-1.4 kg-m

Install stop light switch spring into brake pedal correctly and install R. step stay

\* Assemble brake pin from swingarm side  
\* Insert split pin into the brake rod as in the picture

Torque: 2.4-3.0 kg-m

Install 2 new sealing washers and hose bolts into master cylinder

Install reservoir

Torque: 0.7-1.1 kg-m

Fill with brake fluid and bleed air ( 14.3)

Install side cover ( 15.2)

Adjust rear brake pedal height ( 2.5)

## FRONT BRAKE CALIPER

### Removal





\* Ensure no foreign particles enter brake fluid  
\* Cover hose joint so that brake fluid does not flow out  
\* Clean removed parts with brake fluid and check that air can flow through each part  
\* Ensure no foreign particles enter parts

\* Do not spill brake fluid onto brake discs or brake performance will be affected. If dirty replace with new pads and clean disc

Drain brake fluid ( 14.3)

Remove plug and loosen hanger bolt  
Remove brake hose bolt and remove brake hose

Remove caliper bracket bolt and remove caliper from bracket



Ensure piston and brake fluid do not fly out and lower piston  
insert low pressure air into brake hose installed, hole and remove piston from caliper

- \* Do not use high pressure air and do not hold air gun too close
- \* Do not enter hands into caliper

Push piston seal and dust seal into cylinder to remove

- \* Take care not to damage caliper cylinder inside

Clean caliper cylinder and piston with brake fluid

#### INSPECTION

Inspect cylinder movement and damage  
Measure cylinder I.D

Service limit: 27.06mm (replace if above)

Inspect piston outside for damage

Measure O.D




Service limit: 26.91mm (replace if below)

#### ASSEMBLY

- \* Ensure all foreign particles are removed for each part.
- \* Do not reuse brake fluid
- \* When separating caliper, replace with new piston seal and dust seal

Install new piston seal and dust seal into caliper groove.  
Apply brake fluid to each seal and assemble caliper  
Assemble piston into caliper

- \* Face caliper piston groove to caliper side and install



Install pad spring into caliper  
 Apply silicon grease to boot inside  
 Install boot correctly into caliper  
 and caliper bracket groove  
 install caliper bracket  
 Install brake pads.

### INSTALLATION

install caliper into front forks

\* Take care not to damage brake pads

Tighten caliper bracket bolt  
 Torque: 2.4-3.0 kg-m

Tighten hanger pin  
 Torque: 1.5-2.0 kg-m

Install janger pin plug  
 Install 2 new sealing washers and  
 brake hose bolt and tighten brake  
 bolts  
 Torque: 2.5-3.5 kg-m

Fill with brake fluid and bleed air  
 ( 14.3)

### REAR BRAKE CALIPER





#### Removal

Drain brake fluid ( 14.3)  
 Remove brake hose bolt and brake hose  
 Remove hanger pin retainer  
 Remove caliper pinch bolt, turn caliper  
 upwards to remove disc and remove from  
 caliper bracket  
 Remove brake pads.

\* Do not spill brake fluid onot brake  
 disc. Brake performance will be  
 affected. If dirty then replace with  
 new pads and clean disc

#### Separation

Remove pad spring, pivot collar and boot  
 from caliper  
 Inspect boot and replace if damaged.





Ensure piston and brake fluid do not fly out and face piston downwards.  
insert low pressure air into brake hose hole and remove piston from caliper

- \* Do not use high pressure air and do not hold air gun too close.
- \* Do not enter hand into caliper

Push piston seal and dust seal into groove

- \* Take care not to damage caliper cylinder inside

Clean caliper cylinder and piston with brake fluid

#### INSPECTION

inspect cylinder movement and damage  
Measure cylinder I.D

Service limit : 27.06mm (replace if above)  
Inspect piston outside for damage  
Measure piston O.D



Service limit 26.91mm (replace if below)

#### ASSEMBLY

install new dust seal and piston seal inot caliper cylinder  
Apply brake fluid to each seal and assemble caliper  
Assemble piston into caliper

- \* Face caliper piston groove and shoulder to pad side and install

- \* Ensure no foreign particles enter each part
- \* Do not reused brake f;uid
- \* When separating caliper, replace piston seal and dust seal



Install pad spring

Apply silicon grease to pivot collar  
O.D and boot I.D  
Install pivot collar and boot into  
caliper

Installation

Install brake pads  
Apply silicon grease to caliper pinch  
bolt and caliper bracket pin

Install caliper to bracket, turn downwards  
and set over disc

\* take car not to damage brake pads

Tighten caliper pinchbolt  
Torque: 2.0-2.5 kg-m

Assemble hanger pin retainer and tighten  
bolt  
Torque: 0.8-1.3 kg-m

Install 2 sealing washers and brake  
hose bolts and tighten hose bolts  
Torque: 2.5-3.5 kg-m

Fill with brake fluid and bleed air  
( 14.3)





## BRAKE PEDAL

Removal


Remove side cover ( 15.1)  
Remove R. step stay

Remove stop light switch spring from  
pedal  
Remove brake hose crammer

SILICON  
GREASE PIVOT COLLAR




Remove retain spring  
 Remove cotter pin and remove brake rod  
 joint tin  
 Remove snap ring and remove brake pedal  
 from R. step stay




INSTALLATION

Apply grease to R. step stay pivot and  
 install brake pedal




Install snap ring correctly  
 Assemble brake rod joint pin correctly and  
 install new washer and cotter pins

Assemble retain spring into pedal



Install R. step stay and tighten bolts  
 Torque: 2.4-3.0kg-m

Install stop light stay spring into brake  
 pedal  
 Install brake hose crammer  
 Install side covers ( 15.2)



# 15. FAIRING, EXHAUST CHAMBER, RR FENDER, SUB FRAME

MAINTENANCE INFORMATION	15-1	SUB FRAME	15-6
SIDE COVERS	15-1	EXHAUST CHAMBER	15-7
WINDSCREEN	15-2	REAR FENDER	15-8
FAIRING	15-3		

## MAINTENANCE INFORMATION

### Warnings

\* Only adjust exhaust chamber or silencer when cold


### Torques:

- Sub frame 3.5-4.5 kg-m
- Exhaust chamber pinch bolt 2.4-3.0 kg-m
- Chamber/silencer joint bolt 1.0-1.4 kg-m
- Silencer pinch bolt 2.4-3.0 kg-m
- Fairing stau (UP) 2.4-3.0 kg-m
- Seat pinch bolt 2.0-2.4 kg-m

## SIDE COVERS

### Removal


Remove seat pinch bolts and remove seat



Use ignition key and remove tandem seat  
Remove 2 screws

Remove seat cowl hook from side covers and  
remove seat cowl

\* Take care not to damage seat cowl hook



Remove 4 pinch screws from side covers  
 Remove side cover from fuel tank  
 grommets and remove side covers backwards  
 and up to remove

\* Take care not to damage side cover


**INSTALLATION**

Set side covers in frame  
 Insert into fuel tank grommet

\* Take special care not to damage side cover when pushing into grommet

Tighten 4 screws



Install seat cowl  
 Align tandem seat stay with frame and  
 push seat until; you can hear catch  
 noise to install seat  
 Align seat stay with frame and install  
 Tighten bolts  
 Torque: 2.0-2.4 kg-m



**WINDSCREEN**

**Replacement**


Remove set pins and speed nut and remove  
 windscreen  
 Set windscreen  
 Install new set pins, speed nut and  
 windscreen




FAIRING

Lower fairing


Remove 5 quick screws  
Remove R Lower fairing from stay  
Open R lower fairing forward and remove  
from L. lower fairing hinge and remove  
R. lower fairing



Remove L. lower fairing under engine nut




Remove centre lower fairing pinch nut,  
screws and lower fairing  
Remove L. lower fairing 3 screws  
Remove L. lower fairing from stay and remove  
L. lower fairing




UPPER FAIRING

Remove back mirror pinch nut and remove  
mount rubber and back mirror together




Remove L and R front winker coupler connection  
 Remove position light wire connector  
 Remove upper fairing pinch bolt



L. WINKER COUPLER, POSITION LIGHT WIRE CONNECTOR


Remove 3 screws, 3 fairing screws and fairing nut and pull out fairing from the front



QUICK SCREWS

NUT

Remove headlight coupler  
 Remove speedometer cable and grommet from the upper fairing and remove upper fairing




HEADLIGHT COUPLER

GROMMET

SPEEDOMETER CABLE

INSTALLATION

Reverse upper fairing and lower fairing removal process to install






## SUB FRAME

### Removal

Remove the following, then remove the subframe

- Side covers ( 15.1)
- Fuel tank ( 4.2)
- Battery ( 16.3)
- Control unit ( 19.6)
- Tailight rear winker coupler and harness clamp
- Rear fender A
- Rear brake resevoir
- Air cleaner case pinch bolt
- AC Generator coupler ( 10.2)
- Pulse generator coupler ( 10.2)
- Regulator/rectifer ( 16.5)
- Silencer pinch bolt



### Installation


Reverse removal process to install

## EXHAUST CHAMBER

### Removal

Remove lower fairing ( 15.2)  
Remove rear cylinder exhaust chamber joint nut, pinch bolt and silencer pinch bolt  
Remove rear cylinder exhaust chamber

In the same way, remove the front cylinder exhaust chamber




### Removal

Inspect spring seat B for wear  
If any abnormalities, htne replace exhaust chamber. Replace spring seat A with a new one  
After cleaning spring seat A,B assemble facein the muffler, then install


When installing, tighten the following bolts, nuts.

- cylinder and muffler pinch bolts
- muffler body pinch bolt
- silencer muffler pinch bolt

\*After cleaning all removed parts, then reinstall



### SPRING SEAT B




### Torques:

Exhaust Chamber pinch bolt	2.4-3.0 kg-m
Silencer pinch bolt	2.4-3.0 kg-m

## SILENCER REPLACEMENT

Remove silencer pinch bolt  
Remove 3 silencer joint bolts and remove silencer from exhaust chamber




Install new gasket

Reverse silencer removal procedure to install

Torques:


silencer pinch bolt      2.4-3.0 kg-m  
Chamber/silencer joint bolt      1.0-1.4 kg-m



## REAR FENDER


Removal

Remove side covers ( 15.1)  
Raise frame and unweight rear wheel  
Remove rear cushion upper bolt ( 13.7)




Remove rear fender 4 bolts

Tilt rear fender to left and pull back to remove





Installation

Reverse removal procedure to install



# BATTERY, CHARGING SYSTEM

## WIRING MAP



# 16. BATTERY, CHARGING SYSTEM

WIRING MAP	16-0	BATTERY	16-3
MAINTENANCE INFORMATION	16-1	REGULATOR/RECTIFIER	16-4
TROUBLESHOOTING	16-2	AC GENERATOR INSPECTION	16-5

## MAINTENANCE INFORMATION

### Warnings

\* A special regulator rectifier is used on this machine. Do not use regulator/rectifiers from a different machine. If a different regulator/rectifier is used the CDI unit will be damaged.

- Connect each lead to a lead of the same colour. If connected to an incorrect lead trace the correct one and connect. Before disconnecting check all lead colours
- Connect couplers of the same colours
- AC generator removal (section 10)
- Refer to 1.28 for the total system troubleshooting section

### Maintenace free battery:

- Fluid level inspection is not necessary. No need to adjust fluid levels
- When charging battery, remove battery from frame, but do not remove fluid caps
- Do not use 'quick charging' for battery unless an emergency
- Always charge battery for the standard time and charging level
- Always use a digital circuit tester to inspect charging performance
- When replacing battery, do not use an uncompatable battery

BATTERY	Capacity	12V 3 AH
	Electric Current	0.4A
	Open voltage	13.0-13.2V (20°C)
Start of charging revolutions (headlight-lowbeam) under		1.050rpm
REGULATOR/RECTICIFER	Type	Silister
	Voltage stop	13.5-15.5V
AC GENERATOR COIL RESISTANCE		0.2-0.9Ω
AC GENERATOR OUTPUT		180W/5.000rpm

### TOOLS

Gauges	
Digital Circuit Tester ( Showa)	07411-0020000
Circuit Tester (Sanwa)	07308-0020000
(Showa)	TH-5H

---

## TROUBLESHOOTING

### No Electrics (with mainswitch "ON")

- battery losing voltage
  - leaking
  - regulator/rectifier faulty
  - AC generator faulty
- battery cord connection cut
- fuse cut (inspect main fuse)
- main switch faulty
- coupler connection faulty or shorting

### Charging System Faulty

- connector or coupler connection faulty, misrouted or showing
  - between AC Generator and regulator/rectifier (Y)
  - between regulator/rectifier & battery (R)
  - between regulator/rectifier & earth (G)
- regulator/rectifier faulty
- AC generator faulty

### Voltage Low

- battery charging faulty or losing charge
- regulator/rectifier faulty
- AC generator faulty

### Electric Current Faulty

- battery cord connector faulty
- charging system connection faulty
- ignition system connection faulty or showing

## BATTERY

### Battery removal

Remove seat and open battery cover  
Remove cables from terminals

\* Remove negative first then positive terminal

Remove battery  
install in reverse procedure to removal

\* After installing battery apply a small amount of grease to terminals

### Charging System Inspection

Measure battery voltage

Safe Charge : 13.0 - 13.2V (20°C)  
Faulty charge : under 12.3V (20°C)

\* Always use circuit tester to inspect charging system.  
Terminal circuit tester: 07411-0020000  
\* Connect voltage gauge positive cord to battery positive terminal and negative cord to negative terminal

## CHARGING




Connecting method:

Charger positive - battery positive  
Charger negative - battery negative

\* Always switch charger switch on and off using ON and OFF switch. If performed using connector it may cause sparks to jump  
\* Always charge using recommended current and time

\* If recommended charge or time is exceeded battery performance will be affected, so follow the recommendations below

Charge current	Std	0.4A
	Quick Charge	4.0A
Charge Time	Std	
	Quick Time	30.
Charge Open Voltage		12.8 (above)



## LEAK TEST

Turn main switch OFF, disconnect regulator/rectifier coupler, remove negative terminal from battery and install voltage gauge between negative terminal and battery earth cable

If no voltage it is abnormal

\* Connect voltage gauge negative cord to battery negative terminal and positive cord to negative cable

If leaking check for shorts in wire harness and coupler and inspect main switch for abnormalilites ( 18.6). If abnormal measure regulator/rectifier controlled voltage ( 16.4)

## REGULATOR/RECTIFIER

\* refer to ( 1.28) and inspect each step

### Controlled Voltage Inspection

Warm engine  
Stop engine and remove seat  
Set voltage gauge between battery terminals and start engine

\* Raise engine revolutions and inspect for the holding of charge  
voltage = 13.5-15.5V/5000rpm

### Replacement


\* Only use specified regulator/rectifier  
Use of an unspecified regulator/rect. will result in damage to CDI unit

remove side covers ( 15.1)  
Remove coupler connection

Remove regulator/rectifier pinch nut and remove regulator/rectifier

install in reverse proceedure to removal

\* Connect each coupler correctly





---


## AC GENERATOR INSPECTION

Remove side covers  
Remove AC generator 3P coupler connection  
and measure resistance between yellow wires  
of AC generator

Resistance: 0.2-0.9 ohm (20°C)

Check for no lead through each wire and earth



If resistance is not normal or there is lead  
through wires an earth then replace AC  
generator



\* This measurement can be performed with AC  
generator installed in engine

# IGNITION SYSTEM

## WIRING MAP



# 17. IGNITION SYSTEM

WIRING MAP	17-0	CDI UNIT INSPECTION	17-3
MAINTENANCE INFORMATION	17-1	IGNITION COIL	17-4
TROUBLE SHOOTING	17-2	PULSE GENERATOR	17-5

## MAINTENANCE INFORMATION

### Warnings:

- A CDI ignition system is used so adjustments are not necessary. Use a DC-DC1 battery
- Inspect ignition timing ( 2.11)
- Inspect spark plug ( 2.11)
- Check that each lead is connected to the same colour. Always align correct colours and connect each connector to nearest coloured tube. Before removing wires, check colours
- Measure distance for large and small variations
- Refer to ( 1.29 for total system trouble shooting

SPARK PLU	NGK	ND
	B8ECS, B9ECS. B10ECS B8ES, B9ES	W24ES-C, W27ES-C, W31ES-C W24ES-U, W27ES-U
Spark plug gap	0.7-0.8mm	
Ignition timing "F"	15° ± 2° BTDC/1,200rpm	
Advanced opening revolutions	15° ± 2° BTDC/2,700rpm	
Advanced closing revolutions	25° ± 2° BTDC/4,000rpm	
Retarded opening revolutions	24° ± 2° BTDC/7,000rpm	
Retarded closing revolutions	4° ± 3° BTDC/10,850rpm	
Ignition coil resistance Primary coil	0.1-0.2Ω	
	Secondary coil - plug cap ON	
	- plug cap OFF	
Pulse generator coil resistance 20°C	5-13kΩ 3.6-4.6kΩ 180-220Ω	

### TOOLS

Gauges

Digital Circuit tester (Showa)

Circuit tester (Sanwa)

(showa)

07411-0020000

07308-0020000

TH-5H

## TROUBLE SHOOTING

### Does Not Fire All Plugs

- Kill switch OFF
- Kill switch faulty
- Main switch faulty
- Pulse generator faulty
- CDI unit faulty
- Sub fuse blown (10A)
- Wire connection faulty, incorrect routed, shorting
  - battery to main fuse (20A) (R)
  - main fuse (20A) to main switch (R)
  - main switch to sub fuse (R/B1)
  - sub fuse to kill switch (B1)
  - Kill switch to CDI unit (B1/W)
  - Ign, switch to CDI unit (B1/Bu, B1/Y)
  - CDI unit to earth (G)
  - Pulse generator to CDI Unit (W/Bu, Bu, W/Y, Y)

### Plug Not Firing

- Plug faulty
- Plug cap faulty
- High tension cord faulty
- CDI unit to ign. coil wire misrouted, connector faulty or shorting
- Kill switch to CDI unit (B1/W) wire misrouted, connector faulty or shorting

### Revolutions Imbalanced


- Ignition Primary Circuit
  - Ign. coil faulty
  - Kill switch faulty
  - Main switch faulty
  - Battery charging faulty
  - CDI unit faulty
  - Pulse generator faulty
  - Pulse rotor faulty
- Ignition Secondary Circuit
  - Plug faulty
  - High tension cord faulty
  - plug cap leak
  - Ign. coil faulty
  - CDI unit faulty
  - Pulse generator faulty

### Advanced Or Retarded Faulty

- Pulse generator faulty
- CDI unit faulty

## CDI UNIT INSPECTION

Refer to ( 1.29) for troubleshooting



CDI UNIT COUPLER

Remove CDI unit fuel tank ( 4.2) and coupler holder, remove coupler terminal and perform the following inspection

			Std (20°C)
	No.1 CDI	No.2 CDI	
Ign. coil primary coil resistance	Bl/Y to G	Bl/Bu to G	0.1-0.2Ω
Ign. coil Sec. coil resistance	G to high tension cord		5k-13kΩ cap on
Pulse generator coil resistance	W/Bl to Y	W/Bu to Bu	180-220Ω
Main switch -kill switch	Bl/W(+) to G (-)		Battery voltage present
CDI unit voltage	Main switch	"ON".	
	Kill switch	"RUN"	

If inspection valves are abnormal, inspect/replace the following

- Ignition coil inspection/replacement ( 17.4)

- Pulse generator inspection ( 17.5)

If any further abnormalities then replace the CDI unit



CDI UNIT (REAR)

CDI UNIT (FRONT)

## IGNITION COIL

Ignition coil inspection

Remove ignition coil

Measure resistance of primary ignition coil between terminals

Standard: 0.1-0.2 ohm (20°C)



Measure ignition coil secondary resistance between high tension cord (plug cap on) and green terminal

Standard: 5 - 13 K ohms (cap on/20°C)



If the measured value is outside that of the standard value remove plug cap from high tension cord and measure secondary resistance

Standard: 3.6-4.6 K ohms (No cap/20°C)

If the measured value is within that of the standard value, inspect plug cap, if necessary then replace. If outside the standard value, then replace ignition coil



## IGNITION COIL REPLACEMENT

Ignition coil (rear)


Remove fuel tank ( 4.2)

Ignition coil (Front)

Remove R. lower fairing ( 15.3)

Remove connector from primary terminal and remove plug cap from plug

Remove ignition coil from installed stay



\* Install connector correctly to primary terminal

Rear Coil = green-green wire  
black-black/yellow wire

Front coil = green-green wire  
black-black/blue wire

Install plug cap to new ignition coil and install coil to stay.  
Install plug cap to plug

Ignition coil (rear)

Install fuel tank ( 4.2)

Ignition coil (front)

Install R. Lower fairing ( 15.5)

#### PULSE GENERATOR

Inspection

Remove side cover ( 15.1)



Remove pulse generator coupler and measure resistance W/Y-Y (rear pulse generator coil)

and W/Bu-Bu (front pulse generator coil)

Standard + 180-220 ohms (20°C)

Replace pulse generator ( 10.2)

IGNITION COIL (FRONT)



PULSE GENERATOR COUPLER

# 18. LIGHTS, METERS, SWITCHES

MAINTENANCE INFORMATION	18-1	HANDLE BAR SWITCHES	18-7
TROUBLE SHOOTING	18-1	OIL WARNING SYSTEM	18-8
HEADLIGHT	18-2	TEMPERATURE GAUGE	18-9
WINKER	18-3	TACHOMETER	18-9
BRAKE/TAILLIGHT	18-3	NEUTRAL SWITCH	18-10
METER	18-3	BRAKE LIGHT SWITCH	18-10
MAIN SWITCH	18-6	HORN	18-10

## MAINTENANCE INFORMATION

### Warnings

- Route each lead to the same colours. Always realign incorrectly matched wires and attach to the nearest connector. Before removing wires, note each leads colour
- Connect couplers to those of the same colours
- Perform switch current test while installed in machine
- Take care with connector couplers and align lock hook correctly

Headlight bulb	12V60/55W
Position bulb	12V3.4W
Winker bulb	12V23W × 4
Stop/tail light bulb	12V23/8W × 2
Pilot lamp	12V3.0W × 5
Meter lamp	12V3.4W × 4
Speed warning light	12V3.0W
Main fuse	20A
Winkers, brake light, horn, passing switch sub fuse	15A
Sub fuse(winkers,brake light, horn, passing switch sub fuse)	10A × 4

### Torque:

Main switch 2.4-3.0 kg-m

### Trouble Shooting

#### Lights Do Not Shine

- bulb blown
- switch faulty
- wire misrouted
- fuse blown  
(inspect upper fairing inner sub fuse and main fuse)
- battery charging
- routing faulty

#### Lights Do Not Work

- battery charging
- Bulb faulty

#### Can Not Change Headlight Hi-Lo

- Bulb faulty
- Dimmer switch faulty
- Routing faulty




## HEADLIGHT

### Bulb Replacement

Remove meters ( 18.3)


Remove headlight coupler and remove dust cover



Remove clip and replace bulb


\* Bulb may be damaged by cleaning or handling

Install clip  
Face "TOP" mark to the top and install dust cover  
Connect headlight coupler and check lighting performance




### Removal

Remove upper fairing ( 15.3)  
Remove 4 screws and remove headlight bracket



Remove 2 screws and remove headlight case from bracket

HEADLIGHT




### Installation

Install in reverse procedure to removal

\* After installing headlight case, adjust headlight ( 2.16)


## WINKERS

Turn bulb socket, separate bulb socket lock and remove bulb socket and bulb from winker  
If necessary remove screws and replace winker lens.  
Install new bulb in bulb socket and install in reverse procedure to removal




## BRAKE/TAILLIGHT

Remove side covers ( 15.1)  
Remove brake/tailight lens




Replace bulb  
install lens  
Install side covers ( 15.2)




## METERS

Removal  
Remove meter coupler and connector




Remove meter pinch bolt, nut




Remove speedometer cable

Remove meter




#### BULB REPLACEMENT

Remove pilot light case cover




Remove bulb socket and replace bulb

Install cover



Pull bulbsocket out of meter and replace bulb


BULB SOCKET      BULB



SEPARATION

Remove screws and nuts and separate meter

TACHOMETER      SPEEDOMETER



ASSEMBLY/INSTALLATION


perform in reverse procedure to removal/separation

TEMP GAUGE

DRIVE METER KNOB

When assembling motor, align colour codes and wire colours

- B Black      W:White
- BR:Brown    y: Yellow
- L :Blue      G: Green




**MAIN SWITCH**

**Inspection**

Remove main switch 6P coupler from fuel tank lower coupler holder

○—○ If current, then okay


	BAT1	IGN	TL1	TL2	PA
	R	R/Bl	Br/W	Br	Y/Bl
ON	○—○	○—○	○—○	○—○	
OFF					
P	○				○
LOCK					



MAIN SWITCH


**Removal**

Remove main switch 6P coupler from fuel tank lower coupler holder



MAIN SWITCH 6P COUPLE

Remove main switch 2 bolts and remove main switch




MAIN SWITCH

BOLT

**Separation**

Cut bands remove 3 screws and remove switch from switch cylinder



BANDS

SWITCH

**ASSEMBLY**

Align cylinder shaft with switch hole and install  
 Install 3 screws and clamp with band  
 Cut band excess  
 After assembly inspect switch current  
 ( 18.6)

**INSTALLATION**

In reverse order to removal

Handle switch

Remove fuel tank coupler holder 9P mini coupler (Bl and R) and connector

\* After install ing check switch movement

○—○ If current then okay

**KILL SWITCH**

	IG	BAT6
	Bl/W	Bl
OFF		
RUN	○—○	○—○

**LIGHTING SWITCH**

	BAT5	TL	BAT4	HL
	Br/Bu	Br/W	Bl/R	Bu/W
P	○—○	○—○		
(N)	○—○	○—○	○—○	○—○
H	○—○	○—○	○—○	○—○

**PASSING SWITCH**

	BAT3	Hi
	W/G	Bu
FREE		
PUSH	○—○	○—○

**HORN SWITCH**





	BAT3	Ho
	W/G	Lg
FREE		
PUSH	○—○	○—○

**DIMMER SWITCH**

	HL	Lo	Hi
	Bu/W	W	Bu
Lo	○—○	○—○	
(N)	○—○	○—○	○—○
Hi	○—○		○—○

**WINKER SWITCH**

	W	R	L
	Gr	Lb	O
R	○—○	○—○	
N			
L	○—○		○—○



## OIL WARNING SYSTEM

Oil warning light inspection

Remove fuel tank ( 4.2)

Remove R Lower fairing ( 15.3)

Remove oil tank installed bolt and move oil tank backwards. Remove oil level switch coupler and measure voltage between Br/Bu (+) and Green (-). If voltage with main switch on then okay Short the coupler Br/Bu and G/R terminals and if the light glows with the main switch on, then okay. If it does not glow then either the bulb has blown; connector faulty or harness misrouted

Remove unit holder and pull unit from oil tank

Remove stopper and remove front case

Connect coupler and turn main switch ON

\* Turn on wipers and check battery then perform next inspection

Move oil level switch up and down and insoect if light goes on and off  
If abnormal then replace switch

## OIL LEVEL SWITCH INSPECTION





Lower float down safely and measure resistance

G/R - Br/Bu 5-20 ohm

G - Br/Bu infinity

Raise float up safely and measure resistance of G/R and Br/Bu

G/R - Br/Bu 320 - 350 ohm



## TEMPERATURE GAUGE



\* Before inspecting thermosensor check radiator fluid level and cooling system for air internally

Remove R lower fairing ( 15.3)  
Remove thermosensor connector from thermostat case

Use jumper cord and earth connector  
Turn main switch ON and check if temperature gauge needle reaches H mark in one movement

\* Do not earth thermosensor wire for more than 5 seconds or temperature gauge will be damaged

If abnormal check wire harness and if normal replace temperature gauge ( 18.5)



TEMP GAUGE

## TACHOMETER

If tachometer does not move correctly perform the following inspection  
Check that spark jumps on rear cylinder. If it jumps inspect the following

Turn main switch ON and measure voltage between meter coupler (9P mini W) Br/Bu and earth  
If no voltage between Br/Bu and earth inspect wire harness routing and sub fuse (10A)

Remove fuel tank ( 4.2)

Remove meters ( 18.3)

Remove rear cylinder CDI unit coupler  
Check for current between fairing side Bl/Y connector and CDI unit coupler  
Bl/Y cord


If current check meters sub harness Bl/Y cord routing and connector quality.  
If normal replace tachometer





## NEUTRAL SWITCH

Remove fuel tank ( 4.2)  
Remove neutral switch connector and  
inspect between Lg/R wire and earth for  
current




## BRAKE LIGHT SWITCH

Front

Remove brake light switch connector  
Without moving brake lever inspect for  
current


Pulling lever - current  
Not Pulling Lever - No current



Rear


remove seat and remove rear brake light  
switch coupler. Without moving brake  
pedal inspect for current

Pushing Pedal - current  
Not Pushing Pedal - No current




## HORN

Remove wire from horn  
Connect 12V battery to horn and if  
noise then okay




# CONTROL UNIT, SERVO MOTOR, OIL PUMP SOLENOID

## WIRING MAP



## FRONT CYLINDER CDI UNIT



# 19.

WIRING MAP	19-0	OIL PUMP SOLENOID	19-4
MAINTENANCE INFORMATION	19-1	WIRE HARNESS INSPECTION	19-5
TROUBLE SHOOTING	19-1	CONTROL UNIT	19-6
SERVO MOTOR	19-2		

## MAINTENANCE INFORMATION

### Warnings

- Route all corde to those of the same colour. Misrouted cords should be realized and connect to nearest connector. Before removing wiring take note of cord colours. Connect couplers to those of the same colour
- When inspecting using battery take extreme care not to short battery
- If the oil pump solenoid is poor quality the replace oil pump assembly
- If the servo motor or throttle sensor are poor quality, then replace as servo motor assembly

	Standard
Oil pump solenoid resistance <sup>(20°C)</sup>	3.0-5.0Ω

## TROUBLE SHOOTING

### RC Valve Does Not Move ( 1.30)

- throttle sensor faulty
- Wire harness, coupler or connector misrouted or shorting
- ignition system faulty (Section 17)
- Control unit faulty
- Sub fuse blown

### At Low Revolutions, Lots Of Exhaust Gas

- Oil pump solenoid faulty
- Ignition system faulty (Section 17)
- Wire harness, coupler, connector misrouted or shorting
- Control unit faulty

SERVO MOTOR

RC Valve Movement Inspection

Remove R. Lower fairing ( 15.3)  
 Start engine, slowly raise revolutions to around 2000rpm whereby the cylinder pulley should move clockwise to a stop and at 3000rpm it should move anti-clockwise to a stop

Check:

- (1) roughly 2000rpm pulley movement
- (2) roughly 3000rpm pulley movement

SERVO MOTOR INSPECTION

Remove fuel tank ( 4.2)  
 inspect servo motor control cable connection for damage.  
 Remove R lower fairing ( 15.3)  
 Remove servo motor coupler and connector  
 If any movement in connectors then correct





Remove control cable connector from cylinder pulley ( 19.3)  
 Connect fuel tube to fuel cock and start engine  
 Raise engine revs slowly and inspect that at roughly 2000rpm the oulley shoulder reaches the HI mark and at roughly 3000rpm it reaches the LO mark  
 If it moves incorrectly inspect cable and bulb for carbon sticking

Remove screw and remove servo motor pulley  
 When the battery is connected to the servo motor coupler W/B1 terminal and W/R terminal inspect if the motor moves the opposite way

Also measure the resistance of the servo motor coupler G/Bu terminal and servo motor connector (Lg) when the motor is turning and inspect that the tester needle moves 0-5 K ohm -00


**\* Do not short battery**

Turn motor over and if the tester needle waves between 0-5 K ohm - 00 then the servo motor is okay  
 If the motor does not turn over and the tester needle does not move the replace servo motor




SERVO MOTOR REPLACEMENT


Remove fuel tank ( 4.2)  
Remove R. Lower fairing ( 15.3)  
Remove control cable connection from  
cylinder pulley




Remove servo motor coupler (4P mini,W)  
connector  
Remove servo motor pinch bolt and replace  
servo motor




Fully open cylinder pulley RC Valve and  
hold with knock pin



Connect fuel tube to fuel cock and start  
the engine. Rev engine slowly and at  
roughly 2000rpm check that servo motor  
shoulder stops at HI position and turn main  
switch off to stop engine



Connect control cable to servo motor pulley  
 Connect control cable to cylinder pulley  
 Adjust control cable ( 2.17)  
 Install fuel tank ( 4.2)  
 Install R lower fairing ( 15.5)




#### OIL PUMP SOLENOID

Inspection:

Remove fuel tank ( 4.2)  
 Remove R lower fairing ( 15.3)

Remove oil pump solenoid coupler connection

Measure resistance at coupler  
 Br/Bu-Peach box - std (20°C) = 3.0-5.0 ohm




Connect solenoid coupler Br/Bu box to positive and peach box to negative of 12 volt battery

\* Do not shorth battery  
 \* Do not connect battery for more then one minute

If there is no "clunk" sound from solenoid then replace oil pump assy

Oil pump replacement ( 3.3)


If there is a sound then advance to next inspection



Turn main switch "ON"  
 Measure voltage between solenoid harness coupler (2P mini,W) earth Br/Bu box

Battery voltage (above 10V) - inspect wire harness

No battery voltage (under 10V) - battery charging faulty, wire harness, coupler short, connection faulty, fuse faulty



## WIRE HARNESS INSPECTION

Inspect servo motor and oil pump solenoid.  
If any abnormalities then conduct the following inspection:

Inspect ignition system ( section 17)

Remove side covers ( 15.1)

Turn main switch on and inspect if there is voltage between control unit coupler BR/Bu-G

If no battery voltage inspect main switch battery, fuses, wire harness and couplers

If voltage inspect current between control unit connector (Bl/Bu) and cylinder CDI unit coupler Bl/Bu

If no current correct wire harness or replace

If current inspect for current of wire harness from control unit to oil pump solenoid and servo motor

If no current, then correct wire harness or replace

If current then replace control unit

## CONTROL UNIT

\* If servo motor does not work or oil pump solenoid does not work, do not replace control unit first. If the servo motor or solenoid is shorting it will cause damaged to control unit

Inspect servo motor, oil pump solenoid and wire harness, if no abnormalities but servo motor or oil pump solenoid does not move then replace control unit.




## REPLACEMENT

Remove side covers ( 15.1)

Remove control unit coupler and connectors

Pull out control unit from rear fender A shoulder and replace it.

Install side covers ( 15.2)



# 20. NSR250R(J)

---

- 20-2 TECHNICAL FEATURES
- 20-3 TRANSMISSION, SPARK PLUGS, PGM CDI, CARBURETTION
- 20-6 SPECIFICATIONS
- 20-8 TOOLS
- 20-9 WIRING MAP
- 20-11 CABLE ROUTING
- 20-15 TROUBLE SHOOTING
- 20-23 MAINTENANCE SCHEDULE
- 20-27 MAINTENANCE, FRONT BRAKE
- 20-28 IGNITION TIMING
- 20-28 AIR CLEANER, CHOKE
- 20-28 LIGHTING, SIDE STAND, RC VALVE ADJUSTMENT
- 20-30 AIR CLEANER
- 20-30 CARBURETTOR
- 20-34 ENGINE REMOVAL INSTALLATION
- 20-36 OIL STRAINER, GEAR CHANGE
- 20-38 CASSETTE TRANSMISSION
- 20-43 SPEEDO DRIVE
- 20-44 FRONT FORK, WHEEL, STTERING
- 20-47 REAR WHEEL, SUSPENSION
- 20-51 BRAKES
- 20-57 REAR SUBFRAME
- 20-58 CHARGING SYSTEM
- 20-59 IGNITION SYSTEM
- 20-61 LIGHTING SYSTEM, INSTRUMENTS
- 20-65 PGM IGNITION SYSTEM
- 20-68 EVEN MORE PGM IGNITION SYSTEM




# NSR250R

# SPECIAL FEATURES


Make	Honda MC18	
Length	1.985m	
Width	0.640m	
Height	1.105m	
Wheel Base	1.355m	
Engine Type	MC16E	
Eng. Capacity	249cm <sup>3</sup>	
Motive Power	Petrol	
Vehicle Weight	FRT	72kg
	Rr	73kg
	TTL	145kg
Rider No.	2	
Gross Weight	Frt	89kg
	Rr	166kg
Weight	TTL	255kg
Tires	Frt	110/70-17 53H
	RR	140/60R18 64H
Ground Clearance	0.135m	
Braking Distance (50K/H)	14.0m (50)	
Turning Circle	2.9m	
Starting	Kickstart	
Fuel	Petrol 2 Cycle	
Cyl. Configuration	V 2	
Com. Type	Half Ball	
Bore X Stroke	54.0 × 54.5mm	
Comp. ratio	7.3	
Cyl. Comp	10.0kg/cm <sup>2</sup> - 400rpm	
Max H.P.	45PS 9500rpm	
Torque	3.8kgm/ 8000rpm	
Port Timing	Open Movement	Auto
	Close Movement	Auto
Intake	Open	76°-95° (BBDC)
	Close	76°-95° (ABDC)
Exhaust	Open	62° BBDC
	Close	62° ABDC
Idle Speed	1200rpm	
Lubrication	Forced pressure wet sump	
Oil Pump	Plunge type Tricoid type	
Oil Capacity	*2.1ℓ	

Cooling system	Water Cooled	
Air Cleaner type	Foam	
Fuel Tank Cap	16	
	Type	TA20
Gas Intake	32mm	
Venturi Bore	32mm	
Type	CDI	
Ign Timing	15° BTDC 1200rpm	
Spark Plug	NGK	BR9ECM, BR10ECM
	ND	W27EMR-C, W31EMR-C
Plug Gap	0.7-0.8mm	
Battery	12V 3AH	
Clutch type operation	Wet Coil Spring	
	Manual	
Primary Reduction	2.360	
Trans- type	Usual Method	
	1st Gear	2.846
2nd Gear	1.941	
3rd Gear	1.500	
4th Gear	1.272	
5th Gear	1.136	
6th Gear	1.045	
Reduction Method	Chain	
	Final	2.733
Frt Wheel - Caster	24°	
	Trail	90mm
Tire Pressures	Frt	2.25kg/cm <sup>2</sup>
	RR	2.50kg/cm <sup>2</sup>
Strg Angle	Lft	30°
	Rt	30°
Brakes	Frt	Pressurised Disc
	RR	Pressurised Disc
Suspension	Frt	Telescopic
	RR	Swing Arm
Frame Type	Diamond	
Frame NO.	MC18-1000020~	
Engine NO.	MC16E-1031032~	
* Transmission Oil	0.8ℓ	
Engine Oil	1.3ℓ	

CASSETTE TRANSMISSION



ALL NEW, SHORT BODY SPARK PLUG



# NSR250R(J)

## SPECIAL FEATURES


### Engine Control Unit.

The PGM-CDI unit and RC valve unit are related to the engine control unit. The engine control unit is composed of a PGM control unit and CDI convertor

PGM Control unit does: PGM-CDI 2 ignition timing adjustment  
PGM-Carburettor 2 air/fuel mixture adjustment  
PGM-RC Valve RC valve adjustment  
Oil pump solenoid Oil outflow characteristic adjustment

### Performance:

The engine control unit is divided into the PGM control section and the CDI convertor. In the CPU program map the pulse signaling from the No.1 & 2 pulse generator is in accordance with the engine revolutions, enters voltage from the throttle sensor in accordance with the throttle opening. The program does, the ignition timing demanded




by the engine from the enforced valve, the air/fuel mixture, exhaust port timing, oil outflow capacity measurement and predicts the various circumstances from low revolutions to high revolutions which give good fuel performance


PGM-CARBURETTOR

Carburettor Air Jet Control System.

The air mixture (ideal) & air mixture supplied to the engine are shown respectively on the graph. In this system the carb supplies the air mixture and in order to supply close to the air mixture demanded by the engine, send air into the carb air jet. The PGM carb not only supplements the air jet and solenoid valve but also make fine control possible. The PGM control according to the input power from the engine revs (pulse Generator), throttle opening (throttle sensor) is produced by separate solenoid valves and adjusts the input volume of air from the sub air cleaner to the main air bleed



When the air mixture supplied to the carb is too rich, (oblique line on graph) the solenoid is turned ON and according to the air input increase to the air bleed the air mixture is diluted & the engine nears the ideal air/fuel mixture demanded by the engine. The PGM-carburettor as for engine revolutions makes it such that it can control the correct air mixture with the throttle opening from low revolutions to high revolutions and improves drivability over all rev. ranges



NSR250R(J)

	mm	kg-m
1	20	8.0 - 9.0
1	10	7.0 - 9.0
1	10	1.5 - 2.5
1	6	0.8 - 1.2
1	6	0.6 - 0.8

	mm	kg-m
4	8	1.8 - 2.5
4	7	1.5 - 2.0
1	18	9.0 - 11.0
1	20	1.0 - 2.0
1	20	6.0 - 7.0
4	6	1.0 - 1.4
4	8	2.4 - 3.0
8	8	3.0 - 3.5
12	6	1.4 - 1.6
5	10	5.0 - 6.0
3	10	1.5 - 2.0
3	10	0.2 - 0.3
2	10	1.2 - 1.5
2	10	2.5 - 3.5
4	10	4.5 - 5.5
1	54	8.0 - 10.0
1	5	0.35 - 0.5
2	10	3.5 - 4.5
3	10	3.5 - 4.5
1	12	5.0 - 6.0

32mm	
TA20A	
No.1 #130	No.2 #132
No.1 BPD	No.2 BPE
No.1 # 75	No.2 # 70
2 - 3.8	

# NSR250R(J)

			: mm
		0.30—0.45	0.50
		0.30—0.45	0.50
		10±2kg/cm <sup>2</sup>	—

			: mm
		36.0	35.0
		20.020—20.041	20.07
		22.959—22.980	22.92
		23.000—23.021	23.05

			: mm
		—	0.2
		0.02—0.07	0.12
		0.10—0.15	0.2
		24.987—24.993	24.95

			: mm
		0.54—0.76	0.85

			: mm
		15.4—20.0kg	12.3kg
		160.3	—
		172.3	168.9

			: mm
	A	25.400—25.450	25.46
	B	30.230—30.280	30.29
		38.180—38.230	38.24
	A	25.318—25.368	25.31
	B	30.148—30.198	30.14
		38.115—38.148	38.105
		14.000—14.043	14.055
		13.957—13.984	13.945

			: mm
		429cc	—
		128mm	—
		267.2mm	261.9mm


**NSR250R(J)**

	NGK	ND
	BR 9ECM	W27EMR-C
	BR10ECM	W31EMR-C

	12V1.7W
	12V15W×4
	12V18/5W×2
	12V1.7W×4
	12V1.7W×5
	10A×2, 15A×1


07JMB - KV30100	
07946 - KM90001	
07946 - KM90401	
07508 - 0014400	PGM CDI
07947 - KA50100	
07947 - KF00100	

07746 - 0010400	
07746 - 0041000	
07746 - 0040600	
07746 - 0030100	
07746 - 0050600	
07703 - 0010100	
07707 - 0020500	




0030Z KW3 7010











0030Z--KW3--7010

WIRING MAP




NSR250R(J)







NSR250R(J)




TROUBLE SHOOTING







POOR ADJUSTMENT TO ENGINE - NO POWER







AT LOW REVS, LOTS OF EXHAUST NOISE




## NO SPARK FROM SPARK PLUG

If there is no spark, conduct spark test on ignition coil. Measure the ignition coils primary voltage. If there is difficulty with the coil but still normal spark, the ignition coil has been faulty from beginning


PERFORMANCE PROBLEM	CHECK THE FOLLOWING POSSIBLE CAUSES FROM 1.
PEAK VOLTAGE IS LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. TESTING SAMPLING TIME CONSEQUENCES</li> <li>3. IGNITION WIRING CUT, POOR CONTACT</li> <li>4. IGNITION COIL FAULTY</li> <li>5. ENGINE CONTROL UNIT FAULTY</li> </ol> <p>(1-4 If no abnormal conditions, no spark from plugs)</p>
NO PEAK VOLTAGE PEAK VOLTAGE USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. ADAPTOR MISCONNECTED</li> <li>2. FUSE, MAIN SWITCH, KILL SWITCH FAULTY</li> <li>3. ENGINE CONTROL UNIT COUPLER CONNECTION POOR</li> <li>4. NO VOLTAGE IN ENGINE CONTROL UNIT 16P COUPLER BLACK/WHITE WIRES ( 22.42)</li> <li>5. ENGINE CONTROL UNIT 4P COUPLER WIRE BROKEN, POORLY CONNECTED</li> <li>6. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>7. PULSE GENERATOR POOR QUALITY (MEASURE PEAK VOLTAGE)</li> <li>8. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>9. ENGINE CONTROL UNIT FAULTY</li> </ol> <p>(1-8 If no abnormal condition, no spark from plugs)</p>
PEAK VOLTAGE NORMAL BUT NO SPARK FROM PLUGS	<ol style="list-style-type: none"> <li>1. SPARK PLUGS POOR QUALITY, OR IGNITION COIL SECONDARY CURRENT LEAK</li> <li>2. IGNITION COIL FAULTY</li> </ol>
PEAK VOLTAGE LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>3. TESTING SAMPLING TIME CONSEQUENCES (MEASURE REVOLUTIONS - NORMAL IF VALVE ABOVE STANDARD)</li> <li>4. PULSE GENERATOR FAULTY</li> </ol> <p>(1-3 No abnormal conditions)</p>
NO PEAK VOLTAGE OR USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>2. PULSE GENERATOR FAULTY</li> </ol>

# NSR250R(J)


## POOR CHARGING



## IGNITION TIMING POOR




CARBURETTOR AIR JET CONTROL SYSTEM



# NSR250R(J)

## RC VALVE MOVEMENT POOR



MAINTENANCE SCHEDULE

		12 Mths	6 Mths	1 Mths	Cont. Inspects	
STEERING	Play	●				
	Damage	●				
	Left, Right turning	●				
	Damage	●	●			
	Fork spindle installation	●	●		Tighten steering stem	
	Fork spindle movement	●	●		Tighten steering stem	
	Brake Pedal	Play and performance when pushed	●	●		Play 10-20mm Pedal 20-30mm Lever
		Noise	●			
		Brake noise	○	●	●	
		Leakage, damage, installation	○	●	●	
Brake hose replacement					Every 4 years	
Reservoir Tank	Fluid capacity	●	●	●	Fluid level Front between top & bottom mark Rear between top & bottom amrk	
	M/Cyl. Wheel Cyl. Disc caliper	Damage, wear			●	
Master cylinder, cylinder cap, dust seal, disc caliper replacement					☆ Every two years	
Brake Disc/Pads	Disc to pad clearance			●		
	Pad wear		○	●	Indicator	
	Disc wear and damage				●	Standard : F - 4.0mm R - 5.0mm
					●	Ser. limit : F - 3.5mm R - 4.0mm
	Brake fluid replacement				Every year	

# NSR250R(J)

		1	6	12														
WHEEL	Tire Pressures	●	●	●	<table border="1"> <thead> <tr> <th></th> <th>Front</th> <th>Rear</th> </tr> </thead> <tbody> <tr> <td>1 rider</td> <td>2.25</td> <td>2.25</td> </tr> <tr> <td>2 riders</td> <td>2.25</td> <td>2.50</td> </tr> <tr> <td>Tire type</td> <td colspan="2">.10/70R17 54H/150/60R18 67H</td> </tr> </tbody> </table>			Front	Rear	1 rider	2.25	2.25	2 riders	2.25	2.50	Tire type	.10/70R17 54H/150/60R18 67H	
		Front	Rear															
	1 rider	2.25	2.25															
	2 riders	2.25	2.50															
	Tire type	.10/70R17 54H/150/60R18 67H																
Tire wear and damage	●	●	●															
Tire tread depth	●	●	●	Min - Front 0.8mm Rear 0.3mm														
Foreign articles stuck in tires	●	●	●															
Wheel nut, wheel bolt loosening				Tighten axle nut, axle holder front axle holder torque 1.8-2.5 Kg.m Front axle bolt torque 5.5-6.5 Kg.m Rear axle nut torque 8.5-10.5 Kg.m														
Rim, side rim, wheel disc damage		○	●	Wheel rim runout, warpage Front 2.0mm axial 2.0mm radial Rear 2.0mm axial 2.0mm radial														
Front wheel bearings			●															
Rear wheel bearing			●															
Rushdown Arm	Damage			●	Tighten cushion, spring													
	Arm damage			●														
Shock Bushes	Fluid leakage, damage			●														
	Bushes			●														
Clutch	Lever play		●	●	Play - lever 10-20mm													
	Use		○	●	●													
Trans	Fluid leakage, oil capacity			●	●	Oil capacity - between upper and lower marks												
	Gear movement				●													
Oil	Transmission oil replacement					Every two years												

	1 Month	6 Months	12 months	
CHAIN AND SPROCKET	Chain slack	●	●	Use side stand and measure play in middle 15-23mm
	Sprocket installation & damage		●	
IGN	Ignition plug performance	●	●	Plug gap 0.7-0.8mm
	Ignition plug replacement			5,000km (every)
BAT WIRE	Terminal connections		●	
	Connections & wire damage		●	
BODY	Twisting, foreign sounds	●	●	
	Low/High speed performance	○	●	Idle speed 1200 = 100rpm
	Exhaust gas		●	
	Air cleaner element		●	
FUEL SYS	Oil leakage and capacity		●	Oil capacity Check that pilot lamp does not shine
	Oil leakage		●	
	Oil capacity	●		
	Oil cleaner clogging		●	
	Oil pump performance	○	○	
	Fuel leakage		●	
	Carburettor link		●	
	Throttle cable & choke cable		●	
	Fuel filter clogging		●	
	Fuel capacity	●		
COOLING SYS	Fuel hose replacement			Every 4 years
	Water capacity	●	●	Between upper and lower levels in reserve tank
	Water leakage	●	●	
	Radiator cap		●	Pressure 1.1-1.4 K/cm <sup>2</sup>
	Cooling agent replacement			Every two years
			●	
			●	




NSR250R(J)

	Cont. Ins.	1 month	5 mt. Int.	12 mt. Int.
Horn				●
Labels	●			
	●			
Gauges				●
Exhaust pipe, muffler				●
Muffler performance				●
				●
	●			
			●	●
			○	

FRONT BRAKE

Lever travel 10-20mm




FRONT BRAKE PAD

Pad Wear

Inspect pad wear using the usage marks

\* Replace brake pads as a set




REAR BRAKE PAD

Pad Wear

Inspect pad wear using the usage marks


\* Replace brake pads as a set



FRONT FORK

Spring preload adjustments

\* Ensure spring preload settings are even between left and right forks



## NSR250R(J)

### IGNITION TIMING


\* This machine uses CDI ignition system so adjustment of the ignition timing is not necessary



### AIR CLEANER

\* do not clean element with petrol, solvents or alkalis


\* If element is installed squashed then it will become easily worn, thus needing replacement



### CHOKE

Inspect the choke cable and adjusters condition

Inspect for smooth operation from fully closed to fully open



### LIGHTING SYSTEM

headlight adjustment

With motorcycle on level ground adjust headlight by turning screw with a driver




**SIDE STAND**

Because of the weight of the frame and raising the bike using the side stand the stand may bend.


With 2.0-3.0 Kg pressure the stand will raise when pushing the rubber

If the rubber is worn or damaged replace



**LUBRICATING POINTS**



Indicated in diagramm



**RC VALVE CONTROL CABLE ADJUSTMENT**

\* If the control cable connection is removed or the control cable is loose, then replace the control cable

- Remove R. lower fairing ( 15.3)
- Remove fuel tank ( 4-2)
- Remove control cable connection from cylinder pulley
- Connect fuel tube to fuel cock and start engine
- Slowly raise engine revolutions and check that at roughly 2000rpm the servo motor pulley protuberance stops at the "HI" mark position and stop the engine with the OFF switch



## NSR250R(J)

Fully open the pulley on the cylinder side and fix there with the knock pin or something suitable

\* Check that the pulley is okay when it is in the fixed position

\* it is easier to perform if the knock pin (94303-06100) is used

Connect control cable to the cylinder pulley.

Adjust the adjuster nut so that the pulley which pulls up cable has freeplay of under 0.5mm

\* Always tighten the adjuster nut by hand

Start engine and slowly increase revolutions to around 2000rpm and check that the pulley moves clockwise to a stop, and increase the revolutions to around 3000rpm where it should move anti clockwise to a stop

### AIR CLEANER CASE





remove air cleaner drain tube

Remove air cleaner case bolt

Loosen connecting tube band and remove air cleaner


### CARBURETTOR

Remove as per section 4




CARBURETTOR INSPECTION


Disassemble as per section 4




Remove bracket





\* Caution care must be taken when removing throttle angle sensor



Inspect air jet by removing the plug shown





NSR250R(J)






REASSEMBLY



Assemble in the reverse order of disassembly



Ensure the tubes are all routed correctly









ENGINE REMOVAL

As per ( 6-2)


Remove hanger bolts as shown



Remove hanger bolts




Remove special hanger bolt by removing lock nut and then remove bolt with commercially available hex driver



ENGINE INSTALLATION


reverse order of disassembly refer ( 6-3)




# NSR250R(J)

Torque engine hanger bolts to recommended torque

refer section 6




Align the drive pegs with the slots of the speedo drive box




## OIL STRAINER

Remove the oil strainer retaining bolts and plate




Blow out all recesses etc with compressed air




GEAR CHANGE

Ratchet assembly




Stopper drum assembly




CLUTCH ASSEMBLY

Lock washer







Oil pump assembly



Oil pump drive gear and retaining plate



Oil pump dowels



Oil pump rotor tip clearance measurement

Service Limit: 0.2mm



# NSR250R(J)

Outer rotor to body clearance

Service limit: 0.12mm




Rotor to body side clearance

Service limit 0.20mm




Oil pump assembly

Ensure you lubricate all moving parts with clean engine oil when assembling and align dowels/hole etc




Fit retaining screw





# NSR250R(J)

Assemble drive gear plate and retaining clip to oil pump shaft




Ensure all O rings are in good condition and install oil pump






\*



TRANSMISSION


Bearing removal

Remove bearing retainer, before removing bearing




ASSEMBLY

Use a suitable bearing holder to assemble the mainshaft and countershaft to outer cover




ACC/SPROCKET COVER

SPEEDO DRIVE BOX




SPEEDO DRIVE BOX

SPROCKET COVER



# NSR250R(J)



HANDLE BARS


Removal

Remove the following from the R. Handle

- Master Cylinder
- Handle switch
- Throttle grip


Remove the following from the L. Handle

- Clutch lever bracket
- Lighting switch
- Handle grip




Assembly

When installing the throttle housing align the peg in the housing with the hole in the right handle




Take care not to pinch the wires from the engine stop switch




# NSR250R(J)

When installing the L.H. switch block be sure to align the alignment peg in the housing with the L. handle pipe




## Front Wheel/Suspension


To remove the front wheel remove the brake calipers.  
Loosen the axle bolt then loosen the axle pinch bolts.  
Remove the axle and remove the wheel.




To Remove the Disks remove disk mounting bolts




\* Regrease seals before reassembly



When routing the front brake hose fit the clamp and then check for free steering operation left to right




Spring preload adjuster assembly




Rear Wheel/Bearing


Whenever replacing the rear wheel bearings ensure that the sprocket spacer is attached before fitting the sprocket



Rear wheel Bearings




NSR250R(J)




REAR WHEEL ASSEMBLY

Rear Suspension



Rear shock spring pre load adjustment




Rear shock assembly




Rear shock



Rear brake hose clamps




Chain Case






# NSR250R(J)


## Tortion Arm Assembly




## Explode view of torsion assembly




When reassembling the torsion arm assembly use Molybdenum grease






# NSR250R(J)


## FRONT BRAKE INSPECTION



In order to install new brake pads return pistons to original position




Remove hanger pin to remove brake pads



\* Always replace brake pads as a set

After replacing brake pads pump brake lever to push pads back into disk



REAR BRAKES





Always replace brake pads as a set

Ensure that the brake pad springs are installed correctly

Always pump up rear brake after pad replacement


Front Brake.Lever Assembly

Exploded view front brake lever




# NSR250R(J)



## REAR MASTER CYLINDER ASSEMBLY



Ensure no foreign particles enter brake fluid




Ensure you grease brake pedal bushes with Molybdenum disulphide grease




# NSR250R(J)

Do not spill brake fluid onto brake disks or brake performance will be affected




Do not use high pressure air and do not hold air gun too close

Do not enter hands into caliper




Take care when removing pistons not to damage seals and caliper assembly






# NSR250R(J)


Take care when reassembling not to damage pistons seals etc




When reassembling caliper torque bolts to: 3.0 - 3.5 Kg-m



Re assemble in reverse order of  
disassembly




EXPLODED VIEW






# NSR250R(J)



## CHARGING SYSTEM



### VOLTAGE REGULATOR RECTIFIER


Check rectifier for forward and reverse resistance to check the diodes in the normal manner






# NSR250R(J)



Do not drop PGM Unit or it could be damaged



1	OFF	=====
2	P	=====
3	EXT	
4	ON1	
5	ON2	




Test unit adaptor



LIGHTS


Headlight Unit




NSR250R(J)

---


Indicator bulb




Stop tail bulb




Instrument bulbs



Instrument couplers






SWITCHES

Engine Stop Switch





	BAT1	IGN
ON		
OFF		



	IG	BAT4
OFF		
RUN		



# NSR250R(J)





## LEFT HANDLE BAR SWITCH











# NSR250R(J)




NSR250R(J)

---









COUPLER

COUPLER


# 21. NSR250R SP SPECIAL FEATURES




A : 4.05 - 5.15mm  
 B : 17.20 - 17.44mm



10g	42704 - KV3 - 7200
20g	42705 - KV3 - 7200
30g	42706 - KV3 - 7200



# NSR250R(K)



K

# 22. NSR250R(K)

TECHNICAL FEATURES.....	22-2	CYLINDER HEAD, CLYINDER, PISTON .....	22-31
SPECIAL FEATURES .....	22-3	BRAKE SYSTEM .....	22-31
MAINTENANCE DATA .....	22-7	FAIRING, EXHAUST CHAMBER, SUB .....	22-34
WIRING DIAGRAMS .....	22-9	FRAME .....	22-38
WIRING LOCATIONS .....	22-11	IGNITION SYSTEM.. .....	22-39
TROUBLE SHOOTING.....	22-16	CONTROL UNIT, SERVO MOTOR .....	
INSPECTION SCHEDULE .....	22-24	OIL PUMP SOLENOID .....	22-44
ELECTRICAL SYSTEM.....	22-28	CARBURETTOR, AIR JET CONTROL .....	
CARBURETTOR.....	22-28	SYSTEM .....	22-47
.....	22-30		

# NSR250R(K).

Make	Honda MC18	
Length	1.980m	
Width	0.650m	
Height	1.060m	
Wheel base	1.345m	
Engine type	MC16E	
Engine capacity	249cm <sup>3</sup>	
Motive power	Petrol	
Vehicle Weight	FRT	73kg
	RR	76kg
	Ttl	149kg
Rider number	2	
Gross Weight	Frt	91kg
	Rr	168kg
	Ttl	259kg
Tires	Frt	110/70R17 54H
	Rr	150/60R18 67H
Ground clearance	0.135m	
Braking Distance (Km/H)	14.0m (50)	
Turning circle	2.9m	
Starting	Kickstart	
Fuel	Petrol - 2 cycle	
Cyl. configuration	V 2	
Com. type	Half ball	
Bore x stroke	54.0×54.5mm	
Comp. ratio	7.3	
Cyl. Compress.	10.0kg/cm <sup>2</sup> -400rpm	
Max Horse power	45PS/9500rpm	
Torque	3.8kgm/8000rpm	
Port Timing	Movement - Open - Automatic	
	closed- Automatic	
Intake	Open 76°-95° (BBDC)	
	Closed 76°-95° (ABDC)	
Exh,	Open 62° (BBDC)	
	Closed 62° (ABDC)	
Idle speed	1200rpm	
Lubrication Method	Forced pressure	
	Wet sump	
Oil pump type	Plunge type, (eng)	
	Tricoid type (g/box)	
Oil Capacity	*2.1	

Cooling system		water cooled	
Air cleaner type		Foam	
Fuel capacity		16	
Carb	Type	TA21	
	Gas intake	32mm	
	Venturi bore	32mm	
Ign. System	Type	CDi	
	Ign. Tim	Frt	15° BTDC/1200rpm
		Rr	5° BTDC/1200rpm
	Ignition Plug	NGK ND	BR9ECM, BR10ECM
	Plug gap	0.7~0.8mm	
Battery	12V 3 AH		
Clutch	Type	Wet, coil spring	
	Operation	Manual	
Primary reduction		2.360	
Transmission	Type	Usual method	
	1st gear	2.846	
	2nd gear	2.000	
	3rd gear	1.631	
	4th gear	1.368	
	5th gear	1.250	
6th gear	1.173		
Method	Final	Chain	
	Final	2.800	
Caster		23° 15'	
Trail		87mm	
Tire Pressures	Frt	2.25kg/cm <sup>2</sup>	
	Rr	2.50kg/cm <sup>2</sup>	
Steering Angle	Lt	30°	
	Rght	30°	
Brakes	Frt	Pressurised discs	
	Rr	Pressurised discs	
Suspension	Frt	Telescopic	
	Rr	Swing arm	
Frame type	Diamond		
Frame NO.	MC18-1100001~		
Engine NO.	MC16E-1130001~		

\* : Transmission OIL 0.8

Engine oil 1.3



## SPECIAL FEATURES

Engine Control Unit -(PGM-2)

The PGM-CDI unit and RC valve unit are related to the engine control unit (PGM-2)


The engine control unit is composed of a PGM control unit and CDI convertor

PGM control unit does:

- PGM-CDI 2 ignition timing adjustment
- PGM- Carburettor 2 air/fuel mixture adjustment
- PGM-RC Valve RC valve adjustment
- Oil pump solenoid oil outflow characteristic adjustment

Performance:

The engine control unit is divided into the PGM control section and the CDI convertor. In the CPU program map the pulse signaling from the No.1 & 2 pulse generator is in accordance with the engine revolutions, enters voltage from the throttle sensor in accordance with the throttle opening. The program does, the ignition timing demanded by the engine from the enforced valve, the air/fuel mixture, exhaust port timing, oil outflow capacity measurement and predicts the various circumstances from low revolutions to high revolutions which give good fuel performance




# NSR250R(K)

## PGM-CDI 2


The PGM-CDI 2, at the same time as advancing new domains, has the advanced characteristics of ign timing for independent frt & rear cylinders. The No.1-2 pulse generators pulse signaling is on the eng. revs & throttle sensor output voltage is on throttle opening, and respective PGM control PGU program maps apply power. The CPU program map is independent for the frt & Rr cylinders and with a plan for optimum ignition timing, gives spark plug firing points produced by the CDI convertor.

For example, when the throttle opening is less than 5% and the engine revs are between 1000 & 1800rpm, it becomes possible to approach ign. timing which demands different characteristics for the frt & Rr cylinders. Giving very smooth idle characteristics


Even with the advanced performance at all en. revs, the program map details can be changed, with not only the throttle opening and eng. revs being able to be divided, the ign. timing demanded by the eng. can be corresponding. With this, it has become possible for the acceleration response to be increased. For example even at the same engine revolutions, with the throttle opening at 30% & 50% the ign. timing can be adjusted for the respective throttle openings.



IGNITION TIMING PERFORMANCE



Also regarding the advanced angle of compensating for ignition timing at quick throttle opening, whether it be 100-4500rpm, or even widened to 1000-11500rpm, the following throttle performance at all rev ranges has been increased. When the revolutions are between 1000 and 11500rpm it compensates for the changed throttle opening from the fixed timing (30m sec). With the PGM control, if the throttle opening change is 20% below the 30m sec the 2-8° will be compensated to 5-6°.




### PGM-CARBURETTOR 2

#### Carburettor Air Jet Control System:

The air mixture (ideal air mixture) and air mixture supplied to the eng. are shown respectively on the graph below. In this system the carb supplies the air mixture, and in order to supply close to the air mixture demanded by the engine, sends air into the carb air jet. The PGM carb.2 not only supplements the air jet and solenoid valve, but also makes fine control possible. The PGM control according to the input power from the engine revs (pulse generator), throttle opening (throttle sensor) is produced by separate NO.1 solenoid and NO.2 solenoid valves, and adjusts the input volume of air from the sub air cleaner to the main air bleed.

When the air mixture supplied to the carburettor is too rich, (oblique line on graph), the solenoid is turned ON, and according to the air input increase to the air bleed the air mixture is diluted and the engine nears the ideal air/fuel mixture demanded by the engine. The PGM-Carburettor 2, as for engine revolutions, makes it such that it can control the correct air mixture with the throttle opening from low revolutions to high revolutions, and improves drivability over all rev. ranges




# NSR250R(K)

## PGM-RC VALVE

With the PGM-RC valve system, the exhaust port timing in relation to the engine revolutions and throttle opening operates the servo motor according to the engine control units PGM control map and controls the RC valve opening


As for the input from the pulse generator and throttle sensor, the output power correspondingly details the exhaust port timing and is adjusted according to the change in the PGM control program map.

For example, at the same engine revolutions, the exhaust port timing which gives the maximum output that relates to the respective throttle openings is held within the PGM control program map. According to the program map the RC valve is operated and controls the optimum port timing



(PGM-RC VALVE OPENING PERFORMANCE)

RC VALVE OPENING



The PGM-RC Valve makes it possible to finely adjust the exhaust port timing in accordance to the various engine revolutions and throttle openings, and depending on this the throttle response and power output is improved.

# NSR250R(K)

## MAINTENANCE DATA

### Torques:

Frame	No.	Threadmm	Torque (kg-m)	Notes
Front disc pinch bolt	12	6	1.8~2.2	
Torque rod pinch bolt/nut (frame)	1	10	3.0~4.0	after tightening
Torque rod pinch bolt/nut (caliper)	1	10	3.0~4.0	insert split pin
Brace hose clamp bolt	4	6	1.0~1.4	
Driven socket bolt	5	10	7.0~8.0	Apply oil to thread
Rear brake disc pinch bolt	3	8	4.0~4.5	
Rear axle nut	1	18	8.5~10.5	

### Tools:

Standard	Tool number	No.	Use
Torque driver bit	07703-0010400	1	Carb. separation
Bit driver	07703-0010300	1	Carb. separation
Rear suspension compressor attach.	07959-MB10000	1	Rear suspension sep/install

Special	Tool number	No.	Use
Spherical driver bit	07HMF-HC00100	1	Torque rod brg removal
Rear suspension compressor	07GME-0010000	1	Gear suspension sep/install

### Gauges:

	Tool number	No.	Use
Peak voltage adaptor	07HGJ-0020100	1	Ignition inspection

### Fuel system

	No.1 Carb	No.2 Carb
Setting mark		TA21A
Main jet		≅128
Jet needle mark	BPG	BPH
Power jet		≅75
Air screw rotations		2-1/8

# NSR250R(K)

## CYLINDER HEAD, CYLINDER PISTON, RC VALVE

mm

		Standard	Service limit
Cylinder I.D	Mark : A	54.008 - 54.011	54.02
	Mark : B	54.004 - 54.008	54.02
	Mark : C	54.000 - 54.004	54.02
Piston O.D	Mark : B	53.966 - 53.969	53.92
	No mark	53.962 - 53.965	53.91
	Mark : D	53.958 - 53.961	53.91
Cylinder to piston clearance		0.039 - 0.045	0.09
Piston pin bore I.D		15.022 - 15.006	15.05
Piston pin O.D		14.966 - 15.000	14.95
Piston to piston pin clearance		0.002 - 0.010	0.04

## Front wheel, suspension

mm

	Standard	Service Limit
Front cushion spring freeplay	285.4	279.7
Front fork oil	Honda Ultra cushion oil 10	

## Rear wheel, suspension

mm

	Standard	Service Limit
Rear cushion damper pressure (at 10mm)	15.4 - 19.9kg	12.3kg
Rear Cushion spring torque length	161.8	-----

## Ignition System:

Ignition timing	Front cylinder	15° BTDC / 1200rpm	
	rear cylinder	5° BTDC / 1200rpm	
		300rpm	
		11,500rpm	
Ignition coil	First coil resistance (20°C)		0.1 - 0.3Ω
	2nd coil resistance (20°C)	Cap On	5.0 - 11.0KΩ
		Cap Off	2.0 - 4.0KΩ
Pulse generator	Coil resistance (20°C)		180 - 220Ω

## Generator System:

AC Generator Resistance (20°C)	0.2 - 1.0Ω
--------------------------------	------------

## Air Solenoid



Air solenoid resistance (20°C)	25 - 40Ω
--------------------------------	----------

SPEED WARNING LIGHT SYSTEM






0030Z-KV3-7900

WIRING MAP











# NSR250R(K)





NSR250R(K)



# NSR250R(K)


## TROUBLE SHOOTING







# NSR250R(K)

## POOR ADJUSTMENT TO ENGINE - NO POWER





AT LOW REVS, LOTS OF EXHAUST NOISE






# NSR250R(K)

## NO SPARK FROM SPARK PLUG


If there is no spark, conduct spark test on ignition coil. Measure the ignition coils primary voltage. If there is difficulty with the coil but still normal spark, the ignition coil has been faulty from beginning

PERFORMANCE PROBLEM	CHECK THE FOLLOWING, POSSIBLE CAUSES FROM 1.
PEAK VOLTAGE IS LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. TESTING SAMPLING TIME CONSEQUENCES</li> <li>3. IGNITION WIRING CUT, POOR CONTACT</li> <li>4. IGNITION COIL FAULTY</li> <li>5. ENGINE CONTROL UNIT FAULTY</li> </ol> (1-4 If no abnormal conditions, no spark from plugs)
NO PEAK VOLTAGE  PEAK VOLTAGE USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. ADAPTOR MISCONNECTED</li> <li>2. FUSE, MAIN SWITCH, KILL SWITCH FAULTY</li> <li>3. ENGINE CONTROL UNIT COUPLER CONNECTION POOR</li> <li>4. NO VOLTAGE IN ENGINE CONTROL UNIT 16P COUPLER BLACK/WHITE WIRES ( 22.42)</li> <li>5. ENGINE CONTROL UNIT 4P COUPLER WIRE BROKEN, POORLY CONNECTED</li> <li>6. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>7. PULSE GENERATOR POOR QUALITY (MEASURE PEAK VOLTAGE)</li> <li>8. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>9. ENGINE CONTROL UNIT FAULTY</li> </ol> (1-8 If no abnormal condition, no spark from plugs)
PEAK VOLTAGE NORMAL BUT NO SPARK FROM PLUGS	<ol style="list-style-type: none"> <li>1. SPARK PLUGS POOR QUALITY, OR IGNITION COIL SECONDARY CURRENT LEAK</li> <li>2. IGNITION COIL FAULTY</li> </ol>
PEAK VOLTAGE LOW	<ol style="list-style-type: none"> <li>1. USE TESTER TO CHECK FOR LOW INTERNAL RESISTANCE</li> <li>2. CRANKING SPEED TOO LOW (KICK POWER TOO STRONG)</li> <li>3. TESTING SAMPLING TIME CONSEQUENCES (MEASURE REVOLUTIONS - NORMAL IF VALVE ABOVE STANDARD)</li> <li>4. PULSE GENERATOR FAULTY</li> </ol> (1-3) No abnormal conditions
NO PEAK VOLTAGE OR USUALLY NOT THERE	<ol style="list-style-type: none"> <li>1. PEAK VOLTAGE ADAPTOR FAULTY</li> <li>2. PULSE GENERATOR FAULTY</li> </ol>

POOR CHARGING




IGNITION TIMING POOR




# NSR250R(K)

## CARBURETTOR AIR JET CONTROL SYSTEM



RC VALVE MOVEMENT POOR



# NSR250R(K)

## MAINTENANCE SCHEDULE

		Continuous	1 Mths	6 Mths	12 Mths				
STEERING	/Bar/Stg Forks	- Play			●				
		Damage			●				
		Left, Right turning				●			
		Damage			●	●			
		Fork spindle installation			●	●	Tighten steering stem		
		Fork spindle movement				●	Tighten steering stem		
		Brake Pedal	Pedal	Play and performance when pushed		●	●	Play 10-20mm Pedal 20-30mm Lever	
				Noise	●				
				Brake noise		○	●	●	
				Leakage, damage, installation		○	●	●	
Res. Tank	Tank	Brake hose replacement				Every 4 years			
		Fluid capacity	●	●	●	Fluid level Front between top & bottom mark Rear between top & bottom amrk			
		Damage, wear			●				
M/cyl. Wheel cyl. Disc. caliper	M/cyl. Wheel cyl. Disc. caliper	Master cylinder, cylinder cap, dust seal, disc caliper replacement				☆ Every two years			
		Disc to pad clearance			●				
Brake Disc/Pads	Brake Disc/Pads	Pad wear		○	●	Indicator			
		Disc wear and damage			●	Standard : F - 4.0mm R - 5.0mm Ser.limit : F - 3.5mm R - 4.0mm			
		Brake fluid replacement				Every year			



# NSR250R(K)

		1 Month	6 Mths	12 mths	
CHAIN AND SPROCKET	Chain slack	○	●	●	Use side stand and measure play in middle 15-25mm
	Sprocket installation & damage			●	
IGN	Ignition plug performance		●	●	Plug gap 0.7-0.8mm
	Ignition plug replacement				5,000km (every)
BATT/WIRE	Terminal connections			●	
	Connections & wire damage			●	
BODY	Twisting, foreign sounds		●	●	
	Low/High speed performance	○	●	●	Idle speed 1200±100rpm
	Exhaust gas		●	●	
	Air cleaner element		●	●	
	Oil leakage and capacity		●	●	Oil capacity Check that pilot lamp does not shine
	Oil leakage		●	●	
	Oil capacity	●			
	Oil cleaner clogging			●	
	Oil pump performance		○	○	
FUEL SYS	Fuel leakage		●	●	
	Carburettor link			●	
	Throttle cable & choke cable			●	
	Fuel filter clogging			●	
	Fuel capacity	●			
	Fuel hose replacement				Every 4 years
COOLING SYS	Water capacity	●	●	●	Between upper and lower levels in reserve tank
	Water leakage	●		●	
	Radiator cap			●	Pressure 1.1-1.4 K/cm <sup>2</sup>
	Cooling agent replacement				Every two years
			●	●	
		●			

		12 mths	6 mths	1 month	Contin.
	Horn	●			
	Labels			●	
				●	
	Gauges	●			
	Exhaust pipe, muffler	●			
	Muffler performance	●			
		●			
				●	
		●	●		
			○		



## NSR250R(K)

\* Because this machine uses a CDI ignition system maintenance of ignition timing is not necessary

\* If ignition timing is incorrect turn to ( 22.21) and inspect the connections

Remove lower fairing ( 22.35)

Keep engine warm

Remove L. crankcase cover ( 20.42)

Join the timing light cord to the rear cylinder high tension cord

Start engine and idle at  $1200 \pm 100$ rpm

Align the index mark with the F mark and inspect whether the ignition timing is okay or not

### ENGINE

Main body

\* Adjust idle speed once engine is warm  
\* After overhauling a carburettor balance the carburettors ( 4.16)




Place engine in neutral

Start engine

Turn throttle stop screw to slowest speed and turn in to adjust idle speed

Idle speed:  $1200 \pm 100$ rpm

If idling speed is imbalanced or there is a snapping sound then synchronise carburettors ( 4.16)



## RC VALVE CONTROL CABLE MAINTENANCE

Remove fuel tank ( 4.2)

Start engine, confirm that at roughly 2000rpm the servo motor pulley protrusion nears the HI mark and turn off the engine.

Insert the 3mm screw into the pulley screw hole and tighten until the pulley cannot move




(Cable Play Adjustment)

Push pulley by hand until the pulley protrusion left side (A section) meets the centre of the index mark (as in illustration 1)

In that situation turn the pull adjuster by hand and at the point where the pulley protrusion (A) meets the engine index mark right hand side, (illustration 2), release the hand that was pushing the pulley  
Turn the push adjuster by hand and align the pulley protrusion left side (A) with the engine index mark centre (1)

Check that the pulley moves by hand and that the pulley gap is between 0.5-3.0mm (illus.3)

If pulley gap is under 0.5mm (cable is too tight) or over 3.0mm (cable is too loose) then adjust as shown above



## RC Valve Adjustment


With the pulley free, check the protrusion left (A) side and the engine index mark

- pulley lag direction is under 0.4mm (4)
- the protrusion left (A) mark is between the engine's two index marks

If outside standard, readjust  
If inside standard, tighten lock nut while turning adjuster by hand

Remove the screw that held the servomotor pulley

Reinstall fuel tank



# NSR250R(K)


## CARBURETTOR

### Tube Installation


Assemble carburettor ( 20.31)

Install air vent tube

Install air inlet tube




\*\* Install black tape on tube and protector as shown



Install air outlet tube


Clamp tube with the carburettors top clumper



Install fuel tube and drain tube ( 4.13)

Install carburettor

Install tubes properly as shown in wiring map ( 22.11)





# NSR250R(K)

## CYLINDER, PISTON SELECTION

The cases for replacement of cylinder, pistons and corresponding replacement parts are shown below

### Selection

Cyl	Mark A		Mark B		Mark C	
	54.008—	54.011	54.004—	54.008	54.000—	54.004
Piston						
Mark B			×			×
No Mark	×					×
Mark D	×		×			



## BRAKE SYSTEM



Front brake caliper installation

Install caliper to front fork

install caliper pinch bolt ( 20.55)

Install brake hose and hose bolt

Torque 3.0-4.0 Kg.m



- \* When installing brake hose install hose end to caliper stopper correctly
- \* Check that the brake hose is definitely attached to hose guide


# NSR250R(K)

## REAR BRAKE TORQUE ROD

### Removal

Remove split pin

Remove bolt and nut and remove torque rod




### SPHERICAL BEARING REPLACEMENT

Remove collar and dust seal

Use hydraulic press to remove bearing

Spherical Bearing Driver 07HMF-HC00100




Use hydraulic press and install bearing

Special tool:  
Spherical Bearing Driver 07HMF-HC00100

\* Insert bearing to face ( as illustrated )

Apply molybdenum to dust seal

Install collar




### Installation

Install torque rod to frame

\* Face F mark on torque rod to the front

Install bolt, nut and collar to frame and tighten

Install new split pin



REAR BRAKE CALIPER BRACKET REMOVAL

\* Be careful not to spill fluid on brake discs or pads. Brake performance would be affected. If removing, replace pads and check disc

\* Brake caliper bracket can be removed without disconnecting brake hose

Removal

Remove torque rod caliper bracket pinch bolt ( 22.32)

Remove caliper bolt and remove caliper bracket ( 20.56)

\* Suspend brake caliper so as not to pinch hose

Remove rear wheel ( 13.3)

Remove caliper bracket

Remove collar from bracket and inspect for damage

Inspect for damage to dust seal, warpage and damage to bush

If the bush is worn then replace bracket as an assembly

Installation

\* Apply molybdenum grease to dust seal lip and bush inner

Install collar to bracket

Install caliper bracket and rear wheel ( 13.7)




Install caliper to bracket ( 20.56)

Install torque rod ( 22.32)

Torques:

Rear axle nut	8.5-10.5 Kg.m
Torque rod pinch bolt/nut	3.0-4.0 Kg.m


torque rod bolt/NUT



# NSR250R(K)


FAIRING, EXHAUST CHAMBER, SUB FRAME

FAIRING




## MAINTENANCE LID

Remove 5 screw  
 Remove upper fairing hook, inner lower fairing screw and remove L. maintenance lid  
 Loose 5 quick release screws  
 Remove screws from upper fairing hook and inner lower fairing, and remove R. maintenance lid




## LOWER FAIRING

Remove pinch nut from engine section of lower fairing  
 Remove the 2 screws and 2 flange nuts, and remove lower fairing from assembly




Remove 3 screws and remove inner lower fairing  
 Pull apart where lower fairing front sections meet



Remove heat guard from lower fairing connection  
 Separate left and right fairing by taking it forward and back.

\* Take care not to break lower fairing hook


When installing reverse removal process





# NSR250R(K)

## SUB FRAME, SEAT COWL REMOVAL



# NSR250R(K)

\* Remove muffler and exhaust chamber when cold

\* Exhaust pipe is stainless. Thus oil and dirt stains can be removed with the engine running. If removing stains use a specified stainless steel cleaner and wash with sponge


## Removal

Remove lower fairing ( 22.35)

Remove front cylinder exhaust chamber joint nut, silencer pinch bolt and chamber pinch bolt

In the same way, remove exhsust chamber


Inspect exhaust chamber bush for damage



## Installation

Pull off exhsust chamber spring seat face

Install a new spring seat to exhaust chamber



When installing, insert the bolts and nuts by hand and tighten

- exhaust chamber joint nut
- exhaust chamber pinch bolt
- silencer pinch bolt



## Torque:

Exhaust chamber joint nut 2.3-2.7 Kg.m

Exhaust chamber pinch bolt 1.8-2.5 Kg.m

Silencer pinch bolt 1.8-2.5 Kg.m

\* Install silencer pinch bolt as in the illustration



## NSR250R(K) 追補

### SILENCER REPLACEMENT



Remove silencer pinch bolt  
Remove 3 silencer joint bolts and  
heat guard and remove silencer from  
exhaust chamber

Install new gasket to silencer  
Install heat guard and silencer joint  
bolt and tighten bolt

Install silencer pinch bolt

Torque: Silencer joint bolt 1.0-1.4 Kg.m  
Silencer pinch bolt 1.8-2.5 Kg.m

\* The heat guard installed silencer  
joint bolt is larger then the other 2  
bolts



### BATTERY/CHARGING SYSTEM

Battery Removal

Remove battery (-) terminal cable


Open battery cover

Remove (+) cable from (+) terminal

Remove battery



Install and reverse removal process

\* After installing battery, apply a  
small amount of grease.



IGNITION SYSTEM

Wiring Diagram



## NSR250R(K) 追補

### Warnings;

- When inspecting ignition system, refer to trouble shooting section ( 22.20)
- Most ignition system troubles are caused by coupler etc being misconnected. Before adjusting each one, inspect quality of connection
- If engine control unit is dropped, damage may be caused so take care when charging. Also if there is a charge leak, when connector and couplers are connected too much voltage may be applied, causing internal damage to the unit. Always turn main switch OFF before performing work.
- Do not remove throttle sensor from carburettor. If any abnormalities to throttle sensor, replace sensor, sensor stay assy, joint, throttle shaft and throttle link arm as a set.

### IGNITION SYSTEM INSPECTION

\* If no spark from spark plug, remove each wire, loosen and check for abnormalities and measure respective peak voltages  
\* Measure digital tester input resistance (impedance) for values above 10M ohm/DCV. Depending on the type of tester used the resistance will differ.

Connect peak voltage adaptor to digital tester

Gauge: Peak voltage adaptor 07HGJ-0020100  
Showa Digital Tester 07411-0020000

Resistance above 10M ohm/DCV



Ignition Coil Primary Voltage ( Primary Peak Voltage)

\* Wire ignition system correctly and measure value. If there is a break in wiring, measurement cannot be done.  
\* If cylinder compression, inspect plug installation

Remove fuel Tank( 4.2)

As for primary peak voltage, crank and measure ignition coil primary voltage. For this purpose if there are any abnormalities on one cylinder, kick over and measure the other cylinder. NB If cranking speed is imbalanced your primary voltage will vary

As with the standard spark test, leave spark plug in cylinder head and install good spark plugs to cylinder plug gap, earth to engine, advance to next step, and measure primary voltage



FRONT CYLINDER


With ignition coil primary wire connected, connect peak voltage adaptor to primary wire B/Y and body earth.

Turn main switch ON and RUN kill switch Kick over and measure ignition coil primary voltage

Inspect rear cylinder in the same way

Recommended method

Front cyl. : (-) B/Y - body earth (+)  
 Rear Cyl. : (-) B/Bu - body earth (+) -  
 Peak voltage: above 300V



\* When measuring voltage, if finger touches probes metal end, it will become electrified. Take care not to touch it with finger

\* Abnormal values will be given if other ignition system routes are cut or connections faulty

\* The respective ignition coils primary voltage may be abnormal, but if above the respective standard values then it is okay


PULSE GENERATOR

\* Install spark plugs into cylinder head and inspect cylinder compression

Turn main switch OFF  
 Remove seat cowl  
 remove engine control unit 16P and 4P couplers and connect peak voltage adaptor to harness sides coupler pulse generator wire, 4P Bu and 16P W/Bu terminals  
 Kick engine over and measure pulse generator peak voltage  
 Inspect W/Y terminal in the same way

Recommended method:

No.1 (+) 16P W/Y - 4P Y (-)  
 No.2 (+) 16P W/Bu - 4P Bu (-)  
 Peak voltage : above 2V



\* If one sides pulse generator is faulty spark will not jump for both cylinders  
 \* If each pulse generators measured voltage differs, it each is above the respective standard value then it si okay

## NSR250R(K)

If measured value at unit coupler is abnormal, remove pulse generator 6P coupler connection

Connect adaptor, and in the same way, measure both pulse generators peak voltage, and compare with peak voltage value measured at unit coupler

### Recommended method

No.1 (+) W/Y - Y (-)

No.2 (+) W/Bu - Bu (-)

Peak voltage above 2 V

If the value at the unit is abnormal, but the voltage at the pulse generator is normal, either the coupler connection is faulty or the wire harness is misrouted. If both are abnormal, then pulse generator abnormality is possible. Refer ( 22.20)

### THROTTLE SENSOR INSPECTION

Turn main switch OFF

Remove seat cowl

Remove engine control unit 16P & 4P coupler inspect the following at the harness sides coupler

Measure 16P coupler Bu/G and Y/R resistance

Std Resistance (20°C): 4-6 K ohm

Measure resistance between Y/Bu & Bu/G when throttle is fully closed to fully open and if each resistance value is exceeded then it is normal

Std resistance (20°C) Fully closed

0-1.5 K ohm (throttle stop screw loosened safely)

Fully open : 4-6 K ohm

When value becomes large, remove throttle sensor 3P coupler connection and perform the above inspection at both sides of the sensor couplers terminals.

If measured value is inside standard resistance value, then correct wire harness or replace it.

If the measured value is larger than the standard value then replace throttle sensor & sensor stay assy, joint, throttle shaft & throttle link arm as a set

### ENGINE CONTROL UNIT

Engine Control Unit Input Voltage Inspection

Turn main switch OFF

Remove seat cowl

Remove 16P & 4P

### ENGINE CONTROL UNIT

Engine control unit input voltage inspection

Turn main switch Off. remove seat cowl

Remove 16P and 4P couplers from engine control unit

Turn main switch ON and kill switch on RUN.




Inspect for voltage in 16P coupler harness coupler, Bl/W terminals. If voltage then okay

### Recommended method:

(+) 16P coupler Bl/W - body earth (-)

Recommended voltage : Battery voltage

If not holding battery voltage, inspect main switch, kill switch, fuses and wire harness



ENGINE CONTROL UNIT OUTPUT VOLTAGE INSPECTION

(Throttle sensor, RC valve servo motor potentro meter)

Turn main switch OFF, remove seat cowl & fule fuel tank ( 4.2). Remove throttle sensor 3P coupler. Remove servo motor 4P coupler and connector

Turn main switch ON and kill switch to RUN Remove throttle sensor 3P coupler & measure voltage on coupler harness side Y/R and Bu/G terminals. Remove servo motor 4P coupler and measure voltage of coupler harness side Y/R and BU/G terminals

Recommended method

Throttle sensor = (+) Y/R - Bu/G (-)

Servo motor + (+) Y/R - Bu/G (-)

Recommended voltage = 4-5V




ENGINE CONTROL UNIT TERMINALS

Refer to wiring map ( 22.9,10) and below illustration and inspect for correct placements

4P WIRE HARNESS COLOUR

- 1] Ign coil (-) G/W
- 2] NO.1 pulse generator (-) Y
- 3] No.2 pulse generator (-) Bu
- 4] Earth G

- 16P
- 5] Frt Ign. coil (+) Bl/Y
- 6] Oil pump solenoid P
- 7] RC servo motor (+) W
- 8] No.2 Carb solenoid P/Bu
- 9] Earth O/Bu
- 10] No.2 pulse generator (+) W/Bu
- 11] Potentro meter (+) Y/R
- 12] Throttle sensor Y/Bu
- 13] Rr Ign coil (+) Bl/Bu
- 14] Battery power source (+) Bl/W
- 15] RC Servo motor (-) W/R
- 16] No.1 Carb solenoid P/W
- 17] Potentro meter (-) Bu/G
- 18] No.1 pulse generator (-) W/Y
- 19] Tachometer Y/G
- 20] RC valve sensor Lg







# NSR250R(K).

CONTROL UNIT, SERVO MOTOR, OIL PUMP SOLENOID

Wiring Diagram



Warnings:

Refer to troubleshooting section 22.23 for total system.  
 - If engine control unit is dropped damage may be caused, so take care when carrying.  
 Also if there is a charge leak when connector and couplers are connected, too much voltage may be applied, causing internal damage to the unit. Always turn main switch OFF before performing work.


RC Valve, Servo Motor Inspection

Refer to ( 19.2) and inspect RC valve performance  
 Even if it does not perform normally conduct inspections listed in ( 19.2)

WIRE HARNESS, ENGINE CONTROL UNIT INSPECTION

Inspect servo motor and if no abnormalities conduct the following inspection  
 Remove seat cowl and fuel tank ( 4.2)  
 Inspect engine control unit input voltage ( 22.42)  
 If battery voltage, then normal.  
 If no battery voltage, inspect wire harness routing and sub frame

If there is battery voltage inspect for current in the servo motor harness 4P coupler, connector and engine control unit harness 14P and 4P couplers



Servo Motor	W	W/R	Bu/G	Y/R	Lg
Unit	W	W/R	Bu/G	Y/R	Lg

If no current; replace wire harness or correct it


If current inspection is normal, inspect engine control unit output voltage ( 22.43)

Connect engine control unit 16P and 4P couplers  
 Turn main switch ON

Recommended method

(+) Y/R - Bu/G (-)  
 Recommended voltage = 4-5V

If no voltage, inspect engine control unit




# NSR250R(K)

## OIL PUMP SOLENOID INSPECTION

Remove fuel tank ( 4.2)  
Remove R. maintenance lead ( 22.35)  
Remove oil pump solenoid coupler connection  
Measure resistance between coupler W/C and P terminals  
Standard resistance (20°C) = 3.0-5.0 ohm

Connect battery (+) to solenoid coupler W/G terminal and (-) to P terminal

OIL PUMP SOLENOID COUPLER




- \* Do not short battery
- \* Do not connect battery for more than 1 second
- \* Use a safe charge battery

If no Click sound comes from solenoid, then replace oil pump assy (Oil pump replacement ) 3.3)

If there is a sound, advance to the next inspection  
Connect pump solenoid 2P coupler  
Turn main switch ON  
Measure voltage between solenoid harness 2P coupler (R) B1/W and body earth  
If there is battery voltage, then okay



@P COUPLER





Recommended method  
(+) B1/W - body earth (-)

If no battery voltage, conduct the following inspection

- Main switch current
- Battery charging performance
- Wire harness, coupler short, connectors
- Blown Fuse

CARBURETTOR AIR JET CONTROL SYSTEM

Wiring Map



# NSR250R(K)

## Warnings:

- Refer to ( 22.22) and conduct the appropriate inspections
- Take care that foreign particles do not enter carburettor air jet control system tube joint and air screw.
- If engine control unit is dropped damage may be caused. Take care when charging. Also if there is a charge leak, when connector and couplers are connected too much voltage may be applied, causing internal damage to the unit. Always turn main switch OFF before performing work

## CARBURETTOR SOLENOID TUBE INSPECTION





- Remove seat cowl
- Remove fuel tank ( 4.2)
- Remove air cleaner case ( 20.29)
- Inspect for wear and damage to tube leading from solenoid to carburettor and joint
- Refer wiring diagram ( 22.11) and inspect routing

## VALVE LEAK INSPECTION

- Remove air cleaner case ( 20.29)
- Remove No.1-2 solenoid 2P coupler connection
- Remove bottom tube from No.1 solenoid
- Apply pressure to bottom of solenoid and if it will hold it is okay


\* Do not apply more than 30mm Hg pressure

- If it does not hold, then replace solenoid
- Inspect No. 1 solenoid in the same way
- Connect solenoid 2P coupler, turn on main switch and inspect in the same way as above. If it can hold pressure, then it is okay. If it cannot then inspect engine control unit and wire harness




SOLENOID PERFORMANCE INSPECTION

Place transmission in neutral  
 Remove No.1 solenoid lower tube and connect vacuum tester. Start engine with the No. solenoid pressure holding  
 When engine is idling, release pressure  
 Inspect No.2 solenoid in same way. With No.1 solenoid, raise engine revolutions and at roughly 6500rpm, if it can hold pressure then it is okay




SOLENOID COIL INSPECTION

Turn main switch OFF  
 Remove seat cowl  
 Remove No.1 solenoid lower tube and connect vacuum tester.  
 Remove control unit 16P and 4P couplers  
 Earth 16P coupler harness P/W terminals with jumper cords




When main switch is turned On, release pressure & when it is OFF, if it can hold pressure then solenoid is okay  
 Inspect P/Bu terminals (No.2 solenoid) in the same way



SOLENOID HARNESS INSPECTION

Turn main switch OFF  
 Remove seat cowl  
 Remove engine control unit 16P coupler connector  
 Remove No.1 solenoid 2P coupler connection and join harness coupler terminal with jumper wires



## NSR250R(K)


With main switch turned OFF, inspect for no voltage between harness 16P coupler P/W terminal (+) and frame earth (-)

If no voltage okay

Inspect P/Bu terminal (+) in the same way. If battery voltage, inspect main switch

Turn main switch ON and inspect for voltage between harness 16P coupler P/W terminal (+) and frame earth (-). If voltage, wire harness is okay. Inspect P/Bu terminal (+) in the same way.

If no voltage, inspect main switch and wire harness



### ENGINE CONTROL UNIT INSPECTION

Turn main switch OFF


Remove seat cowl

Remove engine control unit 16P and 4P couplers.

Inspect respective currents between P/W and G, P/Bu and G terminals

If no voltage then okay

If voltage then replace engine control unit



Standard method:

16P P/W - G 4P

16P P/Bu - G 4P

---

---

**ホンダ** NSR250R(K)

サービスマニュアル

---

不許複製

---

発行 本田技研工業株式会社

編集 本田技研工業機整備資料課

---

---



**HONDA**  
本田技研工業株式会社