



## **Instructions for fitting silicone hose kits.**

1. Hoses are made to fit only one way and cannot be reversed. This includes hoses D & E.
2. Clamps must be fitted behind bead.
3. If possible, ensure that at least 3mm of hose is protruding beyond the clamp
4. Use only recommended clamps, NOT OEM parts. T-Bolt clamps cannot be fitted in most positions because they are too wide.
5. Tighten clamps to 20 inch pounds then wait 30 minutes and check again. If you do not have a suitable torque wrench then use a 1/4" drive screwdriver handle with 7mm socket attached. Do not use 1/4 drive ratchet handle as they exert too much leverage to allow good feel. Tighten until clamp screw begins to feel firm. At that point hose will expand slightly out at the end.
6. Ensure that hoses are not rubbing on any part of your motorcycle.
7. Do not use harsh cleaners or petroleum based products to clean your hoses.

