



Gambar 01 CYLINDER HEAD



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E1111-10	HEAD, CYLINDER 1	1	
2	4TT-E1191-00	COVER, CYLINDER HEAD 1	1	
3	4TT-E1161-00	ABSORBER 1	1	
4	9502M-06014	BOLT, FLANGE	4	
5	90116-08393	BOLT, STUD	4	
6	90176-08061	NUT, CROWN	4	
7	94701-00045	PLUG, SPARK (NGK B8ES)	1	
8	4TT-11181-00	GASKET, CYLINDER HEAD 1	1	
9	4TT-E1311-10	CYLINDER 1	1	
10	9561L-08625	BOLT, STUD	2	
11	4AC-E1351-10	GASKET, CYLINDER	1	
12	99530-10114	PIN, DOWEL	2	
13	90179-08299	NUT	4	
14	4TT-E1162-00	ABSORBER 2	2	
15	4TT-E1127-00	ABSORBER 3	4	


Gambar 02 CRANKSHAFT & PISTON



4TT14276-9020


Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E1400-00	CRANKSHAFT ASSY	1	
2	4TT-E1412-00	CRANK 1	1	
3	4TT-E1422-00	CRANK 2	1	
4	4X8-11651-00	ROD, CONNECTING	1	
5	3KC-E1681-00	PIN, CRANK 1	1	
6	90209-22071	WASHER	2	
7	93310-422L0	BEARING	1	
8	4AC-E1630-00	PISTON ASSY (STD)	1	
	4AC-E1630-10	PISTON ASSY (0.25MM O/S)	1	AP
	4AC-E1630-20	PISTON ASSY (0.50MM O/S)	1	AP
9	4AC-E1610-00	PISTON RING SET (STD)	1	
	4AC-E1610-10	PISTON RING SET (0.25MM O/S)	1	AP
	4AC-E1610-20	PISTON RING SET (0.50MM O/S)	1	AP
10	93310-214C3	BEARING	1	
11	3SB-E1633-00	PIN, PISTON	1	
12	93450-15090	CIRCLIP	2	
13	93306-20594	BEARING	2	
14	93102-25807	OIL SEAL	1	
15	93103-32099	OIL SEAL	1	
16	90387-208N8	COLLAR	1	
17	90280-03017	KEY, WOODRUFF	1	
18	90201-12593	WASHER, PLATE	1	
19	90170-12368	NUT	1	
20	90208-12015	WASHER, CONICAL SPRING	1	
21	90179-12659	NUT	1	
22	90282-05005	KEY, STRAIGHT	1	
23	93210-18023	O-RING	1	

Gambar 03 OIL PUMP




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-13104-01	OIL PUMP SUB ASSY	1	
2	90445-077K8	HOSE (L95)	1	
3	90467-07093	CLIP	1	
4	93210-20027	O-RING	1	
5	90149-04318	SCREW	1	
6	90430-04229	GASKET	1	
7	4TT-E3492-00	HOLDER, WIRE	1	
8	9850L-06012	SCREW, PAN HEAD	1	
9	4TT-13178-01	GEAR, PUMP DRIVE	1	
10	93603-22028	PIN, DOWEL	1	
11	93430-08036	CIRCLIP	2	
12	90467-07093	CLIP	1	
13	4FL-13175-00	SHAFT, WORM	1	
14	4FL-13176-00	METAL, WORM SHAFT OUTER	1	
15	93210-18397	O-RING	1	
16	98507-05014	SCREW, PAN HEAD	2	
17	93101-10837	OIL SEAL	1	

Gambar 04 INTAKE




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E3610-00	REED VALVE ASSY	1	
2	4TT-E3613-00	REED, VALVE	1	
3	4TT-E3616-00	STOPPER, REED VALVE	1	
4	9760N-03108	SCREW, PAN HEAD WITH WASHER	2	
5	4TT-E3621-00	GASKET, VALVE SEAT	1	
6	4TT-E3565-00	JOINT, CARBURETOR	1	
7	90450-44046	HOSE CLAMP ASSY	1	
8	9580M-06020	BOLT, FLANGE	4	
9	90460-49058	CLAMP, HOSE	1	
10	4TT-E4411-00	CASE, AIR CLEANER 1	1	
11	4TT-E4412-10	CAP, CLEANER CASE 1	1	
12	4TT-E4437-10	DUCT	1	
13	97607-06230	SCREW,WITH WASHER	3	
14	4TT-E4451-00	ELEMENT, AIR CLEANER	1	
15	4TT-E4476-00	SEAL	1	
16	4TT-E4453-00	JOINT, AIR CLEANER 1	1	
17	4TT-E443E-00	PIPE, DRAIN	1	
18	4TT-E4457-00	SEAL	1	
19	97607-06216	SCREW,WITH WASHER	2	
20	90465-08028	CLAMP	1	

Gambar 05 CARBURETOR





Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-E4101-10	CARBURETOR ASSY 1	1
2	127-14186-00	PIN, FLOAT	1
3	304-14185-00	FLOAT	1
4	2N4-14145-00	HOLDER	1
5	12R-14191-00	PLUG, DRAIN	1
6	304-14184-00	GASKET, FLOAT CHAMBER	1
7	4AC-14103-00	THROTTLE SCREW SET	1
8	3XV-14171-00	PLUNGER, STARTER	1
9	10X-14106-00	CABLE ADJUST SCREW SET	1
10	1M1-14169-00	CAP	1
11	214-14147-00	O-RING	1
12	4TL-14131-00	SPRING, THROTTLE VALVE	1
13	4AC-14197-00	PIPE	1
14	98507-04016	SCREW, PAN HEAD	4
15	92907-04100	WASHER, SPRING	4
16	4TT-1490J-10	NEEDLE SET	1
17	193-14126-00	GASKET	1
18	4TT-14141-38	NOZZLE, MAIN	1
19	304-14112-20	VALVE, THROTTLE 1	1
20	193-14142-17	JET, PILOT (#17.5)	1
21	3MB-14104-00	AIR SCREW SET	1
22	21W-14107-20	NEEDLE VALVE SET	1
23	137-14143-28	JET, MAIN (#140)	1
24	132-14146-00	PLATE	1
25	4TT-14196-00	PIPE	1
26	878-14147-00	O-RING	1
27	127-14135-00	SPRING, PLUNGER	1

Gambar 06 EXHAUST




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E4710-10	MUFFLER ASSY 1	1	
2	4TT-E4718-00	PROTECTOR, MUFFLER 1	1	
3	98907-06008	SCREW, BIND	2	
4	90202-05187	WASHER, PLATE	4	
5	3PP-E4613-00	GASKET, EXHAUST PIPE	1	
6	95707-08500	NUT, FLANGE	2	
7	97007-08020	BOLT	1	
8	92907-08200	WASHER	1	
9	95707-08500	NUT, FLANGE	1	
10	97007-08020	BOLT	1	
11	90201-083A8	WASHER, PLATE	1	

Gambar 07 CRANKCASE



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E5111-00	CRANKCASE 1	1	
2	4TT-E5121-00	CRANKCASE 2	1	
3	99530-10114	PIN, DOWEL	2	
4	90116-08388	BOLT, STUD	2	
5	90116-08318	BOLT, STUD	2	
6	9850M-06035	SCREW, PAN HEAD	3	
7	9850M-06060	SCREW, PAN HEAD	5	
8	9850L-06070	SCREW, PAN HEAD	5	
9	4TT-E5316-00	DAMPER, ENGINE MOUNT 1	2	
10	4NP-E5118-00	HOLDER	1	
11	9850M-08010	SCREW, PAN HEAD	1	
12	3KC-E5371-00	BREATHER	1	
13	90446-07228	HOSE	1	


Gambar 08 CRANKCASE COVER 1



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E5411-00	COVER, CRANKCASE 1	1	
2	4TT-E5451-00	GASKET, CRANKCASE COVER 1	1	
3	99530-10114	PIN, DOWEL	2	
4	9850M-06025	SCREW, PAN HEAD	2	
5	9850M-06035	SCREW, PAN HEAD	1	
6	4TT-E5431-00	COVER, CRANKCASE 3	1	
7	9850M-06020	SCREW, PAN HEAD	1	
8	9850M-06035	SCREW, PAN HEAD	1	
9	9850M-06045	SCREW, PAN HEAD	1	
10	4TT-E5421-00	COVER, CRANKCASE 2	1	
11	99530-10114	PIN, DOWEL	2	
12	4TT-E5461-00	GASKET, CRANKCASE COVER 2	1	
13	4TT-E5362-00	PLUG, OIL LEVEL	1	
14	93210-19809	O-RING	1	
15	9850M-06030	SCREW, PAN HEAD	7	
16	9850M-06040	SCREW, PAN HEAD	2	
17	95807-08080	BOLT, FLANGE	1	
18	90430-08119	GASKET	1	


Gambar 09 STARTER

Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-15660-00	KICK AXLE ASSY	1	
2	4TT-E5641-00	GEAR, KICK	1	
3	4TT-15671-00	WHEEL, RATCHET	1	
4	90468-26046	CLIP	1	
5	90508-26700	SPRING, TORSION	1	
6	4TT-E5666-00	SPACER	1	
7	90201-203F5	WASHER, PLATE	1	
8	93410-20038	CIRCLIP	1	
9	90201-17713	WASHER, PLATE	1	
10	4TT-E5620-00	KICK CRANK ASSY	1	
11	97027-08030	BOLT	1	
12	93102-17828	OIL SEAL	1	



4TT1431-7090


Gambar 10 CLUTCH



4TT1431-7100


Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E6150-00	PRIMARY DRIVEN GEAR COMP.	1	
2	90201-178K8	WASHER, PLATE	1	
3	4TT-E6371-00	BOSS, CLUTCH	1	
4	4TT-E6321-00	PLATE, FRICTION	4	
5	4TT-E6324-00	PLATE, CLUTCH 1	4	
6	4TT-E6331-00	PLATE, FRICTION 2	1	
7	4TT-E6383-00	SPRING, CLUTCH BOSS	1	
8	4TT-E6384-00	PLATE, SEAT	1	
9	4TT-E6351-00	PLATE, PRESSURE 1	1	
10	4TT-E6352-00	PLATE, PRESSURE 2	1	
11	90501-24858	SPRING, COMPRESSION	4	
12	90101-06871	BOLT	4	
13	90201-178K8	WASHER, PLATE	1	
14	90208-12015	WASHER, CONICAL SPRING	1	
15	90179-12659	NUT	1	
16	4TT-16356-00	ROD, PUSH 1	1	
17	93306-00106	BEARING	1	
18	90201-12163	WASHER, PLATE	1	
19	93102-12224	OIL SEAL	1	
20	93315-10838	BEARING	1	
21	90508-143A4	SPRING, TORSION	1	
22	4TT-E6380-00	PUSH LEVER ASSY	1	
23	4FU-16111-00	GEAR, PRIMARY DRIVE	1	
24	90387-178N4	COLLAR	1	

Gambar 11 TRANSMISSION



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-E7411-00	AXLE, MAIN	1	
2	4MA-E7151-00	GEAR, 5TH PINION (23T)	1	
3	90201-20266	WASHER, PLATE (T=1.0)	1	
4	93410-20038	CIRCLIP	1	
5	4MA-E7131-00	GEAR, 3RD/4TH PINION (19/21T)	1	
6	4MA-E7121-00	GEAR, 2ND PINION (16T)	1	
7	4XC-E7161-00	GEAR, 6TH PINION (24T)	1	
8	93306-30304	BEARING (B6303Z)	1	
9	93306-20201	BEARING (B6202)	1	
10	4TT-E7421-00	AXLE, DRIVE	1	
11	4MA-E7211-00	GEAR, 1ST WHEEL (34T)	1	
12	4MA-E7251-00	GEAR, 5TH WHEEL (23T)	1	
13	4MA-E7231-10	GEAR, 3RD WHEEL (26T)	1	
14	4MA-E7241-00	GEAR, 4TH WHEEL (24T)	1	
15	4MA-E7221-01	GEAR, 2ND WHEEL (29T)	1	
16	4TT-E7261-00	GEAR, 6TH WHEEL (21T)	1	
17	90209-18135	WASHER	2	
18	93410-22820	CIRCLIP	4	
19	90201-22555	WASHER, PLATE	1	
20	90201-15700	WASHER, PLATE	1	
21	99009-15400	CIRCLIP	1	
22	93306-20201	BEARING (B6202)	1	
23	93306-30401	BEARING (B6304)	1	
24	93102-20874	OIL SEAL	1	
25	10V-E7461-40	SPROCKET, DRIVE (14T)	1	
26	3KC-E7456-00	HOLDER, SPROCKET	1	
27	97027-06010	BOLT	2	


Gambar 11 TRANSMISSION




Nomor	Nomor Part	Nama Part		Keterangan
	28 4TT-E7471-00	PLATE, COVER	1	
	29 9850L-05012	SCREW, PAN HEAD	2	

Gambar 12 SHIFT CAM & FORK

Nomor	Nomor Part	Nama Part		Keterangan
	1 4TT-E8540-10	SHIFT CAM ASSY	1	
	2 90501-06022	SPRING, COMPRESSION	1	
	3 4TT-E8542-00	POINT, NEUTRAL	1	
	4 4TT-E8140-00	STOPPER LEVER ASSY	1	
	5 4TT-E8144-00	HANGER, SPRING	1	
	6 90109-063F8	BOLT	1	
	7 4TT-E8511-00	FORK, SHIFT 1	1	
	8 4TT-E8512-00	FORK, SHIFT 2	1	
	9 4TT-E8513-00	FORK, SHIFT 3	1	
	10 3KC-E8531-00	BAR, SHIFT FORK GUIDE 1	1	
	11 4TT-E8535-00	BAR, SHIFT FORK GUIDE 2	1	




Gambar 14 FRAME





Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F1110-10-33	FRAME COMP.	1 YB
2	95817-10110	BOLT, FLANGE	1
3	95817-08110	BOLT, FLANGE	1
4	95817-10170	BOLT, FLANGE	1
5	90201-101J1	WASHER, PLATE	1
6	95607-10200	NUT, U FLANGE	2
7	95607-08200	NUT, SELF-LOCKING	1
8	4TT-F1116-00	COLLAR	1
9	90170-10852	NUT	1
10	4TT-F117F-00	COVER	1
11	4TT-F132H-00	PLATE, COVER	1
12	4TT-F114H-00	SUPPORT, SEAT	1
13	4TT-F1321-00	STAY, SIDE COVER 1	1
14	4TT-F1322-00	STAY, SIDE COVER 2	1
15	4TT-F114J-00	SUPPORT, SEAT	1
16	9570L-06500	NUT, FLANGE	2
17	95807-06010	BOLT, FLANGE	1
18	90159-06840	SCREW, WITH WASHER	1
19	9760L-06250	SCREW, PAN HEAD WITH WASHER	1
20	90183-06023	NUT, SPRING	1
21	4TT-F177G-00	BOX, BATTERY	1
22	90183-06023	NUT, SPRING	2
23	90480-13867	GROMMET	2
24	56H-F139X-00	DAMPER	1
25	4VK-F8100-00	TOOL KIT	1

Gambar 15 FENDER



Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F1511-00-21	FENDER, FRONT	1 VRC1
2	4TT-F1513-00	STAY, FENDER 1	1
3	9580L-06012	BOLT, FLANGE	4
4	5R7-F1518-00	HOLDER, CABLE	1
5	4TT-F1611-00	FENDER, REAR	1
6	90119-06044	BOLT, WITH WASHER	5
7	2JH-F1685-00	BRACKET, LICENSE	1
8	9580L-06016	BOLT, FLANGE	2
9	90387-068B4	COLLAR	2
10	4TT-F1376-00	BAND, TOOL	1
11	99231-00018	EMBLEM, YAMAHA	1


Gambar 16 SIDE COVER



4TT4276-9160


Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F1711-00-33	COVER, SIDE 1	1 YB FOR VRC1/DPBMC
2	90480-23858	GROMMET	1
3	4TT-F1721-00-33	COVER, SIDE 2	1 YB FOR VRC1/DPBMC
4	90480-01868	GROMMET	2
5	90154-06024	SCREW, BINDING	2
6	9770L-50012	SCREW, TAPPING	4
7	90183-05807	NUT, SPRING	2
8	90159-06815	SCREW, WITH WASHER	2
9	4TT-F171E-00-33	COVER, SIDE 5	1 YB FOR VRC1/DPBMC
10	90183-05807	NUT, SPRING	2
11	4TT-F4742-00	GROMMET	2
12	4TT-F173E-C0	GRAPHIC 1	1 UR FOR VRC1
13	4TT-F173F-C0	GRAPHIC 2	1 UR FOR VRC1

Gambar 17 OIL TANK



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-F1751-00	TANK, OIL	1	
2	90159-06840	SCREW, WITH WASHER	1	
3	90480-01868	GROMMET	1	
4	2N3-F1771-00	BODY, CAP	1	
5	4TT-F1752-00	TUBE, FILLER 1	1	
6	4TT-F1766-00	PIPE, OIL	1	
7	90467-08003	CLIP	2	


Gambar 18 REAR ARM & SUSPENSION




4TT3431-9180


Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F2110-00-33	REAR ARM COMP.	1 YB
2	307-22123-00	BUSH 1	2
3	4TT-F2151-00	SEAL, GUARD	1
4	9580M-06012	BOLT, FLANGE	1
5	90387-06681	COLLAR	1
6	4TT-F2141-00	SHAFT, PIVOT	1
7	95617-12100	NUT, U	1
8	90201-12699	WASHER, PLATE	3
9	4TT-F2311-00	CASE, CHAIN	1
10	9850M-06012	SCREW, PAN HEAD	2
11	90201-06557	WASHER, PLATE	2
12	4AC-F5887-00	HOLDER, BRAKE HOSE	1
13	9580M-06012	BOLT, FLANGE	1
14	4TT-F2210-00	SHOCK ABSORBER ASSY, REAR	1
15	90109-104E4	BOLT	2
16	90201-10126	WASHER, PLATE	2
17	95607-10100	NUT, U	2

Gambar 19 STEERING




Nomor	Nomor Part	Nama Part		Keterangan
1	156-23412-00	RACE, BALL 2	1	
2	93501-04011	BALL	19	
3	22F-23412-01	RACE, BALL 2	1	
4	22F-23411-01	RACE, BALL 1	1	
5	93503-16003	BALL	22	
6	2JH-F3416-00	COVER, BALL RACE 2	1	
7	90179-25033	NUT	2	
8	4AC-F3418-00	WASHER, SPECIAL	1	
9	90202-26142	WASHER, PLATE	1	
10	4TT-F3435-00-7B	CROWN, HANDLE	1	BIB2
11	91317-08030	BOLT	2	
12	90209-10020	WASHER	1	
13	90106-10805	BOLT	1	
14	4TT-F331A-00	STAY	1	
15	9580M-06020	BOLT, FLANGE	2	
16	90387-07674	COLLAR	2	
17	90480-14869	GROMMET	2	
18	90201-06380	WASHER, PLATE	2	
19	4TT-F317J-00	DAMPER 1	2	
20	4AC-F5887-00	HOLDER, BRAKE HOSE	1	
21	9580M-06012	BOLT, FLANGE	1	
22	4TT-H3523-00	DAMPER	3	
23	2XF-H3524-V0	WASHER, SPECIAL	3	
24	9530L-05600	NUT	3	
25	4TT-F3391-00	PANEL, FRONT	1	
26	9850M-06012	SCREW, PAN HEAD	1	
27	90201-06050	WASHER, PLATE	1	

Gambar 20 FRONT FORK




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-F3102-00	FRONT FORK ASSY (L.H)	1	
2	4TT-F3126-00	TUBE, OUTER (LEFT)	1	
3	1T8-F3156-00	CLIP, OIL SEAL	1	
4	4XC-F3145-00	OIL SEAL	1	
5	4TT-F3110-00	INNER TUBE COMP.1	1	
6	4TT-F3170-00	CYLINDER COMP., FRONT FORK	1	
7	2JG-F3152-00	SPRING, SUB	1	
8	2JG-F3157-00	RING, PISTON	1	
9	2XF-F3111-00	BOLT, CAP	1	
10	276-F3114-00	GASKET	1	
11	2XF-F3168-00	CAP, FRONT FORK	1	
12	4XC-F3144-00	SEAL, DUST	1	
13	509-F3158-L0	GASKET	1	
14	278-F3181-50	BOLT, HEXAGON SOCKET HEAD	1	
15	4TT-F3141-00	SPRING, FRONT FORK	1	
16	290-F3149-00	WASHER, SPRING UPPER	1	
17	3PP-F3166-00	SPACER, OIL LOCK	1	
18	4TT-F3103-00	FRONT FORK ASSY (R.H)	1	
19	4TT-F3136-00	TUBE, OUTER (RIGHT)	1	
20	1T8-F3156-00	CLIP, OIL SEAL	1	
21	4XC-F3145-00	OIL SEAL	1	
22	4TT-F3110-00	INNER TUBE COMP.1	1	
23	4TT-F3170-00	CYLINDER COMP., FRONT FORK	1	
24	2JG-F3152-00	SPRING, SUB	1	
25	2JG-F3157-00	RING, PISTON	1	
26	2XF-F3111-00	BOLT, CAP	1	
27	276-F3114-00	GASKET	1	

Gambar 21 FUEL TANK




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-F4110-00-33	FUEL TANK COMP.	1	
2	9582L-06020	BOLT, FLANGE	4	
3	90480-18476	GROMMET	4	
4	90387-07674	COLLAR	4	
5	90201-064K6	WASHER, PLATE	4	
6	90445-106G0	HOSE (L300)	1	
7	90467-10008	CLIP	2	
8	4TT-F4312-00	PIPE 2	1	
9	4TT-F4500-00	FUEL COCK ASSY 1	1	
10	4X8-24512-00	O-RING	1	
11	90149-06011	SCREW	2	
12	90202-05193	WASHER, PLATE	2	
13	41J-F4610-00	CAP ASSY	1	
14	4M1-F4612-00	GASKET, CAP	1	
15	4TT-F4198-00	SEAT, RUBBER	1	

Gambar 22 SEAT



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-S4730-10	DOUBLE SEAT ASSY	1	
2	2JH-F4741-00	PAD, SEAT	2	
3	4TT-F4723-00	DAMPER, SEAT	4	
4	4TT-F4726-00	HINGE, SEAT	1	
5	90480-14872	GROMMET	3	
6	90201-06071	WASHER, PLATE	3	
7	9530L-06600	NUT	3	
8	90109-065E0	BOLT	1	
9	9570L-06500	NUT, FLANGE	1	
10	3YJ-W2470-01	SEAT LOCK ASSY	1	
11	9850L-06014	SCREW, PAN HEAD	1	
12	4TT-F4780-00	SEAT LOCK ASSY	1	
13	9580L-06012	BOLT, FLANGE	2	
14	4TT-F4773-00-WL	HANDLE, SEAT	1	
15	91317-08020	BOLT	2	
16	3SB-F3469-00	CAP, BOLT	2	


Gambar 23 FRONT WHEEL



Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F5168-00-UA	CAST WHEEL, FRONT	1 CWW
2	90560-10292	SPACER	1
3	93106-20001	OIL SEAL	1
4	93306-30003	BEARING (B6300Z)	2
5	94122-17800	TIRE (2.25-17 33L NR53)	1 INOUE
6	94222-17864	TUBE (2.25-17 TR4)	1 INOUE
7	1A1-25398-01	BALANCER, WHEEL (20G)	1 UN
	1A1-25399-00	BALANCER, WHEEL (10G)	1 UN
	2M0-25399-00	BALANCER, WHEEL (30G)	1 UN
8	90387-10277	COLLAR	1
9	3NA-F5181-00	AXLE, WHEEL	1
10	90185-10091	NUT, SELF-LOCKING	1
11	90201-101J1	WASHER, PLATE	1
12	3PP-25190-02	GEAR UNIT ASSY	1




Gambar 26 REAR WHEEL



Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F5338-00-UA	CAST WHEEL, REAR	1 CWW
2	90387-123A9	COLLAR	1
3	93306-30103	BEARING (B6301Z)	1
4	93306-30101	BEARING (B6301)	1
5	93210-41041	O-RING	1
6	5E7-F5364-00	DAMPER	4
7	93106-20033	OIL SEAL	1
8	3SB-F5366-00	CLUTCH, HUB	1
9	93106-26005	OIL SEAL	1
10	90387-128A5	COLLAR	1
11	93306-00406	BEARING (B6004Z)	1 NTN
12	4AC-F5438-10	SPROCKET, DRIVEN (38T)	1
13	90109-08864	BOLT	4
14	4TT-F5412-00	WASHER	2
15	90179-08888	NUT	4
16	94125-17800	TIRE (2.50-17 38L NR53)	1 INOUE
17	94222-17864	TUBE (2.25-17 TR4)	1 INOUE
18	1A1-25398-01	BALANCER, WHEEL (20G)	1 UN
	1A1-25399-00	BALANCER, WHEEL (10G)	1 UN
	2M0-25399-00	BALANCER, WHEEL (30G)	1 UN
19	4TT-F5381-00	AXLE, WHEEL	1
20	90201-128A4	WASHER, PLATE	2
21	90185-12046	NUT, SELF-LOCKING	1
22	90387-128D9	COLLAR	1
23	90387-123N2	COLLAR	1
24	4TT-F5388-00	PULLER, CHAIN 1	2
25	4TT-F2174-00	END 1	2

Gambar 28 REAR BRAKE CALIPER




Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F582W-00	DISK, REAR BRAKE 2	1
2	90149-08268	SCREW	4
3	4TT-F580W-00	CALIPER ASSY, REAR 2	1
4	4TT-W0057-50	PISTON ASSY, CALIPER	1
5	4TT-W0047-50	CALIPER SEAL KIT	1
6	3LD-F5934-00	SPRING, PAD	1
7	4TT-W0048-50	BLEED SCREW KIT	1
8	4TT-F0046-00	BRAKE PAD KIT 2	1
9	3SP-F5924-51	PIN, PAD	2
10	4TT-F4834-00	BOLT	2
11	95827-10030	BOLT, FLANGE	1
12	90201-10140	WASHER, PLATE	1



4TT1431-7280


Gambar 29 STEERING HANDLE & CABLE




4TT4276-9290

Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F6121-00-7B	HANDLEBAR (LEFT)	1 BIB2
2	4TT-F6122-00-7B	HANDLEBAR (RIGHT)	1 BIB2
3	9131M-08025	BOLT	2
4	9131L-06040	BOLT	2
5	2JK-F3469-00	CAP, BOLT	2
6	4TT-F6114-10-7B	STOPPER, HANDLE BAR	2 BIB2
7	2XF-F6246-00	END, GRIP	2
8	9870M-06030	SCREW, FLAT HEAD	2
9	4MA-F6240-00	GRIP ASSY	1
10	4TT-F6241-00	GRIP	1
11	4TT-F6260-10	CABLE ASSY, THROTTLE & PUMP	1
12	4TT-F6311-10	CABLE, THROTTLE 1	1
13	4TT-F6312-00	CABLE, THROTTLE 2	1
14	4TT-F6321-00	CABLE, PUMP	1
15	2A1-F6261-00	CONNECTOR, CABLE	1
16	55G-F6272-00	CAP	1
17	4TT-F6335-00	CABLE, CLUTCH	1
18	4TT-F6331-00	CABLE, STARTER 1	1
19	5R9-F6281-01	CAP, GRIP UPPER	1
20	5R9-F6282-00	CAP, GRIP LOWER	1
21	9850M-05016	SCREW, PAN HEAD	2
22	4AC-F6280-00	REAR VIEW MIRROR ASSY (LEFT)	1
23	4AC-F6290-00	REAR VIEW MIRROR ASSY (RIGHT)	1


Gambar 30 FRONT MASTER CYLINDER




4TT1431-7300


Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-F5872-00	HOSE, BRAKE 1	1	
2	90401-10810	BOLT, UNION	2	
3	90201-10118	WASHER, PLATE	4	
4	2JK-F5876-01	HOLDER, BRAKE HOSE 2	1	
5	9502M-06025	BOLT, FLANGE	1	
6	4TT-F583T-00	MASTER CYLINDER ASSY	1	
7	4TT-W0041-00	CYLINDER KIT, MASTER	1	
8	5G2-F5868-00	BOOT, MASTER CYLINDER	1	
9	4TT-F5854-00	DIAPHRAGM, RESERVOIR	1	
10	4TT-F5852-00	CAP, RESERVOIR	1	
11	9870M-04012	SCREW, FLAT HEAD	2	
12	56A-F5867-00	BRACKET, MASTER CYLINDER	1	
13	9502M-06025	BOLT, FLANGE	2	
14	4TT-H3922-00	LEVER 2	1	
15	90109-06577	BOLT	1	
16	9560M-06100	NUT, U	1	
17	3FV-83980-00	FRONT STOP SWITCH ASSY	1	
18	9760L-04212	SCREW, PAN HEAD WITH WASHER	1	

Gambar 31 STAND & FOOTREST




Nomor	Nomor Part	Nama Part		Keterangan
1	3SB-F7111-00-33	STAND, MAIN	1	
2	3SB-F7112-00	SHAFT, MAIN STAND	1	
3	90506-29828	SPRING, TENSION	1	
4	93430-12008	CIRCLIP	1	
5	4TT-F7211-00	PEDAL, BRAKE	1	
6	55G-F7114-00	STOPPER, MAIN STAND	1	
7	4TT-F7216-00	SPRING, RETURN	1	
8	99009-17400	CIRCLIP	1	
9	3SB-F7311-00-33	STAND, SIDE	1	
10	90109-08034	BOLT	1	
11	9530L-08700	NUT	1	
12	90506-20829	SPRING, TENSION	1	
13	90445-21848	HOSE (L70)	1	
14	4TT-F7452-00	BRACKET, FOOTREST 1	1	
15	4TT-F7413-00	COVER, FOOTREST	2	
16	4TT-F7462-10-33	BRACKET, FOOTREST 2	1	
17	90105-10802	BOLT, FLANGE	1	
18	95817-10025	BOLT, FLANGE	1	
19	90201-101J1	WASHER, PLATE	1	
20	95707-12500	NUT, FLANGE	1	
21	4TT-F7430-00	REAR FOOTREST ASSY 1	1	
22	4TT-F7433-00	COVER, REAR FOOTREST	1	
23	90249-06220	PIN	1	
24	9290L-06200	WASHER	1	
25	99001-05600	CIRCLIP	1	
26	95807-08016	BOLT, FLANGE	2	
27	4TT-F7440-00	REAR FOOTREST ASSY 2	1	

Gambar 33 COWLING 1




Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-F8351-00-21	BODY, COWLING	1 VRC1
2	90150-06021	SCREW, ROUND HEAD	2
3	90480-13018	GROMMET	2
4	90387-067K6	COLLAR	2
5	4TT-F8336-00	PLATE	1
6	90167-05808	SCREW, TAPPING	1
7	9580M-06012	BOLT, FLANGE	1
8	4TT-F1731-00	COVER, SIDE 3	1
9	4TT-F1741-00	COVER, SIDE 4	1
10	90150-06021	SCREW, ROUND HEAD	1
11	4TT-F8385-00-21	COVER, LOWER	1 VRC1
12	4TT-F8371-00	DAMPER	2
13	4TT-F8395-00-21	COVER, UNDER	1 VRC1
14	9770L-50012	SCREW, TAPPING	2
15	90183-05807	NUT, SPRING	2
16	90154-06811	SCREW, BINDING	2
17	4TT-F8283-00	BRACKET, POUCH	1
18	90480-01868	GROMMET	2
19	4TT-F8284-00	BRACKET, UNDER	1
20	90150-06021	SCREW, ROUND HEAD	2
21	90480-13018	GROMMET	2
22	90387-067K6	COLLAR	2
23	4TT-F8391-C0	GRAPHIC 1	1 UR FOR VRC1
25	4TT-F8385-X0-21	COVER,LOWER GRAPHIC SET	1 UR FOR VRC1
26	4TT-F8395-X0-21	COVER,LOWER GRAPHIC SET	1 UR FOR VRC1

Gambar 35 FLASHER LIGHT




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-H3310-00	FRONT FLASHER LIGHT ASSY 1	1	
2	4AC-H3311-00	BULB, FLASHER (12V-10W)	1	
3	4TT-H3312-00	LENS, FLASHER	1	
4	97701-30112	SCREW, TAPPING	1	
5	4TT-H3320-00	FRONT FLASHER LIGHT ASSY 2	1	
6	4AC-H3311-00	BULB, FLASHER (12V-10W)	1	
7	4TT-H3322-00	LENS, FLASHER 2	1	
8	97701-30112	SCREW, TAPPING	1	
9	90167-05808	SCREW, TAPPING	2	
10	90464-08828	CLAMP	2	

Gambar 36 METER




Nomor	Nomor Part	Nama Part	Keterangan
1	4TT-83510-10	SPEEDOMETER ASSY	1
2	4TT-83518-00	BULB, METER (14V-3W)	3
3	4TT-83517-00	BULB, TAILLIGHT (12V-1.7W)	6
4	4TT-83518-10	BULB, METER (14V-3W)	1
5	4TT-83517-10	BULB (12V-1.7W)	1
6	4TT-H3550-00	SPEEDOMETER CABLE ASSY	1

Gambar 38 TAILLIGHT



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-H4700-00	TAILLIGHT ASSY	1	
2	4AC-H4714-00	BULB (12V-21/5W)	1	
3	4AC-H3311-00	BULB, FLASHER (12V-10W)	2	
4	4TT-H4721-00	LENS, TAILLIGHT	1	
5	4TT-H3332-00	LENS, FLASHER	1	
6	4TT-H3342-00	LENS, FLASHER 2	1	
7	4TT-H4743-00	LENS, LICENCE LIGHT	1	
8	97702-40116	SCREW, TAPPING	2	
9	90480-18276	GROMMET	2	
10	90387-068N5	COLLAR	2	
11	9530L-06600	NUT	2	
12	4TT-H454J-00	CLAMP, CORD	1	

Gambar 39 HANDLE SWITCH & LEVER




Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-H3972-00	SWITCH, HANDLE 4	1	
2	98506-05030	SCREW, PAN HEAD	1	
3	98506-05040	SCREW, PAN HEAD	1	
4	4TT-H2911-00	HOLDER, LEVER 1	1	
5	4TT-H3912-00	LEVER 1	1	
6	4AP-H3945-00	BOLT, LEVER	1	
7	9560L-06100	NUT, U	1	
8	4AP-H3913-00	COLLAR, LEVER 1	1	
9	9502M-06020	BOLT, FLANGE	1	
10	90123-08818	BOLT	1	
11	90179-08148	NUT	1	




4TT1431-7400

Gambar 40 ELECTRICAL 1



Nomor	Nomor Part	Nama Part		Keterangan
1	55G-H2110-10	BATTERY ASSY	1	
2	90445-08893	HOSE	1	
3	22X-H2131-00	BAND, BATTERY	1	
4	4TT-H2150-00	FUSE HOLDER ASSY	1	
5	4AP-H2151-00	FUSE (10A)	2	
6	4TT-H2501-00	MAIN SWITCH STEERING LOCK	1	
7	9580L-06016	BOLT, FLANGE	2	
8	4TT-H2530-00	STOP SWITCH ASSY	1	
9	4TT-H2590-10	WIRE HARNESS ASSY	1	
10	4TT-F1999-00	CLAMP, WIREHARNESS	1	
11	9580L-06012	BOLT, FLANGE	1	
12	90464-16801	CLAMP	1	
13	2A1-H3936-10	BAND, SWITCH CORD	2	
14	3PP-E2491-00	CLAMP 1	2	
15	4AC-H2310-00	IGNITION COIL ASSY	1	
16	90153-06047	SCREW, HEXAGON	2	
17	81E-82370-30	PLUG CAP ASSY	2	
18	4TT-H2540-10	NEUTRAL SWITCH ASSY	1	
19	93210-26668	O-RING	1	
20	9760N-05216	SCREW, PAN HEAD WITH WASHER	2	

Gambar 41 ELECTRICAL 2



Nomor	Nomor Part	Nama Part		Keterangan
1	4TT-H5540-10	C.D.I. UNIT ASSY	1	
2	56H-F139X-00	DAMPER	1	
3	4TT-H5720-00	OIL LEVEL GAUGE ASSY	1	
4	4LY-H1960-00	RECTIFIER & REGULATOR ASSY	1	
5	9580L-06016	BOLT, FLANGE	1	
6	29G-83350-20	FLASHER RELAY ASSY	1	
7	4TT-H3371-00	HORN	1	
8	9580L-06012	BOLT, FLANGE	1	
9	4TT-85752-00	SENDER UNIT ASSY, FUEL METER	1	
10	4YS-H5753-00	GASKET, SENDER UNIT	1	
11	90109-05865	BOLT	4	
12	9290L-08600	WASHER	4	